			7R0129	_	ΓRMX	Rev. No	'	Page No.:	гау	je i or i
No.	Work Procedure/ Illustration						Records/Remarks/ Quality Pointers			
1			Mr.	War of		1		Qty/bo x	400	50pcs*8 bdls
	Put Vinyl Sheet (1250 x 1250) inside TRMX box.					12		Mat'l name	Dim.	Qty.
								TRMX box	544*370* 228mm	1
				7-1			1	Vinyl Sheet	1250* 1250	1
2				50pcs × 4bdls		Plastic vinyl bag of CSW assy	of	Partition board	343* 510	1
	Put the products inside the box					Vinyl bag	420* 280	8		
	b	direction per indle) 4 bundles)					Note : Step 5 is applicable only in QC FG inspection.			
3				1st I	_AYER			For CSW pro		Pricon box
	Layout p	artition board								
4	Put another bundles inside the box (opposite direction per bundle) (50pcs* 4 bundles)		2ND LAYER							
(5)				ZND LATER						
	Put NBP tag at the the flaps top Then \ Identific	e vinyl sheet. Identification top and tape (two side and portion). Warehouse cation tag at e of the box.	Note: If need to attach 4M tag Put 4M tag at the left side of the box							
	Prepared by					pared by	Checked by	Apprøv e d by	Noted by	
06/27/24 06/2/22	1 0	an a lake a				alabuvac	R Faseua	Q. Merin		
Eff. Date	Rev. No.		etails of change	Prepared	Checked App	-0-		June 2, 2022		

CONFIDENTIAL: ©2017 NBC; all rights reserved. Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC (Philippines)

MASTER COPY