

Process Name/ Title:

SOLDERING PROCESS/

Management of Iron and Vacuum Nozzle

Document No:

Effective Date:

WI-PRO-COM-003

May 6, 2019

WORK INSTRUCTION

Customer Code:

Rev. No.:

0

Page No.:

Page 1 of 1

No.


Work Procedure/ Illustration

Records/Remarks/ Quality Pointers

1. Confirm condition of iron after 10min since power on.


Product Code/Name:

ALL



In case of NG, report to leader and re-check with leader, then if it is needed, change part.

2. Measure temperature of iron.



*Point of measuring

- ① To sensor, put iron horizontally from foreside.
- 2 Put center of solder plate part on center of sensor.











Finish with condition that solder is on iron

① Put solder on iron which is heated

② Put solder which looks little bit bigger than usual on iron, then after turn power off.







Due to iron is covered by solder, iron can avoid oxidize and can use longer.

*Before break time, do not turn off and must cover iron by solder

05/06/2019 0 Transferred work instruction from NBC Japan (NBPS-9014).(for history purpose only) J. Lorzano O. Merin J. Lorzano O. Merin O.

CONFIDENTIAL: ©2017 NBC; all rights reserved. Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC (Philippines)
MASTER COPY

During working

efore Working

After working

DCC Stamp