

## Production Scanning of Product

Document No:

Rev. No.:

WI-PRO-COM-026

WORK INSTRUCTION
Product Code/Name:

Customer Code: Effective Date:

January 23, 2025

Page No.: 2 of 8

No. Work Procedure/ Illustration

2. RECEIVING AND ISSUANCE OF KITTED PARTS

Records/Remarks/ Quality Pointers

Open the Scanlist application in laptop/monitor.



SCAN RECORD UST

Search State Search Search

ALL

Select "Location" then choose "KIT"

2.2




\*Always double check the selected location to avoid wrong location.

Scan Model Name to check the last box scanned.



\*Always conduct rechecking of last box to avoid skip scan.

Select "New KIT",then system for scanning will appear.




\*Always check selected location.

Start scanning of QR code to receive
a.Receive
b.Operator's ID


c.Item (SA ID tag)

2.6




\*Conduct rechecking of "Type" and "Location" before proceed on scanning of Seatbelt ID tag.


Save the scanned item



\*Check the total boxes enter to the system versus actual ID tag.

CONFIDENTIAL: ©2017 NBC; all rights reserved. Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.









Process Name/ Title: Document No: WI-PRO-COM-026 **Production Scanning of Product** WORK INSTRUCTION Effective Date: January 23, 2025 Product Code/Name:

Customer Code:



## 4. ISSUANCE OF WORK IN PROCESS FROM SUB-ASSEMBLY TO NEXT PROCESS

Check condition of ID tag, must have "SLASH" or fill-up in the 4.1 clamp assembly portion.



No slash or fill-up on clamp assembly portion means WIP was not yet finished to Sub-assembly process.



## **FOR CLAMP ASSY**

\*Scanning must be done from time to time in the assembly line or upon finished of the output

CONFIDENTIAL: ©2017 NBC; all rights reserved. Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any nformation herein is strictly prohibited.



Product Code/Name:

**ALL** 

	Process Name/ Title:		
١	Production Scanning of Product	Document No:	WI-PRO-COM-026
7	WORK INSTRUCTION	Effective Date:	January 23, 2025

Customer Code:


**ALL** 

Rev. No.:

2

Page No.:

5 of 8



Check

Check <u>LABELS</u> attached in the box before proceed on transferring to next process.



(FOR INSPECTION)


4M (MACHINE)
(FOR INSPECTION)



in seen this labels, immediately ask the Leader for the proper treatment or transfer the parts to offline inspection area.

Make sure to always conduct checking of output box before proceed on transferring.

CONFIDENTIAL: ©2017 NBC; all rights reserved. Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.



Check and save the data once done.

5.6



\*Only maximum of 8 boxes are allowed to be scanned to received products prior saving.

\* Make sure to save the data before closing the system.

CONFIDENTIAL: ©2017 NBC; all rights reserved. Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.



