			V	VORK INSTRUCTION	Effectivity Date:		August 12, 2021					
		Process Name/Title:		TAPING ASSEMB	Validity Date:		n/a					
		Product Name/Code:	970A / 17J71	1-7051P Customer:	NBC		Document No.:		WI-ENG-PDE-2	99D		
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASS	PRO	Revision No.:	0	Page No.:	1 of 3		
								1				
PARTS:	1. Con 2. Assy	nector 4F1640-000□ (W) parts					JIG:	1. Insertion	1. Insertion jig			
NO.	Р	ROCESS NAME		WORK PROCEDURE/	ILLUSTRATION		TOOLS/PPE	0	QUALITY POIN	TERS		
1	P4	Connector setting to insertion jig 4F1640-000□ (W)	Holder Guide Lock BEFORE PRESSING 2. Press the guide lock using I	1. Get the consinsertion jig. Note: Follow to		Note: Check the connector before insertion. In gright hand and set to R. It (12pcs) using right hand res (11pcs) (assy parts) in	Safety Instruction Be sure to wear prescribed personal protective equipmen during operation (glove finger cots, etc.) Housekeeping 1. Maintain and alway practice 5's. 2. Personal things on t workplace is prohibite Keep it in your locker Alert level For any trouble, inform the Assembly Assistar Supervisor or Line Leac for immediate correcti action.	1. Use the property of the control o	1. Use the provided jig per model 2. No wrong usage of parts 3. No wrong orientation of connector 4. No damaged connector 5. No half-locked connector Note: Automatically dispose and replace the unit if once encountered Bend terminal, Difficulty of insertion, Half-locked connector. Note: If encountered abnormality, STOP and immediately CALL the attention of the leader. WAIT for further instruction and continue the process. Do not attempt to repair.			
Revision History Prepared by Reviewed by Approved by Not												
							- Mrs. L. a. a.	15:H	(p-t)	(1)		
08/12/21 0	Initial is	sue			M. Catapang	C. Villanueva A. Shimamura	A. Arañes M. Catapang	C. Villanueva	A. Shimamura	A. Aranes		
Eff. Date Rev. No			Details of Change		Prepared	Checked Approved		August 12, 2021				

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited. NBC (Philippines)

MASTER COPY

		WORK INSTRUCTION									Effectivity Date:		August 12, 2021			
		Process Name/Title: TAPING ASSEMBLY PROCESS									Validity Date:		n/a			
		Product Name/Code:	970A	17J711-7051P	Customer: NBC			Document No.:	WI-ENG-PDE-299D							
		Purpose:	PROTOTYPE			PRE-LAUNCH				MASSPRO		Revision No.:		0	Page No.:	2 of 3
PARTS:	1. Assy	parts											JIG	1. WIP Holder		
NO.	PF	ROCESS NAME	ME WORK PROCEDURE/ ILLUSTRATION								TOOLS/	QUALITY POINTERS				
2	Wire insertion to connector (Group 1 wires) 4F1640-000 (W) Note: Hold o insertion mu away from to		SEC T	5mm	176 18 BR V 179 18 1. Get termi 2. Hall 3. Rel 4. Hol 5. Ful insert Note:	nal. If insert th ease wire Id again <mark>5</mark> Iy inserted tion)	B 181 1 GR 180 1 and hold he wire. to check mm awayd wires (and he insertion in the inserti		EMPTY EMPTY EMPTY EMPTY vay from	Finger C	OTS	2. No ter 3. No de 4. Make inserted. 5. Must I insertion 6. No be Note: 029 fi Note: A replace Bend te Half-loc Note: I STOP a attenti further proces:	nave slight I nd terminal Refer to Cor Pull-Pus utomatically the unit if or rminal, Difficked connect f encountere nd immedia on of the lea- instruction	MOVEMENT after Wires GL-PRO-ASY- h procedure. V dispose and nee encountered culty of insertion, or. ed abnormality, tely CALL the der. WAIT for and continue the		

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC (Philippines)

MASTER COPY

				Effectivity Date:	August 12, 2021							
		Process Name/Title:	Validity Date:	n/a								
		Product Name/Code:	970A	1	17J711-7051P	NBC	Document No.:	WI-ENG-PDE-299D				
		Purpose:	☐ PROTOTYPE ■ PRE-LAUNCH ☐ MASSPRO						Revision No.:			3 of 3
									1	I		
PARTS:	1. Assy	parts					1. WIP Holder					
NO.	PF	ROCESS NAME			WORK PROCE	OURE/ ILL	USTRATION	TOOLS/	PPE	QUALITY POINTERS		
2	P4	Wire insertion to connector (Group 1 wires) 4F1640-000□ (W) (Continuation)	BEFOR	6. Release the Group 2 wires (11pcs.) (Assy parts) using left hand. Button R AFTER PRESSING 8. Hold the wires using left hand then gently pull the connector from jig. Check the insertion condition.						1. No wrong wire insertion 2. No terminal backing out 3. No deformed terminal 4. Make sure wires are properly inserted. 5. Must have slight MOVEMENT after insertion 6. No bend terminal/wires NG		
3		Pass WIP to P5					1. Pass WIP to WIP Holder. Note: One piece flow.	WIP HOL	DER	1. No W	IP overflow	

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC (Philippines)

MASTER COPY