

KD-926 Function

Note: Api call must be serial call, that is, after the end of a Api, you can call the next Api, otherwise it will appear Api function failure.




KD-926 Function A - Setting Before Offline Measurement

Note: KD-926 (A-1) must be called before using the offline measurement function of Api, otherwise the time of the off-line data may be incorrect.




A-1: commandFounction: errorBlock:

KD-926 Function B – Upload Offline Data



B-1: commandTransferMemoryDataWithUser: clientID:


KD-926 Function C -Query Function



C-1: commandFounction: errorBlock:

C-2: commandEnergy: errorBlock:

KD-926 Function D - Disconnect Device



D-1: commandDisconnectDevice