

KN-550BT Function

Note: Api call must be serial call, that is, after the end of a Api, you can call the next Api, otherwise it will appear Api function failure.




KN-550BT Function A - Setting Before Offline Measurement

Note: KN-550BT (A-1) must be called before using the offline measurement function of Api, otherwise the time of the off-line data may be incorrect.




A-1: commandFounction: errorBlock:

KN-550BT Function B – Upload Offline Data



B-1: commandTransferMemoryDataWithUser: clientID:


KN-550BT Function C -Query Functions



C-1: commandFounction: errorBlock:

C-2: commandEnergy: errorBlock:

KN-550BT Function D - Disconnect Device



D-1: commandDisconnectDevice