WORK AREA OPENING PROCEDURE

1. Inspect the work area before starting.

2. Keep the probe between 2 and 8 degrees.

3. Record the reading before closing.