

Tensile Test with Strain Rate Dependent Plasticity

When a metal is deformed plastically at a high strain rate, the hardening function will exhibit higher values than at quasistatic conditions. That is, a higher stress is reached for a certain strain.

In this example, the Johnson-Cook material model is used to simulate this behavior for a tensile test run at different loading rates. The current yield stress σ_{vs} is in this model described by Equation 1.

$$\sigma_{ys}(\varepsilon_{pe}) = (\sigma_{ys0} + k\varepsilon_{pe}^{n}) \left(1 + C\max\left(0, \log\left(\frac{\dot{\varepsilon}_{pe}}{\dot{\varepsilon}_{0}}\right)\right)\right) (1 - f(T_{h}))$$
 (1)

Here, σ_{vs0} , k, n, C, and $\dot{\varepsilon}_0$ are material parameters. The function $f(T_h)$ describes the temperature softening, where T_h is a normalized temperature. It is often expressed as $f(T_h) = T_h^m$ where m is a material parameter.

The current yield stress is a product of three factors:

- A standard strain hardening of the Ludvik form, with two parameters (k and n)
- A strain rate dependent factor with two parameters (C and $\dot{\epsilon}_0$). The reference strain rate $\dot{\epsilon}_0$ is the one at which k and n are determined
- A temperature-dependent factor for softening. The reference temperature used to define T_h is typically the one at which k and n are determined

In the model, four different strain rates are investigated. Two different studies are performed. In the first study, both strain rate hardening and temperature softening are included, while in the second study, only the strain rate hardening is considered.

The analysis is coupled to a heat-transfer analysis, in which the heating caused by the plastic deformation is included. Due to this, the temperature will increase during the process, which is the source of the thermal softening.

GEOMETRY

A 100 mm long cylindrical test specimen having a diameter of 10 mm in its central section is used. The detailed geometry is shown in Figure 1.




Figure 1: Geometry of the test specimen.

Axisymmetry is assumed, and only one half of the specimen is modeled due to the symmetry in the axial direction.

MATERIAL MODEL

The material is steel with properties as shown in Table 1.

TABLE I: MATERIAL PROPERTIES.

PROPERTY	SYMBOL	VALUE
Young's Modulus	E	200 GPa
Poisson's ratio	ν	0.3
Coefficient of thermal expansion	α	12.3·10 ⁻⁶ 1/K
Initial yield strength	σ_{ys0}	400 MPa
Strength coefficient	k	200 MPa
Hardening exponent	n	0.5
Reference strain rate	$\dot{\epsilon}_0$	I I/s
Strain rate strength coefficient	C	0.12
Temperature exponent	m	0.6
Reference temperature	T_{ref}	293.15 K
Melting temperature	T_{m}	1700 K
Thermal conductivity	k	44.5 W/(m·K)
Mass density	ρ	7850 kg/m ³
Heat capacity at constant pressure	c_{p}	475 J/(kg·K)

BOUNDARY CONDITIONS

Mechanical

At the thick end of the specimen, the displacement is prescribed in the axial direction. The displacement varies linearly with time, and the maximum elongation of the specimen is 10 mm. This elongation corresponds to an average strain of 10%, but since the plastic deformation occurs only in the thinner part of the specimen, the actual plastic strains will be of the order 20%.

Symmetry conditions are applied in the axial direction at the symmetry plane.

Thermal

On all external boundaries, free convection to external room temperature (293.15 K) is assumed. The heat transfer coefficient is assumed to be 15 W/($m^2 \cdot K$).

HEAT GENERATION

The inelastic deformation causes heat generation. The generated power per unit volume is the product of stress and the rate of plastic strain:

$$q = \sigma : \varepsilon_{\rm pl}$$
 (2)

This power is used as a source term in the heat transfer analysis through the **Thermal Expansion** multiphysics coupling.

THERMAL EXPANSION

Due to the heating, there will also be some thermal expansion of the specimen. This is included in the analysis through the Thermal Expansion multiphysics coupling, even though the effect is not large. The ratio between the thermal strain and the plastic strain can be estimated if the heat produced by plastic dissipation is assumed not to be conducted away from where it is generated:

$$\frac{\varepsilon_{\rm th}}{\varepsilon_{\rm pl}} = \frac{\alpha \Delta T}{\varepsilon_{\rm pl}} = \frac{\alpha \sigma_{\rm y} \varepsilon_{\rm pl}}{\varepsilon_{\rm pl} \rho c_{\rm p}} = \frac{\alpha \sigma_{\rm y}}{\rho c_{\rm p}} = \frac{12.3 \cdot 10^{-6} \cdot 4 \cdot 10^{8}}{7850 \cdot 475} \approx 1.3 \cdot 10^{-3} \tag{3}$$

Results and Discussion

In Figure 2, a general overview of the stress state is shown for the highest loading rate in the first study. The stress in the central part is about 600 MPa, whereas the initial yield stress is 400 MPa. It can be found that the plastic strain at this stage is approximately 20%, and the contributions to the current stress can be estimated from Equation 1 as

 $(400 \text{ MPa} + 200 \text{ MPa} \cdot 0.2^{0.5})(1 + 0.12 \cdot \log(29))(1 - 0.025^{0.6}) = 489 \text{ MPa} \cdot 1.36 \cdot 0.89$

Thus, there is about 22% strain hardening, 36% strain rate hardening, and 11% temperature softening.




Figure 2: Distribution of von Mises stress at the end of the tensile test at the highest strain rate.

The influence of the strain rate is shown in Figure 3. The axial stress at the center of the bar is plotted as a function of the axial strain. Since the stress state is close to uniaxial, this graph essentially shows the constitutive law. For the two lower strain rates, the strain rate hardening effect is negligible since these are below the reference strain rate. It becomes significant when the average strain rate approaches 1/s. Figure 4 shows a corresponding graph of what would be measured in a testing machine, that is the total force versus the end point displacement.




Figure 3: Axial stress and strain at the center of the test specimen for the four tensile tests at different strain rates.




Figure 4: Force versus displacement for the four tensile tests at different strain rates.

In the second study, the temperature softening part of the constitutive law is switched off. The effect on the stress–strain relation is shown in Figure 5. Without the thermal softening effect, the hardening is much more pronounced. It can also be noted that the curves for the two lowest strain rates now completely coincide. The small difference that could be seen in Figure 3 was an effect of heating only.




Figure 5: Comparison of stress vs. strain with and without thermal softening.

In Figure 6, the plastic strain distribution at the end of the experiment is shown for all four loading rates in the first study. At the lower strain rates, the maximum plastic deformation occurs in the central parts of the bar, whereas at the higher strain rates, the peak value actually occurs in a region closer to the loaded end. This redistribution is an effect of the thermal softening. The temperature will be higher at the center of the specimen at low loading rates.

In Figure 7, the final temperature is shown. At the lowest loading rate, the whole process takes 100 s. There is thus enough time for a substantial redistribution of the temperature field. At the two highest loading rates, the temperature field to a large extent matches the strain distribution, since the time is not sufficient for any substantial diffusion of heat. The temperature is however higher at the highest loading rate, since the strain rate hardening causes a higher stress and thus a larger heat production for the same strain.




Figure 6: Distribution of plastic strain at the end of the process for all four strain rates.




Figure 7: Temperature distribution at the end of the process for all four strain rates.

Note that all analyses were performed using an assumption of geometric linearity in order to speed up the analysis and simplify comparisons. In reality, geometric nonlinearity should be taken into account; without it, the strain localization ("necking") that may occur at the center of the bar cannot be predicted.

Application Library path: Nonlinear_Structural_Materials_Module/ Plasticity/strain rate dependent plasticity

Modeling Instructions

From the File menu, choose New.

NEW

In the New window, click Model Wizard.

MODEL WIZARD

- I In the Model Wizard window, click 2D Axisymmetric.
- 2 In the Select Physics tree, select Structural Mechanics>Thermal-Structure Interaction> Thermal Stress, Solid.
- 3 Click Add.
- 4 Click Study.
- 5 In the Select Study tree, select General Studies>Time Dependent.
- 6 Click **Done**.

GLOBAL DEFINITIONS

Parameters 1

- I In the Model Builder window, under Global Definitions click Parameters I.
- 2 In the Settings window for Parameters, locate the Parameters section.
- **3** In the table, enter the following settings:

Name	Expression	Value	Description
totL	100 [mm]	0.1 m	Total length of the specimen
avgStrain	0.1	0.1	Average strain

Name	Expression	Value	Description
wMax	avgStrain*totL/2	0.005 m	Max displacement of the symmetric half
strainRate	0.1[1/s]	0.1 1/s	Strain rate
tFinal	avgStrain/strainRate	l s	End time

GEOMETRY I

- I In the Model Builder window, under Component I (compl) click Geometry I.
- 2 In the Settings window for Geometry, locate the Units section.
- 3 From the Length unit list, choose mm.

Polygon I (poll)

- I In the Geometry toolbar, click / Polygon.
- 2 In the Settings window for Polygon, locate the Object Type section.
- 3 From the Type list, choose Open curve.
- 4 Locate the Coordinates section. From the Data source list, choose Vectors.
- 5 In the r text field, type 5 5 0 0 10 10 6.01.
- 6 In the z text field, type 20 0 0 50 50 30 30.

Quadratic Bézier I (qbI)

- I In the Geometry toolbar, click * More Primitives and choose Quadratic Bézier.
- 2 In the Settings window for Quadratic Bézier, locate the Control Points section.
- 3 In row 1, set r to 6.01.
- 4 In row 1, set z to 30.
- 5 In row 2, set r to 5.25.
- 6 In row 2, set z to 25.
- 7 In row 3, set r to 5.
- 8 In row 3, set z to 20.

Convert to Solid I (csoll)

- I In the Geometry toolbar, click Conversions and choose Convert to Solid.
- 2 Click in the **Graphics** window and then press Ctrl+A to select both objects.
- 3 In the Settings window for Convert to Solid, click **Paul Build Selected**.

Fillet I (fill)

I In the **Geometry** toolbar, click **Fillet**.

- 2 On the object csoll, select Point 5 only.
- 3 In the Settings window for Fillet, locate the Radius section.
- 4 In the Radius text field, type 4.
- 5 Click | Build Selected.

SOLID MECHANICS (SOLID)

Symmetry Plane I

- I In the Model Builder window, under Component I (compl) right-click Solid Mechanics (solid) and choose More Constraints>Symmetry Plane.
- 2 Select Boundary 2 only.

Prescribed Displacement I

- I In the Physics toolbar, click Boundaries and choose Prescribed Displacement.
- 2 Select Boundary 3 only.
- 3 In the Settings window for Prescribed Displacement, locate the Prescribed Displacement section.
- 4 From the Displacement in z direction list, choose Prescribed.
- **5** In the u_{0z} text field, type wMax*t/tFinal.

Linear Elastic Material I

In the Model Builder window, click Linear Elastic Material 1.

Plasticity I

- I In the Physics toolbar, click Attributes and choose Plasticity.
- 2 In the Settings window for Plasticity, locate the Plasticity Model section.
- 3 Find the Isotropic hardening model subsection. From the list, choose Johnson-Cook.

MATERIALS

Structural steel

- I In the Model Builder window, under Component I (compl) right-click Materials and choose Blank Material.
- 2 In the Settings window for Material, type Structural steel in the Label text field.

3 Locate the **Material Contents** section. In the table, enter the following settings:

Property	Variable	Value	Unit	Property group
Young's modulus	E	200[GPa]	Pa	Young's modulus and Poisson's ratio
Poisson's ratio	nu	0.3	1	Young's modulus and Poisson's ratio
Density	rho	7850	kg/m³	Basic
Initial yield stress	sigmags	400[MPa]	Pa	Elastoplastic material model
Strength coefficient	k_jcook	200[MPa]	Pa	Johnson-Cook
Hardening exponent	n_jcook	0.5	I	Johnson-Cook
Reference strain rate	epet0_jcook	1	I/s	Johnson-Cook
Strain rate strength coefficient	C_jcook	0.12	I	Johnson-Cook
Temperature exponent	m_jcook	0.6		Johnson-Cook
Thermal conductivity	k_iso ; kii = k_iso, kij = 0	44.5[W/ (m*K)]	W/(m·K)	Basic
Heat capacity at constant pressure	Ср	475[J/ (kg*K)]	J/(kg·K)	Basic
Coefficient of thermal expansion	alpha_iso; alphaii = alpha_iso, alphaij = 0	12.3e- 6[1/K]	I/K	Basic

HEAT TRANSFER IN SOLIDS (HT)

In the Model Builder window, under Component I (compl) click Heat Transfer in Solids (ht).

Heat Flux I

- I In the Physics toolbar, click Boundaries and choose Heat Flux.
- 2 In the Settings window for Heat Flux, locate the Heat Flux section.
- 3 From the Flux type list, choose Convective heat flux.
- 4 In the h text field, type 15.
- **5** Select Boundaries 4–8 only.

MULTIPHYSICS

Thermal Expansion I (tel)

- I In the Model Builder window, under Component I (compl)>Multiphysics click
 Thermal Expansion I (tel).
- 2 In the Settings window for Thermal Expansion, locate the Heat Sources section.
- 3 Clear the Thermoelastic damping check box.
- 4 Select the Mechanical losses check box.

As a default, the losses due to material nonlinearities are not computed. You have to explicitly enable that to get access to the heat source.

- **5** Click the **Show More Options** button in the **Model Builder** toolbar.
- **6** In the **Show More Options** dialog box, in the tree, select the check box for the node **Physics>Advanced Physics Options**.
- 7 Click OK.

SOLID MECHANICS (SOLID)

Linear Elastic Material I

- I In the Model Builder window, under Component I (compl)>Solid Mechanics (solid) click Linear Elastic Material I.
- 2 In the Settings window for Linear Elastic Material, click to expand the Energy Dissipation section.
- 3 Select the Calculate dissipated energy check box.

MESH I

- I In the Model Builder window, under Component I (compl) click Mesh I.
- 2 In the Settings window for Mesh, locate the Sequence Type section.
- **3** From the list, choose **User-controlled mesh**.

Size Expression 1

- I In the Model Builder window, right-click Free Triangular I and choose Size Expression.
- 2 In the Settings window for Size Expression, locate the Element Size Expression section.
- 3 In the Size expression text field, type if (z<30[mm],1[mm],3[mm]).
- 4 Click Build All.

STUDY I: WITH THERMAL SOFTENING

I In the Model Builder window, click Study I.

2 In the Settings window for Study, type Study 1: With Thermal Softening in the Label text field

Parametric Sweep

- I In the Study toolbar, click Parametric Sweep.
- 2 In the Settings window for Parametric Sweep, locate the Study Settings section.
- 3 Click + Add.
- **4** In the table, enter the following settings:

Parameter name	Parameter value list	Parameter unit
strainRate (Strain rate)	0.01 0.1 1 10	1/s

Step 1: Time Dependent

- I In the Model Builder window, click Step I: Time Dependent.
- 2 In the Settings window for Time Dependent, locate the Study Settings section.
- 3 In the **Output times** text field, type range(0,0.01*tFinal,0.1*tFinal) range(0.12*tFinal,0.02*tFinal,tFinal).

Solution I (soll)

- I In the Study toolbar, click Show Default Solver.
- 2 In the Model Builder window, expand the Solution I (soll) node, then click Time-Dependent Solver I.
- 3 In the Settings window for Time-Dependent Solver, click to expand the Time Stepping section.
- 4 From the Steps taken by solver list, choose Strict.
- 5 In the Study toolbar, click **Compute**.

RESULTS

Examine the distribution of stress after the fastest deformation.

Mirror 3D I

- I In the Results toolbar, click More Datasets and choose Mirror 3D.
- 2 In the Settings window for Mirror 3D, locate the Plane Data section.
- 3 From the Plane list, choose XY-planes.

Stress, 3D (solid)

- I In the Model Builder window, under Results click Stress, 3D (solid).
- 2 In the Settings window for 3D Plot Group, locate the Data section.

3 From the Dataset list, choose Mirror 3D 1.

Surface I

- I In the Model Builder window, expand the Stress, 3D (solid) node, then click Surface I.
- 2 In the Settings window for Surface, locate the Expression section.
- 3 From the Unit list, choose MPa.
- 4 In the Stress, 3D (solid) toolbar, click Plot.

Stress vs. Strain

Add a graph comparing axial stress vs. strain at the center of the specimen for all strain rates.

- I In the Home toolbar, click In Add Plot Group and choose ID Plot Group.
- 2 In the Settings window for ID Plot Group, type Stress vs. Strain in the Label text field
- 3 Locate the Data section. From the Dataset list, choose Study 1: With Thermal Softening/Parametric Solutions 1 (sol2).

Point Graph 1

- I Right-click Stress vs. Strain and choose Point Graph.
- **2** Select Point 1 only.
- 3 In the Settings window for Point Graph, locate the y-Axis Data section.
- **4** In the **Expression** text field, type solid.sz.
- 5 From the Unit list, choose MPa.
- 6 Locate the x-Axis Data section. From the Axis source data list, choose Inner solutions.
- 7 From the Parameter list, choose Expression.
- **8** In the **Expression** text field, type solid.eZZ.
- 9 Click to expand the Coloring and Style section. From the Width list, choose 2.
- 10 Click to expand the **Legends** section. Select the **Show legends** check box.
- II Find the **Include** subsection. Clear the **Point** check box.

Stress vs. Strain

- I In the Model Builder window, click Stress vs. Strain.
- 2 In the Settings window for ID Plot Group, click to expand the Title section.
- **3** From the **Title type** list, choose **None**.
- 4 Locate the **Plot Settings** section.

- 5 Select the x-axis label check box. In the associated text field, type Axial strain (1).
- 6 Select the y-axis label check box. In the associated text field, type Axial stress (MPa).
- 7 Locate the Legend section. From the Position list, choose Lower right.
- 8 In the Stress vs. Strain toolbar, click Plot.

DEFINITIONS

Add also a graph of the force as function of displacement. To get the force, you need to sum the reaction forces over the boundary having the prescribed displacement. After defining a new variable, you must update the solution to make that variable accessible for postprocessing.

Integration | (intob|)

- I In the Definitions toolbar, click // Nonlocal Couplings and choose Integration.
- 2 In the Settings window for Integration, locate the Source Selection section.
- 3 From the Geometric entity level list, choose Boundary.
- **4** Select Boundary 3 only.
- 5 Locate the Advanced section. From the Method list, choose Summation over nodes.

Variables 1

- I In the Model Builder window, right-click Definitions and choose Variables.
- 2 In the Settings window for Variables, locate the Variables section.
- **3** In the table, enter the following settings:

Name	Expression	Unit	Description
Fz	intop1(solid.RFz)	N	Axial force

STUDY I: WITH THERMAL SOFTENING

In the Study toolbar, click C Update Solution.

RESULTS

Force vs. Displacement

- I In the Home toolbar, click Add Plot Group and choose ID Plot Group.
- 2 In the Settings window for ID Plot Group, type Force vs. Displacement in the Label text field.
- 3 Locate the Data section. From the Dataset list, choose Study 1: With Thermal Softening/ Parametric Solutions I (sol2).

4 Locate the Legend section. From the Position list, choose Lower right.

Global I

- I Right-click Force vs. Displacement and choose Global.
- 2 In the Settings window for Global, locate the y-Axis Data section.
- **3** In the table, enter the following settings:

Expression	Unit	Description
Fz	kN	Axial force

- 4 Locate the x-Axis Data section. From the Axis source data list, choose Inner solutions.
- 5 From the Parameter list, choose Expression.
- **6** In the **Expression** text field, type wMax*t/tFinal.
- 7 Click to expand the Coloring and Style section. From the Width list, choose 2.
- 8 Locate the x-Axis Data section.
- **9** Select the **Description** check box. In the associated text field, type Extension.
- 10 Click to expand the Legends section. Find the Include subsection. Clear the Description check box.
- II In the Force vs. Displacement toolbar, click **Plot**.

Force vs. Displacement

- I In the Model Builder window, click Force vs. Displacement.
- 2 In the Settings window for ID Plot Group, locate the Title section.
- **3** From the **Title type** list, choose **None**.

ROOT

Add a second study in which the temperature softening is ignored.

ADD STUDY

- I In the Home toolbar, click Add Study to open the Add Study window.
- **2** Go to the **Add Study** window.
- 3 Find the Studies subsection. In the Select Study tree, select General Studies> Time Dependent.
- 4 Right-click and choose Add Study.
- 5 In the Home toolbar, click Add Study to close the Add Study window.

STUDY 2: WITHOUT THERMAL SOFTENING

In the Settings window for Study, type Study 2: Without Thermal Softening in the Label text field.

Parametric Sweep

- I In the Study toolbar, click Parametric Sweep.
- 2 In the Settings window for Parametric Sweep, locate the Study Settings section.
- 3 Click + Add.
- **4** In the table, enter the following settings:

Parameter name	Parameter value list	Parameter unit
strainRate (Strain rate)	0.01 0.1 1 10	1/s

Step 1: Time Dependent

- I In the Model Builder window, click Step I: Time Dependent.
- 2 In the Settings window for Time Dependent, locate the Study Settings section.
- 3 In the Output times text field, type range(0,0.01*tFinal,0.1*tFinal) range(0.12*tFinal,0.02*tFinal,tFinal).

SOLID MECHANICS (SOLID)

Plasticity 1

In the Model Builder window, under Component I (compl)>Solid Mechanics (solid)> Linear Elastic Material I right-click Plasticity I and choose Duplicate.

Plasticity 2

- I In the Model Builder window, click Plasticity 2.
- 2 In the Settings window for Plasticity, locate the Plasticity Model section.
- **3** Find the **Thermal softening model** subsection. From the list, choose **No thermal softening**.

STUDY I: WITH THERMAL SOFTENING

Step 1: Time Dependent

- I In the Model Builder window, under Study I: With Thermal Softening click Step 1: Time Dependent.
- 2 In the Settings window for Time Dependent, locate the Physics and Variables Selection section.
- 3 Select the Modify model configuration for study step check box.

- 4 In the tree, select Component I (compl)>Solid Mechanics (solid)> Linear Elastic Material I>Plasticity 2.
- 5 Right-click and choose Disable.

STUDY 2: WITHOUT THERMAL SOFTENING

Solution 7 (sol7)

- 2 In the Model Builder window, expand the Solution 7 (sol7) node, then click Time-Dependent Solver 1.
- 3 In the Settings window for Time-Dependent Solver, locate the Time Stepping section.
- 4 From the Steps taken by solver list, choose Strict.
- 5 In the Model Builder window, click Study 2: Without Thermal Softening.
- 6 In the Settings window for Study, locate the Study Settings section.
- 7 Clear the Generate default plots check box.
- 8 In the Study toolbar, click **Compute**.

RESULTS

Point Graph I

In the Model Builder window, under Results>Stress vs. Strain right-click Point Graph I and choose Duplicate.

Point Graph 2

- I In the Model Builder window, click Point Graph 2.
- 2 In the Settings window for Point Graph, locate the Data section.
- 3 From the Dataset list, choose Study 2: Without Thermal Softening/Parametric Solutions 2 (sol8).
- 4 Locate the Coloring and Style section. From the Color list, choose Cycle (reset).
- **5** Find the **Line markers** subsection. From the **Marker** list, choose **Cycle**.
- **6** From the **Positioning** list, choose **Interpolated**.
- 7 Locate the Legends section. Find the Prefix and suffix subsection. In the Suffix text field, type, No temperature softening.
- 8 In the Stress vs. Strain toolbar, click Plot.

ADD PREDEFINED PLOT

Create a plot comparing the distribution of plastic strains at the end of the process for all four strain rates.

- In the Home toolbar, click Add Predefined Plot to open the Add Predefined Plot window.
- 2 Go to the Add Predefined Plot window.
- 3 In the tree, select Study 1: With Thermal Softening/Parametric Solutions 1 (sol2)> Solid Mechanics>Equivalent Plastic Strain (solid).
- 4 Click Add Plot in the window toolbar.
- 5 In the Home toolbar, click Add Predefined Plot to close the Add Predefined Plot window.

RESULTS

Equivalent Plastic Strain (solid)

- I In the Settings window for 2D Plot Group, locate the Data section.
- 2 From the Parameter value (strainRate (1/s)) list, choose 0.01.
- 3 Click to expand the Title section. From the Title type list, choose Manual.
- 4 In the Title text area, type Equivalent plastic strain.
- 5 Clear the Parameter indicator text field.
- **6** Click to expand the **Plot Array** section. Select the **Enable** check box.
- 7 In the Relative padding text field, type 1.
- 8 In the Model Builder window, click Equivalent Plastic Strain (solid).

Max/Min Surface I

- I In the Equivalent Plastic Strain (solid) toolbar, click More Plots and choose Max/ Min Surface.
- 2 In the Settings window for Max/Min Surface, locate the Expression section.
- **3** In the **Expression** text field, type solid.epeGp.
- 4 Click to expand the **Advanced** section. Locate the **Display** section. From the **Display** list, choose Max.
- **5** Locate the **Text Format** section. In the **Display precision** text field, type **3**.
- 6 Click to expand the Plot Array section. Select the Manual indexing check box.

Annotation I

- I In the Model Builder window, right-click Equivalent Plastic Strain (solid) and choose Annotation.
- 2 In the Settings window for Annotation, locate the Position section.
- 3 In the Z text field, type totL/2.
- 4 Locate the Annotation section. From the Geometry level list, choose Global.
- 5 In the Text text field, type \$\dot \varepsilon = eval(strainRate,1/s,1) \; \mathrm s^{-1}\$.
- 6 Select the LaTeX markup check box.
- 7 Locate the Coloring and Style section. Clear the Show point check box.
- 8 Click to expand the Advanced section. In the Expression precision text field, type 2.
- 9 Locate the Coloring and Style section. From the Anchor point list, choose Lower left.
- 10 Click to expand the Plot Array section. Select the Manual indexing check box.
- II In the Equivalent Plastic Strain (solid) toolbar, click on Plot.
- 12 Click the **Zoom Extents** button in the **Graphics** toolbar.

Annotation I, Max/Min Surface I, Surface I

- I In the Model Builder window, under Results>Equivalent Plastic Strain (solid), Ctrl-click to select Surface I, Max/Min Surface I, and Annotation I.
- 2 Right-click and choose **Duplicate**.

Surface 2

- I In the Model Builder window, click Surface 2.
- 2 In the Settings window for Surface, locate the Data section.
- 3 From the Dataset list, choose Study 1: With Thermal Softening/ Parametric Solutions 1 (sol2).
- 4 From the Parameter value (strainRate (1/s)) list, choose 0.1.
- 5 Click to expand the Inherit Style section. From the Plot list, choose Surface 1.

Max/Min Surface 2

- I In the Model Builder window, click Max/Min Surface 2.
- 2 In the Settings window for Max/Min Surface, locate the Data section.
- 3 From the Dataset list, choose Study 1: With Thermal Softening/ Parametric Solutions 1 (sol2).
- 4 From the Parameter value (strainRate (1/s)) list, choose 0.1.

5 Locate the Plot Array section. In the Index text field, type 1.

Annotation 2

- I In the Model Builder window, click Annotation 2.
- 2 In the Settings window for Annotation, locate the Data section.
- 3 From the Dataset list, choose Study 1: With Thermal Softening/ Parametric Solutions I (sol2).
- 4 From the Parameter value (strainRate (1/s)) list, choose 0.1.
- **5** Locate the **Plot Array** section. In the **Index** text field, type 1.

Annotation 2, Max/Min Surface 2, Surface 2

- I In the Model Builder window, under Results>Equivalent Plastic Strain (solid), Ctrl-click to select Surface 2, Max/Min Surface 2, and Annotation 2.
- 2 Right-click and choose **Duplicate**.

Surface 3

- I In the Model Builder window, click Surface 3.
- 2 In the Settings window for Surface, locate the Data section.
- 3 From the Parameter value (strainRate (1/s)) list, choose 1.

Max/Min Surface 3

- I In the Model Builder window, expand the Surface 3 node, then click Results> Equivalent Plastic Strain (solid)>Max/Min Surface 3.
- 2 In the Settings window for Max/Min Surface, locate the Data section.
- 3 From the Parameter value (strainRate (1/s)) list, choose 1.
- 4 Locate the Coloring and Style section. From the Anchor point list, choose Upper right.
- 5 Locate the Plot Array section. In the Index text field, type 2.

Annotation 3

- I In the Model Builder window, expand the Max/Min Surface 3 node, then click Results> Equivalent Plastic Strain (solid)>Annotation 3.
- 2 In the Settings window for Annotation, locate the Data section.
- 3 From the Parameter value (strainRate (1/s)) list, choose 1.
- 4 Locate the Plot Array section. In the Index text field, type 2.

Annotation 3, Max/Min Surface 3, Surface 3

I In the Model Builder window, under Results>Equivalent Plastic Strain (solid), Ctrl-click to select Surface 3, Max/Min Surface 3, and Annotation 3.

2 Right-click and choose **Duplicate**.

Annotation 4, Surface 4

- I In the Model Builder window, under Results>Equivalent Plastic Strain (solid), Ctrl-click to select Surface 4 and Annotation 4.
- 2 In the Settings window for Surface, locate the Data section.
- 3 From the Parameter value (strainRate (1/s)) list, choose 10.

Max/Min Surface 4

- I In the Model Builder window, expand the Results>Equivalent Plastic Strain (solid)> Surface 4 node, then click Results>Equivalent Plastic Strain (solid)>Max/Min Surface 4.
- 2 In the Settings window for Max/Min Surface, locate the Data section.
- 3 From the Parameter value (strainRate (1/s)) list, choose 10.
- 4 Locate the **Plot Array** section. In the **Index** text field, type 3.

Annotation 4

- I In the Model Builder window, expand the Max/Min Surface 4 node, then click Results> Equivalent Plastic Strain (solid)>Annotation 4.
- 2 In the Settings window for Annotation, locate the Data section.
- 3 From the Parameter value (strainRate (1/s)) list, choose 10.
- 4 Locate the Plot Array section. In the Index text field, type 3.
- 5 Locate the Annotation section. In the Text text field, type \$\dot \varepsilon =
 eval(strainRate) \; \mathrm s^{-1}\$.

Equivalent Plastic Strain (solid)

- I In the Model Builder window, click Equivalent Plastic Strain (solid).
- 2 In the Equivalent Plastic Strain (solid) toolbar, click **1** Plot.
- 3 Click the Show Grid button in the Graphics toolbar.
- 4 Click the **Toom Extents** button in the **Graphics** toolbar.

Now, compare also the final temperature increase.

5 Right-click Equivalent Plastic Strain (solid) and choose Duplicate.

Temperature Increase

- I In the Model Builder window, expand the Results>Equivalent Plastic Strain (solid) I node, then click Equivalent Plastic Strain (solid) I.
- 2 In the Settings window for 2D Plot Group, type Temperature Increase in the Label text field.

3 Locate the **Title** section. In the **Title** text area, type Temperature increase.

Surface 1

- I In the Model Builder window, click Surface I.
- 2 In the Settings window for Surface, locate the Expression section.
- 3 In the Expression text field, type T-293.15.
- 4 Locate the Coloring and Style section. Click Change Color Table.
- 5 In the Color Table dialog box, select Thermal>Thermal in the tree.
- 6 Click OK.

Surface 2

- I In the Model Builder window, click Surface 2.
- 2 In the Settings window for Surface, locate the Expression section.
- **3** In the **Expression** text field, type T-minput.Tempref.

Surface 3

- I In the Model Builder window, click Surface 3.
- 2 In the Settings window for Surface, locate the Expression section.
- **3** In the **Expression** text field, type T-minput.Tempref.

Surface 4

- I In the Model Builder window, click Surface 4.
- 2 In the Settings window for Surface, locate the Expression section.
- 3 In the Expression text field, type T-minput. Tempref.

Max/Min Surface I

- I In the Model Builder window, click Max/Min Surface I.
- 2 In the Settings window for Max/Min Surface, locate the Expression section.
- **3** In the **Expression** text field, type T-minput.Tempref.

Max/Min Surface 2

- I In the Model Builder window, click Max/Min Surface 2.
- 2 In the Settings window for Max/Min Surface, locate the Expression section.
- **3** In the **Expression** text field, type T-minput.Tempref.

Max/Min Surface 3

- I In the Model Builder window, click Max/Min Surface 3.
- 2 In the Settings window for Max/Min Surface, locate the Expression section.

3 In the Expression text field, type T-minput.Tempref.

Max/Min Surface 4

- I In the Model Builder window, click Max/Min Surface 4.
- 2 In the Settings window for Max/Min Surface, locate the Expression section.
- 3 In the Expression text field, type T-minput.Tempref.
- 4 Click the **Zoom Extents** button in the **Graphics** toolbar.