Indicative lists of shipboard locations for asbestos are provided in the Inventory Guidelines (section 2.2.2.1 of appendix 5), and can be used as supporting material if additional assessment and sampling are required.

In order to safely remove asbestos and materials containing asbestos, the following protective measures should be taken, and the SRFP should describe how they are implemented by the Ship Recycling Facility:

.1 workers should be present who are trained and authorized in the removal of asbestos and materials containing asbestos in accordance with applicable

---CHUNK---

SOURCE: MEPC.210(63).pdf
implemented by the Ship Recycling Facility:

.1 workers should be present who are trained and authorized in the removal of asbestos and materials containing asbestos in accordance with applicable national requirements;

.2 the removal of the asbestos and materials containing asbestos should be conducted under the monitoring and management of the Competent person;

.3 the number of workers exposed to asbestos should be limited to the necessary minimum;

.4 the area in which the removal of asbestos and materials containing asbestos is to be conducted should be isolated from the other work areas, and entry should be allowed only to appropriately trained personnel. The area should be clearly posted with a caution that asbestos removal work is occurring;

.5 if the removal work includes cutting, boring, grinding or otherwise disturbing friable asbestos and materials containing asbestos which may scatter into the environment, appropriate protection should be provided, so as not to release the asbestos in the air, by isolating the area in the room or space where the removal will occur; a common approach is as follows:

---CHUNK---

SOURCE: MEPC.210(63).pdf
the environment, appropriate protection should be provided, so as not to release the asbestos in the air, by isolating the area in the room or space where the removal will occur; a common approach is as follows:

seal the room or space with plastic sheets;

the plastic sheets should be of sufficient strength;

I:\MEPC\63\23.doc
where the machines, equipment, pipes or spaces cannot be isolated or sealed (for example, a complex and narrow area under a floor plate in the engine room), partial protection may be provided with plastic sheets;

the isolated area should be maintained under negative pressure where possible; and

practices for dealing with materials containing asbestos under a partial pressure chamber system and the use of wet methods should be encouraged as far as possible;

.6 materials containing friable asbestos in areas such as walls and ceilings should be carefully removed, and water or an appropriate wetting agent should be applied prior to the removal of materials containing asbestos in

---CHUNK---

SOURCE: MEPC.210(63).pdf
.6 materials containing friable asbestos in areas such as walls and ceilings should be carefully removed, and water or an appropriate wetting agent should be applied prior to the removal of materials containing asbestos in order to prevent the asbestos from scattering into the atmosphere;

.7 personal protection equipment (PPE) for workers, including respiratory protection and special protective clothing for asbestos, should be provided;

.8 after removal of asbestos, the area should be cleaned in the following manner:

equipment and tools should be washed/cleaned and then removed from the area;

the asbestos and materials containing asbestos should be packed and sealed in plastic containers prior to being removed from the area;

the plastic sheets used for isolating the area should be moistened with water and handled carefully to prevent the asbestos from scattering;

an efficient vacuum cleaner should be used for cleaning the area, such as one equipped with a high efficiency particulate air (HEPA) filter; and

the airborne asbestos in the air and/or space should be checked before

---CHUNK---

SOURCE: MEPC.210(63).pdf
an efficient vacuum cleaner should be used for cleaning the area, such as one equipped with a high efficiency particulate air (HEPA) filter; and

the airborne asbestos in the air and/or space should be checked before

removing the plastic isolation sheets and allowing other work to continue in the area;

.9 workers removing asbestos should properly prepare for entry into a contaminated area, and should be decontaminated before leaving the contaminated area, as follows:

workers should not be allowed to wear street clothes in the isolated area or under their PPE;

after completing work in the isolated area, workers should shower to remove asbestos, and then enter a separate clean area to put on their clothes; and

work clothes should not be laundered at home; they should be bagged, labelled and laundered at an appropriate location at the Facility or off site;

.10 containers used for packing and transporting the removed asbestos

---CHUNK---

SOURCE: MEPC.210(63).pdf
RESOLUTION MEPC.210(63)
Adopted on 2 March 2012
2012 GUIDELINES FOR SAFE AND ENVIRONMENTALLY SOUND SHIP RECYCLINGMEPC 63/23
Annex 4, page 30

I:\MEPC\63\23.doc
.10 containers used for packing and transporting the removed asbestos materials should be properly labelled and sufficiently strong and resilient as to minimize the possibility of accidental damage or breakage during transport, which could result in the uncontained release of asbestos fibres into the atmosphere; and

.11 asbestos should not be reused or recycled, and its management and final disposal should comply with national requirements.

3.4.3.2 PCBs and materials containing PCBs

The Ship Recycling Facility should identify the location and quantity of the Hazardous Materials and wastes containing PCBs (polychlorinated biphenyls) by actively utilizing the IHM.

Indicative lists of shipboard locations for PCBs are provided in the Inventory Guidelines (section 2.2.2.2 of appendix 5), and can be used as supporting material if additional

assessment and sampling are required. PCBs may be contained in the equipment and

---CHUNK---

SOURCE: MEPC.210(63).pdf
(section 2.2.2.2 of appendix 5), and can be used as supporting material if additional assessment and sampling are required. PCBs may be contained in the equipment and materials in both solid and liquid forms as shown on the IHM. Since PCB sampling and analytical procedures can be expensive and time consuming, it may be more economical to presume that the materials do contain PCBs and remove and manage them accordingly.

In order to safely remove PCBs and materials containing PCBs, the following protective measures should be taken and the SRFP should describe how they are implemented by the Ship Recycling Facility:

.1 workers should be specifically trained and authorized in the removal of PCBs;

.2 personal protection equipment (PPE) for workers, including respiratory protection and dermal protection, should be provided;

.3 removal of Hazardous Materials and wastes containing PCBs should be carefully performed to avoid spills, volatilization or scattering, in the following