RESOLUTION MSC.39(63)
(adopted on 19 May 1994)
ADOPTION OF AMENDMENTS TO THE CODE ON
ALARMS AND INDICATORS ANNEX 23
RESOLUTION MSC.39(63)
(adopted on 19 May 1994)
MSC 63/23/Add.1
ADOPTION OF AMENDMENTS TO THE CODE ON ALARMS AND INDICATORS
THE MARITIME SAFETY COMMITTEE,
RECALLING Article 28(b) of the Convention on the International Maritime Organization concerning the functions of the Committee,
RECALLING ALSO that the Assembly, at its seventeenth session, when adopting resolution A.686(17) on the Code on alarms and indicators, authorized the Committee to amend or extend the Code as may be necessary,
RECOGNIZING the need for extension of the above Code to cover the Code for the Construction and Equipment of Mobile Offshore Drilling Units, 1989 (1989 MODU Code) and the Code of Safety for Diving Systems, with a view to ensuring their uniform application,
HAVING CONSIDERED at its sixty-third session the text of proposed amendments to the Code on alarms and indicators, developed by the Sub-Committee on Ship Design and Equipment,
1. ADOPTS amendments to the Code on alarms and indicators, the text of which is set out in the Annex to the present resolution;

amendments to the Code on alarms and indicators, developed by the Sub-Committee on Ship Design and Equipment,

1. ADOPTS amendments to the Code on alarms and indicators, the text of which is set out in the Annex to the present resolution;

2. RECOMMENDS Governments to take appropriate steps to give effect to the said amendments.

W/1649n/EWP

RESOLUTION MSC.39(63)

(adopted on 19 May 1994)

ADOPTION OF AMENDMENTS TO THE CODE ON ALARMS AND INDICATORS MSC 63/23/Add.1

ANNEX 23

Page 2

ANNEX

AMENDMENTS TO THE CODE ON ALARMS AND INDICATORS TO COVER THE 1989 MODU CODE AND THE CODE OF SAFETY FOR DIVING SYSTEMS

1 Add a new paragraph 5.6 to section 5 of the Code:

' ..

"5.6 On MODUs, where supplemental visual alarms are installed for general emergency alarms, the colour of these supplemental alarms may be amber, provided they flash with a pulse frequency of at least 4 Hz."

2 In paragraph 9.1, replace "9.1.8" by "9.1.9".

3 In the box containing notes below paragraph 9.2, replace "9.1.8" by "9.1.9".

4 Add the following to Table 9.1.1 - Location: navigating bridge

Priority

S

S

P

P

P

P

P

P

IHO Instrument

1989 MODU Code

7.4.1

7.4.2.5

8.5.5

7.4.2.7

7.4.2.8

"9.1.9".

4 Add the following to Table 9.1.1 - Location: navigating bridge

Priority	Instrument	Code	Fund ion	Notes
S	1989 MODU	7.4.1	Propeller pitch indicator	Column 2, table 8.1
S		7.4.2.5	Propulsion station in control indication	Columns 1&3, table 8.2
P		8.5.5	Propulsion machinery remote control failure	II-l/31.2.S'"
P		7.4.2.7	Propell er speed/ direction/pitch	II-l/49.3"'
P		7.4.2.8	Low starting air pressure	Column 1, table 8.2
P		7.4.2.9	Rudder angle indicator	II-l/31.2.7*
P		7.5.1.17	Steering gear running	Column 1, table ~.2
P		7.6.1	Steering gear phase failure/overload alarm	II-l/31.2.8*
IHO		7.6.3		

* Cross reference to SOLAS regulation

W/1649n/EWP

Type	Instrument	Code	Fund ion	Notes
I	1989 MODU	7.4.1	Propeller pitch indicator	Column 2, table 8.1
I		7.4.2.5	Propulsion station in control indication	Columns 1&3, table 8.2
A,V		8.5.5	Propulsion machinery remote control failure	II-l/31.2.S'"
HI		7.4.2.7	Propell er speed/ direction/pitch	II-l/49.3"'
A,V		7.4.2.8	Low starting air pressure	Column 1, table 8.2
A,V		7.4.2.9	Rudder angle indicator	II-l/31.2.7*
I		7.5.1.17	Steering gear running	Column 1, table ~.2
A,V		7.6.1	Steering gear phase failure/overload alarm	II-l/31.2.8*
		7.6.3		

Columns 1&3 table 8.2
II-l/31.2.9*
Column 1, table 8.1
II-1129.11*
Columns 1 & !3,
table 8.1
II-l/30.1*
Column 1, table 8.3
II-l/30.3*
RESOLUTION MSC.39(63)
(adopted on 19 May 1994)
ADOPTION OF AMENDMENTS TO THE CODE ON
ALARMS AND INDICATORS MSC 63/23/Add.l
ANNEX 23

Add the following to Table 9.1.1 (continued) - Location: navigating bridge
Priority
P
P
P
P
P
P
p
IMO
Instrument
1989 ttODU
Code
8.5.7
8.5.8
8.5.9

ALARMS AND INDICATORS MSC 63/23/Add.l
ANNEX 23
Page 3
Add the following to Table 9.1.1 (continued) - Location: navigating bridge
Priority
P
P
P
P
P
P
p
IMO
Instrument
1989 ttODU
Code
8.5.7
8.5.8
8.5.9
8.7.1
8.7.3
9.7.1
9.8
Function
Propulsion machinery
remote control failure
Prope 11 er speed/
di rect ion/pitch
Low propulsion starting
air pressure
Fault requi ri ng attention
Alarm system normal
supply failure
Fire detection
system alarm
Gas detection and
alarm system
Type Notes
A,V Column 1, table 8.2
II-l/31.2.7*
MI Column 1, table 8.3
II-l/49.6*
A,V Column 1, table 8.2
II-l/49.7*
A,V Column 1, table 8.3,
l including 8.3.5.1, l
l 8.4.1,8.8.6 and 8.9 l
l II-l/51 . 1.3* l
l l
A,V l Column 2, table 8.3 l
l II-1/5l.2.2* l
l l
A,V l Column 2, table 8.1 l
l II-2/l3* l
l l
A,V l ! Column 2, table 8.1 l
l l
l l

I I
I I
5 Add the following to Table 9.1.2 - Location: machinery space/machinery control room
I IMO
Priority I Instrument
I
I I 1989 HODU
I Code
I
P I 4.2.7
I
I
P I 4.5.2
I
I
I s I 5.3.12
I
I s I 5.5.7
I
I
Function
Machinery failure pre-al arm
Manual overriding of the automatic control indicator

control room
I IMO
Priority I Instrument
I
I I 1989 HODU
I Code
I
P I 4.2.7
I
I
P I 4.5.2
I
I
I s I 5.3.12
I
I s I 5.5.7
I
I
Function
Machinery failure
pre-al arm
Manual overriding
of the automatic
control indicator
Emergency battery
discharge
Electrical distribution
system low insulation
1 evel
* Cross reference to SOLAS regulation
W!1649n/EWP
Type
A,V
I
I
A or
I
Notes
Column 3, table 8.1
Column 3, table 8.1
Column 3, table 8.1
11-1/42.5.3*
! Column 3, table 8.1
II-l/45.4.2*
RESOLUTION MSC.39(63)
(adopted on 19 May 1994)
ADOPTION OF AMENDMENTS TO THE CODE ON
ALARMS AND INDICATORS MSC 63/23/Add.l
ANNEX 23
Page 4
Add the following to Table 9.1.2 (continued)
- Location: machinery space/machinery control room
Priority
P
S
S
P
P

p
P
P
P
P
P
P
lMO
Instrument
1989 t«JDU
Code
7.3.1
7.4.2.4
8.5.4
7.4.2.5
8.5.5
7.4.2.9
7.6.1
8.3.1
8.3.3
8.3.6
8.3.7
8.5.7
8.7.1
8.8.3
Functi on
Water tube boiler high water level alarm
Propulsion machinery orders from bridge
Propulsion station in control indication
Type
A,V
I
I
Low starting air pressure A,V
Steering gear running I
HP fuel oil pipe leakage , A,V

Functi on
Water tube boiler high
water level alarm
Propulsion machinery
orders from bridge
Propulsion station in
control indication
Type
A,V
I
I
Low starting air pressure A,V
Steering gear running I
HP fuel oil pipe leakage , A,V
I
I
Fuel heating temperature I A,V
alarm I ,
Fire detection alarm for , A,V
boiler/propulsion machinery' ,
Internal combustion engine, HI
monitors ,
I
Propulsion machinery 'A,V
remote control failure ,
I
fault requiring attention I A,V
I
I
I
I
I
I
Automatic changeover of ,A,V
propulsion auxiliaries ,
I ,
Cross reference to SOLAS regulation
WIl649n/EWP
Notes
Column 3, table 8.1
Column 3, table 8.2
11-1/31.2.4'"
11-1/49.2"
Columns 1&3, table 8.2
11-1/31.2.5'"
11-1/49.3'"
Columns 1&3, table 8.2
11-1/31 .2.9'"
Columns 1 & !3, Table 8.1
II-1/30. 1"
! Column 3, table 8.3
11-2115.5.1'"
! Column 3, table 8.3
11-2/15.5.3"
! Column 3, table 8.3
11-1/47.1'"
Column 3, table 8.3
11-1/47.2'"

Column 3, table 8.2
II-l/49.5"
At a normally manned control station in addition to main machinery control station including 8.3.5.1,8.4.1, 8 .8.6 and 8.9
11-1/51.1"
Column 3, table 8.3
11-1153.4.2"

Column 3, table 8.3
11-1/47.2'"
Column 3, table 8.2
II-l/49.5"
At a normally manned control
station in addition to main
machinery control station
including 8.3.5.1,8.4.1,
8 .8.6 and 8.9
11-1/51.1"
Column 3, table 8.3
11-1153.4.2"
RESOLUTION MSC.39(63)
(adopted on 19 May 1994)
ADOPTION OF AMENDMENTS TO THE CODE ON
ALARMS AND INDICATORS 6 Add the following to Table 9.1. 3
MSC 63/23/Add.1
ANNEX 23
Page 5
- Location: central fire control station where provided
I I I
I IMO I I
Pd ori ty I Instrument function I Type Notes I
I I I
I I I
I 1989 HODU I I
I Code I I
I I I
P I 9.7.1 fi re detection system I A,V,I II-U13'" I
I alarm I I
I I I
P I 9.8 Gas detection and alarm I A,V I
I system I I
I I I
I I I
7 Add the following to Table 9.1.4
- Location: at the equipment or at the location being monitored
I I I I
I IMO I I I
Priority I Instrument I function Type I Notes I
I I I I
I I I I
I 1989 HODU I I I
I Code I I I
I I I I
S I 3.6.4.2 I Watertight doors and hatch A,V I I
I I cover positions alarm I I
I I I I
S I 4.3.5 I Water level of essential HI I II-1/32.6'" I
I I boi 1 er I
I I I
S I 4.4.3 I Steam pressure HI II-1/33.3'" I
I I I

I Code I I I
I I I I
S I 3.6.4.2 I Watertight doors and hatch A,V I I
I I cover positions alarm I I
I I I I
S I 4.3.5 I Water level of essential HI I II-1/32.6"' I
I I boi 1 er I
I I I
S I 4.4.3 I Steam pressure HI II-1/33.3"' I
I I I
S I 4.8.6 I Bilge valve indicator I II-1121.2.12"' I
I I I
S I 4.9.8 I Ballast valve position I I
I I indicator I
I I I s I 4.11.11- I Cable tension Windlass power I I
I I Amount of cable paid out I
I I I
I I I
Cross reference to SOLAS regulation
W/1649n/EWP
RESOLUTION MSC.39(63)
(adopted on 19 May 1994)
ADOPTION OF AMENDMENTS TO THE CODE ON
ALARMS AND INDICATORS MSC 63/23/Add.1
ANNEX 23
Page 6
Add the following to Table 9.1.4 (continued)
- Location: at the equipment or at the location being monitored
lMO
Pri ority Instrument Function Type Notes
Diving Code
P 2.5.3 Diving bell internal pressure MI ! At the location of the
attendant monitoring
diving operations
p 2.5.5 Diving bell etc. overpressure A,V ! At the location of the
alarm attendant monitoring
diving operations
P 2.9.3 Diving equipment fire A,V ! At the location of the
detection alarm attendant monitoring
diving operations

p 2.5.5 Diving bell etc. overpressure A,V ! At the location of the
alarm attendant monitoring
diving operations
P 2.9.3 Diving equipment fire A,V ! At the location of the
detection alarm attendant monitoring
diving operations
B Add the following to Table 9.1.5 - Location: engineers' accommodation
I I
I IMO I
Priority I Instrument Function Type I Notes
I I
I I
I 1989 MODU I
I Code I
I I
P I 7.8 Engineers' alarm A I Column 4, table 8.3
I I II-l/38'"
I I
P I 8.7.1 Fault requiring attention A I Activate engineers' alarm
I I required by 7.8 includingl
I I 8.3.5.1,8.4.1,8.8.6 I
I I and 8.9 I
I I 11-1/51.1.5" I
I I I
I I I
Cross reference to SOLAS regulation
W/1649n/EWP
RESOLUTION MSC.39(63)
(adopted on 19 May 1994)
ADOPTION OF AMENDMENTS TO THE CODE ON
ALARMS AND INDICATORS MSC 63/23/Add.l
ANNEX 23
Page 7
9 Add the following to Table 9 . 1 . 6 - Location: miscellaneous
I I
IMO I I
Pdori ty Instrument Function I Type Notes I
I I
I I
1989 HODU I I
Code I I
I I
S 3.6.2 Watertight boundary valve I I At the remote control I
position indicator I station I
I I
P 4. 3.2 Oil-fired boiler low water I A,V Alarm at an attended I

I I
I I
1989 HODU I I
Code I I
I I
S 3.6.2 Watertight boundary valve I I At the remote control I
position indicator I station I
I I
P 4. 3.2 Oil-fired boiler low water I A,V Alarm at an attended I
level, air supply failure I location I
or flame fail ure I II-1/32.2"' I
I I
S 4.8.1 Presence of water indicator I I I
I I
S 4.11.12 Cable tension speed and I I At a manned station I
direction of wind I
I
s I 6.3.1.1.3 Loss of ventilation A,V At a manned station I
I I
s I 6.3.1.2.3 Loss of ventilation A,V At a manned station I
I I
s I 6.3.1.3.3 Loss of ventilation A,V At a manned station I
I overpressure I
I I
p I 8.7.1 Fault requiring attention A,V Including 8.3.5.1, I
I 8.4.1,8.8.6 and 8.9 I
I II-l/Sl.1"' I
I I
P I 9.7.1 Fire detection system alarm A,V I At alarm location
I I easily accessible to
I I crew at all times
I I II-2!l3.1 .6"'
I I
EM I 9.7.1 Fire detection alarm not A I Alarmed to crew,
receiving attention I may be part of general
I emergency alarm
I II-2!l3.1.4"'
I
P 9.8 Gas detection and alarm A,V I ! Alarm at a location
system I easily accessible to
1 crew at all times
I

receiving attention I may be part of general
I emergency alarm
I II-2!I3.1.4'"
I
P 9.8 Gas detection and alarm A,V I ! Alarm at a location
system I easily accessible to
1 crew at all times
I
EM 10 . 16. 1 . General emergency alarm A I Clearly perceptible inl
I all parts of the unit I
I Ill/6.4.2'" I
I III/50'" I
I I
Cross reference to SOLAS regulation
W/1649n/EWP
RESOLUTION MSC.39(63)
(adopted on 19 May 1994)
ADOPTION OF AMENDMENTS TO THE CODE ON
ALARMS AND INDICATORS MSC 63/23/Add.l
ANNEX 23
Page 8
Add the following to Table 9.1.6 (continued) - Location: miscellaneous
IMO I
Priority Instrument Function I Type Notes
I
I
Diving Code I
I
P 2.5.2 Compression chamber internal I HI At central control position
pressure I
I
P 2.5.3 Diving bell external I MI Within the bell
pressure I
I
P 2.9.3 Diving equipment fire I A,V ! At an attended location
detection alarm I other than the above
I
I
P 2. 11 . 2 Compression chamber/diving I MI At central control position
bell parameters I
I
P 2.11.3 Diving bell oxygen I MI Within the bell
and C02 levels I
I
10 Add the following to Table 9.1.8 - Location: not indicated by IMO
instruments
IMO

bell parameters I
I
P 2.11.3 Diving bell oxygen I MI Within the bell
and C02 levels I
I
10 Add the following to Table 9.1.8 - Location: not indicated by IMO
instruments
IMO
Priority Instrument Function Type Notes
1989 tlJDU
Code
S 4.9.15 Draught indicator HI ! At an attended location
,.,. 11-1/8.7.3'"
* Cross reference to SOLAS regulation
W/1649n/EWP
RESOLUTION MSC.39(63)
(adopted on 19 May 1994)
ADOPTION OF AMENDMENTS TO THE CODE ON
ALARMS AND INDICATORS MSC 63/23/Add.l
ANNEX 23
Page 9
11 Add the following new table:
"Table 9.1. 9 Location: central ballast control station of
column-stabilized MODUs
IMO
Priority Instrument Function Type Notes
1989 t«)DU
Code
S 3.6.4.1 Watertight doors and hatch I,V
cover position indicator
S 3.6.4.2 Watertight doors and hatch A,V
covers position alarm
S 4.8.8.1 Flooding detector I
P 4.8.8.3 Propulsion and pump room A,V
bilge high water level alarm
S 4.9.10.2 Ballast pump status I For details see also 4.9.12
indicating system
S 4.9.10.4 Ballast valve position I For details see also 4.9.17
indicating system
S 4.9.10.5 Tank level indicating system I For details see also 4.9.14

S 4.9.10.2 Ballast pump status I For details see also 4.9.12
indicating system
S 4.9.10.4 Ballast valve position I For details see also 4.9.17
indicating system
S 4.9.10.5 Tank level indicating system I For details see also 4.9.14
S 4.9.10.6 Draught indicating system I For details see also 4.9.15
S 4.9.10.7 Heel and trim indicators I
S 4.9.10.8 Main and emergency power I
available indication
S 4.9.10.9 Ballast system I
hydraulic/pneumatic
pressure indicating system
S 4.9.14.1 Ballast tanks liquid level MI
S 4.9.14.2 Other tanks liquid level MI
S 4.9.17 Ballast valve position I
**1<
W/1649n/EWP
"
RESOLUTION MSC.39(63)
(adopted on 19 May 1994)
ADOPTION OF AMENDMENTS TO THE CODE ON
ALARMS AND INDICATORS RESOLUTION MSC.39(63)
(adopted on 19 May 1994)
ADOPTION OF AMENDMENTS TO THE CODE ON
ALARMS AND INDICATORS