Lecture 6

Last time:

- Response of 1st order systems
- Response of 2nd order systems:
 - Overdamped (two distinct real poles)
 - Critically damped (two identical real poles)

Now we will look at a third case for 2nd-order systmes:

Complex Conjugate Poles

Consider a transfer function of the general form

$$G(s) = \frac{K\gamma_0}{s^2 + \gamma_1 s + \gamma_0}$$

Let the poles of G(s) be at $s_1 = -\sigma + j\omega$ and $s_2 = -\sigma - j\omega$. Then, the denominator of G(s) becomes:

$$d(s) \equiv s^{2} + \gamma_{1}s + \gamma_{0}$$

$$d(s) = (s + \sigma - j\omega)(s + \sigma + j\omega)$$

$$= (s + \sigma)^{2} + \omega^{2}$$

$$= s^{2} + 2\sigma s + (\sigma^{2} + \omega^{2})$$

$$\times$$
Im
$$\theta$$

$$-\sigma$$
Re
$$\times$$

$$\times$$

$$\times$$

Then, G(s) becomes

$$G(s) = \frac{K(\sigma^2 + \omega^2)}{s^2 + 2\sigma s + (\sigma^2 + \omega^2)}$$

Another way this is often written is

$$G(s) = \frac{K\omega_n^2}{s^2 + 2\zeta\omega_n s + \omega_n^2}$$

This involves the introduction of two parameters:

- Natural Frequency: $\omega_n = \sqrt{\sigma^2 + \omega^2}$, the radial distance of the pole from the origin.
- Damping Ratio: $\zeta = \sigma/\omega_n$. Referring to the figure above, we can see that $\zeta = \sigma/\omega_n = \cos\theta$.

Conversely, the real and imaginary parts of the pole can be written in terms of ζ and ω_n :

$$\sigma = \zeta \omega_n, \quad \omega = \omega_n \sqrt{1 - \zeta^2}$$

From the pole-zero diagram, we can see that there is a geometric relationship between the natural frequency ω_n and the damping factor σ .

$$\zeta = \cos \theta, \quad \sqrt{1 - \zeta^2} = \sin \theta$$

So, the poles are at

$$s = -\underbrace{\frac{\cos \theta}{\zeta} \omega_n \pm j \underbrace{\omega_n \sqrt{1 - \zeta^2}}_{\omega_n}}_{\sigma}$$

Response to Step Input

Let's now consider how a system with complex conjugate poles will respond to a step input:

$$Y(s) = \frac{1}{s} \cdot G(s) = \frac{1}{s} \cdot \frac{K(\sigma^2 + \omega^2)}{s^2 + 2\sigma s + (\sigma^2 + \omega^2)}$$
$$= \frac{K\omega_n^2}{s(s^2 + 2\zeta\omega_n s + \omega_n^2)}$$
$$= \frac{R_1}{s} + \frac{R_2 s + R_3}{(s + \zeta\omega_n)^2 + \omega^2}$$

(Partial fraction expansion steps not shown here.)


$$\Rightarrow y(t) = K \left(1 - e^{-\zeta \omega_n t} \left(\cos(\omega t) + \frac{\zeta}{\sqrt{1 - \zeta^2}} \sin(\omega t) \right) \right) 1(t)$$


Using the geometric relationship between $\cos \theta$ and $\sin \theta$ with ζ , we can rewrite this as

$$y(t) = K \left(1 - \frac{e^{-\zeta \omega_n t}}{\sin \theta} \left(\cos(\omega t) \sin(\theta) + \sin(\omega t) \cos(\theta) \right) \right)$$

This can be further simplified to:

$$y(t) = K \left(1 - \frac{e^{-\zeta \omega_n t}}{\sin \theta} \sin(\omega t + \theta)\right)$$






The system is said to be **underdamped**. In this case, damping is not enough to prevent overshoot. Recall that in the overdamped case (real poles), damping is more than enough to prevent overshoot.

Terminology:

- σ : Damping factor
- ζ: Damping ratio
- ω (or ω_d): Damped natural frequency (the oscillation frequency for $\sigma \neq 0$ or $\zeta \neq 0$)
- ω_n : Undamped natural frequency (the oscillation frequency for $\sigma = \zeta = 0$)

Let's now look at some performance characteristics for underdamped second-order systems.



• **Peak Time:** $t_p = \frac{\pi}{\omega} = \frac{\pi}{\omega_n \sqrt{1-\zeta^2}}$ This formula is obtained by setting dy/dt = 0. The full derivation can be found in the book on page 175.

Peak time is a measure of how fast the system responds. If you want to decrease the peak time t_p , make ω larger, which is done by moving the poles further from the real axis.

• Percent Overshoot: $\%OS = \frac{M_1}{K} \times 100\% = \frac{y_{max} - \lim_{t \to \infty} y(t)}{\lim_{t \to \infty} y(t)} \times 100\%$, where y_{max} is found by evaluating y(t) at $t = t_p$. So,


$$y_{max} = K\left(1 + e^{-\frac{\zeta\pi}{\sqrt{1-\zeta^2}}}\right)$$

Therefore,

$$y_{max} - K = M_1 = Ke^{-\frac{\zeta\pi}{\sqrt{1-\zeta^2}}} \quad \Rightarrow \quad \%OS = 100e^{-\pi\zeta/\sqrt{1-\zeta^2}}$$

The inverse relationship of this is:
$$\zeta = \frac{-\ln{(\%OS/100)}}{\sqrt{\pi^2 + \ln^2{(\%OS/100)}}}$$

What does overshoot tell us about peak time? We know that to decrease peak time, we must make ω larger. Recall that $\zeta = \cos \theta$ and note that overshoot increases with decreasing ζ .



Im Re

Moving the poles straight up improves the peak time, but you increase θ and therefore increase the overshoot.

Moving the poles radially decreases peak time without increasing overshoot.

• Time Constant: $\tau = \frac{1}{\sigma} = \frac{1}{\zeta \omega_n}$

The time constant is a measure of the rate of decay of the asymptote, in other words the rapidity at which the exponential term decays, where a larger time constant means it decays slower.

- Settling Time: t_s is time to the final entrance to a tolerance band. It is a measure of the duration of the transient response.
 - For a $\pm 5\%$ tolerance band: $t_s = 3\tau$
 - For a $\pm 2\%$ tolerance band: $t_s = 4\tau$

Unless specified, settling time typically uses the $\pm 2\%$ tolerance band.

• Rise Time: t_r has multiple definitions; for this course, we will define the rise time as: the time required to go from the initial value (typically 0) to the final value. For this definition, we can construct a mathematical definition of rise time:

$$y(t) = K \left(1 - \frac{e^{-\zeta \omega_n t}}{\sin \theta} \sin(\omega t + \theta)\right)$$

The final value is K, so look for the first point where y(t) = K:

$$K = K \left(1 - \frac{e^{-\zeta \omega_n t_r}}{\sin \theta} \sin(\omega t_r + \theta) \right)$$

$$1 = 1 - \frac{e^{-\zeta \omega_n t_r}}{\sin \theta} \sin(\omega t_r + \theta)$$

$$0 = \frac{e^{-\zeta \omega_n t_r}}{\sin \theta} \sin(\omega t_r + \theta)$$

$$0 = \sin(\omega t_r + \theta)$$

$$\omega t_r + \theta = \pi$$

$$\Rightarrow t_r = \frac{\pi - \theta}{\omega} = \frac{\pi - \theta}{\omega_n \sqrt{1 - \zeta^2}}$$

Alternatively, the course book defines rise time as the time required to go from 0.1 (10%) of the final value to 0.9 (90%) of the final value. There is no simple analytical relationship between rise time and damping ratio. Typically, it is computed digitally or measured in simulation. Figure 4.16 in the book (page 177) graphically shows a relationship between damping ratio and rise time.

Example

$$G(s) = \frac{0.01}{s^2 + 0.002s + 0.01}$$

Our goal is to find: ζ , ω_n , t_s , t_p , and %OS for a unit step input. To find ζ and ω_n , let's compare G(s) to the standard form for a 2nd-order transfer function

$$G(s) = \frac{0.01}{s^2 + 0.002s + 0.01} \Leftrightarrow \frac{K\omega_n^2}{s^2 + 2\zeta\omega_n s + \omega_n^2}$$

G(0) = 1 so K = 1. Then,

$$\omega_n = \sqrt{0.01} = 0.1$$

$$2\zeta\omega_n = 0.002 \quad \Rightarrow \quad \zeta = \frac{0.002}{2\omega_n} = \frac{0.002}{2 \cdot 0.1} = 0.01$$

We can now find the performance metrics using ω_n and ζ .


$$t_p = \frac{\pi}{\omega} = \frac{\pi}{\omega_n \sqrt{1 - \zeta^2}} = \frac{\pi}{0.1\sqrt{1 - 0.01^2}} \approx 31.4$$

$$\%OS = 100e^{\frac{-\pi\zeta}{\sqrt{1-\zeta^2}}} = 100e^{\frac{-\pi\cdot0.01}{\sqrt{1-0.01^2}}} \approx 96.9\%$$

$$t_s = 4\tau = \frac{4}{\zeta\omega_n} = \frac{4}{0.01\cdot0.1} = 4000 \ sec$$

Identifying 2nd Order Systems

How can we re-construct a 2nd-order G(s) from a time-plot of the step response?



$$G(s) = \frac{K\omega_n^2}{s^2 + 2\zeta\omega_n s + \omega_n^2}$$

So, we need to find K, ω_n , and ζ .

1. First, we can find K from the steady-state value of y:

$$K = \lim_{t \to \infty} y(t)$$

2. Next, we can use the peak time to obtain ω :

$$t_p = \frac{\pi}{\omega} \Rightarrow \omega = \frac{\pi}{t_p}$$

3. We can get ζ from the overshoot percent.

$$\%OS = f(\zeta) \Rightarrow \zeta = f^{-1}(\%OS)$$

Fully written out:

$$\%OS = 100e^{-\pi\zeta/\sqrt{1-\zeta^2}} \quad \Rightarrow \quad \zeta = \frac{-\ln(\%OS/100)}{\sqrt{\pi^2 + \ln^2(\%OS/100)}}$$

4. Finally, using ζ and ω we can obtain ω_n

$$\omega = \omega_n \sqrt{1 - \zeta^2} \Rightarrow \omega_n = \frac{\omega}{\sqrt{1 - \zeta^2}}$$

Zeros and Higher-Order Systems

We now have methods for determining the so-called performance specification of a 2nd-order system. That is, we can calculate key characteristics of the system's response to a unit step input. But, all that we have done so far is only valid for a **2nd order system with no zeros**. Hence, the formulas developed are not valid for a 3rd or 4th order system (for example), nor even for a 2nd order system with a zero.

Question: Are there circumstances under which these formulas can be used anyways for a higher order system or a for a 2nd order system with a zero? Let's check: Consider a 2nd-order system with a zero at $s = -\alpha \zeta \omega_n$.

$$G(s) = \frac{K \frac{\omega_n}{\alpha \zeta} (s + \alpha \zeta \omega_n)}{s^2 + 2\zeta \omega_n s + \omega_n^2}$$

$$(\text{static gain of } K)$$

$$Y(s) = \frac{1}{s} G(s) \Rightarrow sY(s) = G(s)$$

$$\lim_{t \to \infty} y(t) = \lim_{s \to 0} sY(s) = \lim_{s \to 0} G(s) = G(0) = K$$

$$y(0^+) = \lim_{s \to \infty} G(s) = \lim_{s \to \infty} \left(K \cdot \frac{\frac{\omega_n}{\alpha \zeta} \left(\frac{1}{s} + \frac{\alpha \zeta \omega_n}{s^2} \right)}{1 + \frac{2\zeta \omega_n}{s} + \frac{\omega_n^2}{s^2}} \right) = 0$$

$$\dot{y}(0^+) = \lim_{s \to \infty} [sG(s)] \text{ (Note: } \mathcal{L}[y] = G(s))$$

$$= \lim_{s \to \infty} \left(K \cdot \frac{\frac{\omega_n}{\alpha \zeta} \left(1 + \frac{\alpha \zeta \omega_n}{s} \right)}{1 + \frac{2\zeta \omega_n}{s} + \frac{\omega_n^2}{s^2}} \right) = K \frac{\frac{\omega_n}{\alpha \zeta}}{1}$$

$$\dot{y}(0^+) = \frac{K\omega_n}{\alpha \zeta}$$


There are two cases for α :

Case 1: α is positive (the zero is in the LHP). Then,

- The initial slope is positive
- The system is sped up
- Increased overshoot


Case 2: α is negative (the zero is in the RHP). Then,

- The initial slope is negative (Reverse Action)
- The system can be slowed down substantially (high t_p)
- Increased overshoot (but not as much as a LHP zero)
- Systems with a RHP zero are called "non-minimum phase" systems




If $\alpha \to \infty$, $\dot{y}(0^+) \to 0$. So, the extra zero has minimal effect on the output if the zero is far left of the complex poles. How far is necessary? Generally 4 to 5 times as from from the $j\omega$ -axis as the complex poles. In other words

$$\alpha > 4\zeta\omega_n \text{ or } \alpha > 5\zeta\omega_n$$



3rd and Higher Order Systems

Third and higher-order systems can be approximated as 2nd-order systems if the extra poles are far left of the dominant complex poles. These extra poles could be either individual real poles or complex conjugate pairs.



We will not go over a derivation for this, but it follows the same method we just used for zeros. In general, if the poles are 4 to 5 times further left of the dominant poles, then the formulas for 2nd-order systems can be used.