
## **Soldering EMF parts**



Don't forget to solder the isolated wire between the two FET's F5 and F6.

Hint: While soldering the wire, be careful not to melt the isolation. This may short circuit F6 and cause F3 on the top side to be overloaded.

Hint: IC3 (LM324) may not have a marker for Pin 1. At one side of the IC you'll find a bevel instead. Place IC3 with the bevel on the side where you see the marker in the picture below.

Nr.	Part	Туре	Form
8	R17, R18, R19, R20, R21, R22	3k3	0805
10	R23, R24, R25, R26, R27, R28	10k	0805
20	IC3	LM324	SO14
	Isolated wire		

