On suppose que les lignes de contrôle associées à un champ dans la valeur n'est pas spécifiée prennent la valeur zéro (ceci est important uniquement pour les broches de chargement des registres à chargement).

Label	ALU control	SRC1	SRC2	Register control	Memory	PCWrite control	Coprocessor 0	Exception	Sequencing
0 : FETCH					Translate PC			Int else bad fetch	Next
1:	Add	PC	4		Read PC	ALU			Next
2:	Add	PC	Extshft	Read			Read reg	Bad privilege	Dispatch I
3 : MEM	Add	A	Extend						Next
4:					Translate ALU			Bad @	Dispatch II
5 : LW					Read ALU				Next
6:				Write MDR					goto FETCH
7 : SW					Write ALU				goto FETCH
8 : R-FORMAT	Func code	A	В					Overflow	Next
9:				Write ALU					goto FETCH
10 : BEQ	Sub	A	В			ALUOut-cond			goto FETCH
11 : JUMP						Jump @			goto FETCH
12 : MFC0				Write C0					goto FETCH
13: MTC0							Write reg		goto FETCH
14 : SYSCALL						Handler	Write PC		Next
15:							Write cause Sys		goto FETCH
16 : ERET						EPC	Read EPC		goto FETCH
17 : INT						Handler	Write PC		Next
18:							Write cause Int		goto FETCH
19 : BAD @ FETCH / LW						Handler	Write PC		Next
20:							Write cause AdEL		goto FETCH
21 : BAD @ SW						Handler	Write PC		Next
22:							Write cause AdES		goto FETCH
23 : BAD PRIV / BAD INSTR						Handler	Write PC		Next
24:							Write cause RI		goto FETCH
25 : OVERFLOW						Handler	Write PC		Next
26:							Write cause Ov		goto FETCH