## Change Order Report For Project SynthyTwo.Project.PrjPcb And SynthyTwo.Project.PrjPcb

Action	Object		Change Document	Status
Add Pins To	) Nets			
Add	EA1-1 to NetC47_2	In	PCBROUTAGE.PcbDoc	Unknown Pin: Pin EA1-1
Add	EA1-2 to NetC46_2	ln	PCBROUTAGE.PcbDoc	Unknown Pin: Pin EA1-2
Add	EA1-3 to GND	In	PCBROUTAGE.PcbDoc	Unknown Pin: Pin EA1-3
Add	EB1-1 to NetC49_2	<u>In</u>	PCBROUTAGE.PcbDoc	Unknown Pin: Pin EB1-1
Add	EB1-2 to NetC48_2	<u> </u>	PCBROUTAGE.PcbDoc	Unknown Pin: Pin EB1-2
Add Add	EB1-3 to GND EC1-1 to NetC51 2	In In	PCBROUTAGE.PcbDoc PCBROUTAGE.PcbDoc	Unknown Pin: Pin EB1-3 Unknown Pin: Pin EC1-1
Add	EC1-2 to NetC50_2	In	PCBROUTAGE.PcbDoc	Unknown Pin: Pin EC1-2
Add	EC1-3 to GND	In	PCBROUTAGE.PcbDoc	Unknown Pin: Pin EC1-3
Add	ED1-1 to NetC53_2	In	PCBROUTAGE.PcbDoc	Unknown Pin: Pin ED1-1
Add	ED1-2 to NetC52_2	ln	PCBROUTAGE.PcbDoc	Unknown Pin: Pin ED1-2
Add	ED1-3 to GND	In	PCBROUTAGE.PcbDoc	Unknown Pin: Pin ED1-3
Add	P9-1 to GND	<u>In</u>	PCBROUTAGE.PcbDoc	Unknown Pin: Pin P9-1
Add	P9-2 to NetP9_2	<u>In</u>	PCBROUTAGE.PcbDoc	Unknown Pin: Pin P9-2
Add Add	P9-3 to NetC44_1 U2- to +5V	ln ln	PCBROUTAGE.PcbDoc PCBROUTAGE.PcbDoc	Unknown Pin: Pin P9-3 Unknown Pin: Pin U2-
Add	U2- to GND	III	PCBROUTAGE.PcbDoc	Unknown Pin: Pin U2-
Add	U2- to NetD2_1	In	PCBROUTAGE.PcbDoc	Unknown Pin: Pin U2-
Add	U2- to NetD2_2	In	PCBROUTAGE.PcbDoc	Unknown Pin: Pin U2-
Add	U2- to NetR7_1	ln	PCBROUTAGE.PcbDoc	Unknown Pin: Pin U2-
Add	U2- to NetR9_2	In	PCBROUTAGE.PcbDoc	Unknown Pin: Pin U2-
Add	U4-3 to NetC25_1	<u>In</u>	PCBROUTAGE.PcbDoc	Unknown Pin: Pin U4-3
Add	U4-5 to NetC23_2	<u>ln</u>	PCBROUTAGE.PcbDoc	Unknown Pin: Pin U4-5
Add Add	U4-7 to NetC25_2 U5-1 to NetR14_2	In In	PCBROUTAGE.PcbDoc PCBROUTAGE.PcbDoc	Unknown Pin: Pin U4-7 Unknown Pin: Pin U5-1
Add	U5-2 to NetR14_1	III	PCBROUTAGE.PcbDoc	Unknown Pin: Pin U5-1
Add	U5-3 to GND	ln	PCBROUTAGE.PcbDoc	Unknown Pin: Pin U5-3
Add	U5-4 to +9V	In	PCBROUTAGE.PcbDoc	Unknown Pin: Pin U5-4
Add	U5-11 to -9V	ln	PCBROUTAGE.PcbDoc	Unknown Pin: Pin U5-11
Add	U6-3 to NetR26_1	In	PCBROUTAGE.PcbDoc	Unknown Pin: Pin U6-3
Add	U6-5 to NetC24_2	<u>In</u>	PCBROUTAGE.PcbDoc	Unknown Pin: Pin U6-5
Add	U6-7 to NetR23_1	<u>In</u>	PCBROUTAGE.PcbDoc	Unknown Pin: Pin U6-7
Add Add	U7-12 to NetR28_1 U7-13 to GND	In In	PCBROUTAGE.PcbDoc PCBROUTAGE.PcbDoc	Unknown Pin: Pin U7-12 Unknown Pin: Pin U7-13
Add	U7-13 to GND U7-14 to NetR28_2	In	PCBROUTAGE.PcbDoc	Unknown Pin: Pin U7-14
Add	U10-8 to +9V	In	PCBROUTAGE.PcbDoc	Unknown Pin: Pin U10-8
Add	U11-5 to NetC35_2	In	PCBROUTAGE.PcbDoc	Unknown Pin: Pin U11-5
Add	U11-6 to NetC23_1	In	PCBROUTAGE.PcbDoc	Unknown Pin: Pin U11-6
Add	U11-7 to NetC23_1	In	PCBROUTAGE.PcbDoc	Unknown Pin: Pin U11-7
Add	U12-7 to NetR42_1	ln	PCBROUTAGE.PcbDoc	Unknown Pin: Pin U12-7
Add	U12-8 to NetR34_2	<u>In</u>	PCBROUTAGE.PcbDoc	Unknown Pin: Pin U12-8
Add Add	U12-11 to +9V U14-8 to +9V	<u>In</u> In	PCBROUTAGE.PcbDoc PCBROUTAGE.PcbDoc	Unknown Pin: Pin U12-11 Unknown Pin: Pin U14-8
Add	U15-5 to NetR55_2	In	PCBROUTAGE.PcbDoc	Unknown Pin: Pin U15-5
Add	U15-6 to NetR48 1	In	PCBROUTAGE.PcbDoc	Unknown Pin: Pin U15-6
Add	U15-7 to NetR47_2	In	PCBROUTAGE.PcbDoc	Unknown Pin: Pin U15-7
Add	U16-8 to +9V	In	PCBROUTAGE.PcbDoc	Unknown Pin: Pin U16-8
Add	U19-5 to GND	ln	PCBROUTAGE.PcbDoc	Unknown Pin: Pin U19-5
Add	U19-6 to NetC36_1	<u>In</u>	PCBROUTAGE.PcbDoc	Unknown Pin: Pin U19-6
Add	U19-7 to NetC36_2	<u>ln</u>	PCBROUTAGE.PcbDoc	Unknown Pin: Pin U19-7
Add Add	U20-11 to -9V U21-11 to -9V	<u>In</u> In	PCBROUTAGE.PcbDoc PCBROUTAGE.PcbDoc	Unknown Pin: Pin U20-11 Unknown Pin: Pin U21-11
Add	U22-11 to -9V	In	PCBROUTAGE.PcbDoc	Unknown Pin: Pin U22-11
Add	U24-1 to NetC43_2	In	PCBROUTAGE.PcbDoc	Unknown Pin: Pin U24-1
Add	U24-2 to NetC43_1	In	PCBROUTAGE.PcbDoc	Unknown Pin: Pin U24-2
Add	U24-3 to GND	ln	PCBROUTAGE.PcbDoc	Unknown Pin: Pin U24-3
Add	U24-4 to -9V	ln	PCBROUTAGE.PcbDoc	Unknown Pin: Pin U24-4
Add	U24-8 to +9V	<u>In</u>	PCBROUTAGE.PcbDoc	Unknown Pin: Pin U24-8
Add	U25-1 to NetJ5_4	<u>In</u>	PCBROUTAGE.PcbDoc	Unknown Pin: Pin U25-1
Add Add	U25-2 to NetR82_1 U25-3 to GND	In In	PCBROUTAGE.PcbDoc PCBROUTAGE.PcbDoc	Unknown Pin: Pin U25-2 Unknown Pin: Pin U25-3
Add	U25-4 to -9V	In	PCBROUTAGE.PcbDoc	Unknown Pin: Pin U25-3 Unknown Pin: Pin U25-4
Add	U25-8 to +9V	In	PCBROUTAGE.PcbDoc	Unknown Pin: Pin U25-8
Add	U26-1 to NetJ5_2	In	PCBROUTAGE.PcbDoc	Unknown Pin: Pin U26-1
Add	U26-2 to NetC45_2	ln	PCBROUTAGE.PcbDoc	Unknown Pin: Pin U26-2
Add	U26-3 to NetR85_2	ln	PCBROUTAGE.PcbDoc	Unknown Pin: Pin U26-3
Add	U26-4 to +9V	ln	PCBROUTAGE.PcbDoc	Unknown Pin: Pin U26-4

Action	Object		Change Document	Status
Add Pins T	o Nets			
Add	U26-11 to -9V	In	PCBROUTAGE.PcbDoc	Unknown Pin: Pin U26-11
Add Nets				
Add Nets		To	PCBROUTAGE.PcbDoc	
Add Comp	anant Class Mambars			
Add Comp	onent Class Members EA1 to Encodeurs	In	PCBROUTAGE.PcbDoc	Failed to add class member : Co
Add	EB1 to Encodeurs	In	PCBROUTAGE.PcbDoc	Failed to add class member : Co
Add	EC1 to Encodeurs	ln	PCBROUTAGE.PcbDoc	Failed to add class member : Co
Add	ED1 to Encodeurs	In	PCBROUTAGE.PcbDoc	Failed to add class member : Co
Add	U4 to Filtres	In	PCBROUTAGE.PcbDoc	Failed to add class member : Co
Add	U5 to Filtres	In	PCBROUTAGE.PcbDoc	Failed to add class member : Co
Add	U6 to Filtres	In	PCBROUTAGE.PcbDoc	Failed to add class member : Co
Add	U7 to Filtres	In	PCBROUTAGE.PcbDoc	Failed to add class member : Co
Add	U12 to Filtres	In	PCBROUTAGE.PcbDoc	Failed to add class member : Co
Add	U17 to Filtres	In	PCBROUTAGE.PcbDoc	Failed to add class member : Co
Add	U24 to Multiplexeur	In	PCBROUTAGE.PcbDoc	Failed to add class member : Co
Add	U25 to Multiplexeur	In	PCBROUTAGE.PcbDoc	Failed to add class member : Co
Add	U26 to Multiplexeur	In	PCBROUTAGE.PcbDoc	Failed to add class member : Co