CORVALLE IMAGING SERVICES · FIELD SERVICE JOB AID

Energy Control and Interlock Checks

For CT and imaging equipment service. Use before opening any equipment cabinet.

Lockout/tagout: five steps, in order

1. **Notify**
   Tell the department manager and every operator that the system is going out of service, and why.
2. **Shut down**
   Use the normal shutdown at the console.
3. **Isolate**
   Open the system's own disconnect. Isolate the equipment you are servicing, not the whole room.
4. **Lock and tag**
   Apply your personal lock and a tag with your name, the date and the reason. One person, one lock.
5. **Verify zero energy**
   Test with your meter, including stored energy such as capacitors, then attempt a start. Only you can verify it.

Repeated shutdown: check in this order

1. **System log.** What failed, and in what sequence.
2. **Every E-stop button,** including those in the exam room.
3. **Key switch.**
4. **Contactors.**
5. **Fuses and power modules.** Replace a fuse only after you know why it failed.

Never

- ✕ Bypass or jumper an E-stop circuit, even temporarily.
- ✕ Treat a console shutdown as isolation.
- ✕ Ask someone else to confirm the power is off.
- ✕ Remove another person's lock or tag.

Stop and escalate when

- ! You are asked to skip or shorten a safety step.
- ! The service procedure for the part is not available.
- ! The same fault returns after a repair.
- ! A patient is on the table when the system fails.

Before returning to service

- ✓ Remove tools and close all covers.
- ✓ Remove your own lock and tag.
- ✓ Notify staff the system is restarting.
- ✓ Run the final check and a test scan.