

The hole in the end cap is slightly off-centre due to the dimensions of the motor. To ensure it is drilled in the correct place, first fasten the end cap to the coupling and take note which direction the end cap sits when fully secure. Mark out a vertical line to make it clear.