

Lock-in amplifier

Measuring input

Oscillator voltage out

V_{meas}

$V_0 \text{ rms}$

R_0

R_D

C_p

I_+

V_+

V_-

I_-

