

Remove and Install Charging Port - Stark VARG

Video link: <https://www.youtube.com/watch?v=2auwe312ncs>

Source video: Remove and Install Charging Port - Stark VARG by Stark Future Official

Applicable models: MX

Scope

This guide follows the same step-by-step workshop structure as the MX tutorials, but it is derived as a visual sequence from the official Stark Future ASMR video. Because the source video does not provide usable captions or narration, the procedure is documented through curated screenshots and concise action guidance.

Preparation

- Place the bike on a stable stand or work area before starting the procedure.
- Prepare the correct tools for the fasteners, clips, brackets, and components shown in the video.
- Keep removed hardware organized in sequence so reassembly follows the same order as the video.
- Have a torque wrench ready for any tightening steps that specify a torque value.

Removal Procedure

1. Prepare access to the Charging Port

Open the surrounding panel area so the Charging Port mounting points and wiring path are fully accessible.

Keep the removed fasteners organized in sequence so reassembly matches the video.



2. Remove the visible retaining hardware for the Charging Port

Remove the visible Charging Port fasteners and support the part so it does not hang on the wiring. Support the component as the last fastener is removed.



3. Release any bracket, clip, or coupling attached to the Charging Port

Free any bracket, clip, spacer, linkage, or connector that still ties the Charging Port to the bike. Note the orientation of these supporting pieces before setting them aside.



4. Remove the Charging Port from the bike

Remove the Charging Port from the bike once the connector, routing clips, and mounting hardware are free.

Inspect the removed part and the mounting points before reassembly.



Installation Procedure

5. Position the Charging Port for installation

Return the Charging Port to its mounting position and align the holes, tabs, or locating surfaces.

Hold the component in place until the first retaining hardware is started.



6. Reconnect or refit the support pieces for the Charging Port

Reinstall any bracket, clip, spacer, linkage, or coupling associated with the Charging Port.

Make sure each supporting piece is seated correctly before final tightening.



7. Install the retaining hardware for the Charging Port

Install the Charging Port mounting hardware by hand first and seat the part evenly against its bracket or panel.

Check that the component remains aligned while the hardware is brought fully home.

Tighten the charging port bolts to **5 Nm**.



Warning: Please take all the necessary precautionary measures to handle high voltage components.
High voltage components should only be handled by qualified personnel.

8. Verify the completed installation of the Charging Port

Inspect the final position of the Charging Port and confirm that all hardware, clips, and surrounding parts are back in place.

Check the component for correct fit and movement before returning the bike to service.



Torque Summary

Component	Torque
Tighten the charging port bolts	5 Nm

Verified torque items:

- Tighten the charging port bolts: **5 Nm** from the official Stark VARG owner manual torque table.

Critical Checks Before Riding

- Confirm the serviced component is fully seated and all fasteners are tightened in the correct order.
- Recheck all torque-critical hardware before riding.
- Make sure all routed cables, clips, brackets, and surrounding parts are returned to their original positions.
- Inspect the bike visually for any missing hardware before returning it to service.