#### **ASSEMBLY MANUAL**





#### **BILL OF MATERIALS**

- R1 1k Ohm Resistor (4)
  BROWN BLACK RED GOLD
  - 5 Luer Lock Nut
- R4 4.7M Ohm Resistor
- SL Slide Switch
- R5 10k Ohm Resistor
- IC1 OP Amp
- 1 Tubing
- 1uF Capacitor (label: 105)
- Q1 MOSFET (4)
- C2 10nF Capacitor (label: 103)
- 2 Battery Case Cover
- 47pF Capacitor (label: 471)
- B1 Battery Holder (2)
- 6 LED Spacer (4)
- 3 PCB
- \_
- T1 Transistor
  2-position Male
- BAT Battery (2)

  LED1 Red LED (2)
- Header

  Potentiometer (2)
- LED2 Green LED (2)
- 7 Case Bottom
- PS1 Pressure Sensor
- 8 M4 Screws (5)
- SW1 Mono Jack (2)

Luer Lock Fitting

9 Case Top


#### **BEFORE STARTING:**

- All components are inserted into the PCB from the side with the MMC logo except the battery holders.
- Insert components flush to the PCB except Q1, IC1, and T1.
- · Some components need to be inserted in a specific orientation.
- W9 = Hole to put component through
- $\mathcal{L}$  = Solder the area in the white square.

#### TOOLS

- · Soldering iron
- Solder
- Flush cutters
- Wire stripper
- wife stripper
- Needle nose pliers
- · Phillips screwdriver
- Clamp


- Magnifier
- · Desoldering pump
- Plate
- Tape







### **ASSEMBLY MANUAL**









**04.** Bend all leads so components stay in place.








06 Snip off all excess leads flush to the PCB.











08.








10.

### **ASSEMBLY MANUAL**









11.

**12.** 






13.


C1 C1

R

14.









**15.** 

C3 C3

16.






18.


#### **ASSEMBLY MANUAL**













Solder only 1 lead and check if the component 20. is flush to board. Adjust as necessary.






21.




**22. IMPORTANT:** Insert and orient the OP Amp with dot towards the PCB dot.






MOSFETs will slightly above the PCB.





24.





25.



26.

T1 T1

### **ASSEMBLY MANUAL**






27.




28.

R




29. Add solder to the bottom left pad.




30. Add solder to the bottom left lead.






31.




**32.** Put the iron tip on the lead and the sensor should "drop." Adjust as necessary.





33.




Insert the LED into the spacer with the shorter lead towards the flat side.



### **ASSEMBLY MANUAL**






35.



36. Insert the red LED in LED2
& LED3. Insert the green
LED in LED1 & LED4.





37. Solder only 1 lead on each LED and check if it's flush to the board. Adjust as necessary.




38.

R






39.




40.





41.







42. Optional: use tape to keep the slide switch in place.

#### **ASSEMBLY MANUAL**





Solder only 1 lead on each component and check Solder only 1 lead on each company if they're flush to the board. Adjust as necessary.




44.





**45.** 




46.











Solder only 1 lead on each component and check Solder only I lead on each components if they're flush to the board. Adjust as necessary.




48.









49.










### **ASSEMBLY MANUAL**





**57.** 

Clear any 3D printed material from the screw holes.

### **ASSEMBLY MANUAL**



