



Ilustracja 1: P=1000




Ilustracja 2: P= 2000




Ilustracja 3: P=3000



Ilustracja 4: P=4000




Ilustracja 5: P=5000




Ilustracja 6: P=6000




Ilustracja 7: P=7000



Ilustracja 8: P=8000




Ilustracja 9: P=9000




Ilustracja 10: P=10000

Tabela maksymalnych wartości naprężeń:

	-	-	_	-						
Р	1000	2000	3000	4000	5000	6000	7000	8000	9000	10000
max	5,624	6,56	7,497	8,433	9,369	10,31	11,24	12,18	13,11	14,05




Ilustracja 11: P=1000



Ilustracja 12: P=3000



Ilustracja 13: P=5000



Ilustracja 14: P=7000



Ilustracja 15: P=9000

Tabela maksymalnych wartości naprężeń:

Р	1000	3000	5000	7000	9000
max	20,08	26,77	33,46	40,14	46,83