

SOP-HW-04 Hot Work Permit Procedure

Revision 5. Effective 01 March 2026. Harbourline Marine Services yard procedures.

1. Purpose. This procedure defines the controls required before, during and after hot work (welding, cutting,
2. Obtain a Hot Work Permit signed by the Permit Issuer and the Area Authority before any hot work starts. A p
3. Remove all flammable and combustible materials within 11 m (35 ft) of the hot work. Where removal is not
4. Post a trained fire watch with a charged extinguisher for the full duration of hot work. The fire watch sha
5. Test the atmosphere for flammable gas before work starts in enclosed or confined spaces and at intervals no
6. Close the permit. On completion the Area Authority inspects the location and closes the permit. Hot surface

Definitions

Fire watch: Trained person who watches for fire during and after hot work.

Flash point: Lowest temperature at which a liquid gives off enough vapour to ignite.

Area Authority: Person responsible for the work area who inspects and closes the permit.

Permit Issuer: Supervisor authorised to issue a hot work permit.

Personal protective equipment: welding helmet or face shield, fire-resistant coveralls, gloves, safety boots.