
Aergo
Setup
(6)
New
Save
Load
Cut
Copy
Paste
Start
Simulate
(5)
Stop
Pause
Resume
PROGRAM
(2)
MOVE_J
WELD
MOVE_J
AVAILABLE
(1)
MOVE_J
PICK
WELD
AUTOMATIC PARAMETERS
(3)
Scene Scan
Value 1
Welding Trajectory
Value 1
Move To Position
Set Position
Reload Visualization
Scan Scene
ADVANCED
(4)
Confirm