

Recommended Helium Fill Levels

General information		Information mainly concerning System Installation				Information mainly concerning CSEs	
System type (magnet type)	Alarm Level (also minimum He level to fill at field)	He Level for operation / hand-over	Recommended He Level for start up (before 1st ramp)	Minimum He level for ramping	He consumption for shimming/ ramping	Fill Bandwidth	
						Target Refill Point (warning level)	Top Fill Level
Aera (OR98)	35%	50%	60%	40%	10%	45%	65%
Avanto, Avanto fit (OR105)	40%	55%	65%	40%	10%	50%	70%
Esprea (OR122)	40%	55%	65%	40%	10%	50%	70%
Essenza (AX60)	40%	55%	65%	40%	10%	50%	70%
Verio, Skyra fit, mMR (OR97)	50%	65%	80%	60%	15%	60%	80%
Skyra (OR99)	35%	60%	70%	60%	10%	45%	70%
Skyra/ Spectra (OR 103)	35%	50%	65%	40%	15%	45%	65%
Prisma (OR65)	40%	60%	90%	60%	30%	50%	70%

Changes are marked in Orange