

RFA Loopback Setup for MR750w (3.0T) – Exciter

Landmark:

One foot from head end of empty table.

Note:

If monitoring Ch1, use cable going to J14.

If monitoring Ch2, use cable going to J21.

