

Treadmill (Rinberg's lab)


Last update: Mihaly Voroslakos (2025. August 29.)

BOM (Bill of Materials)

https://github.com/misiVoroslakos/3D printed designs/blob/main/Treadmill Rinberg/BOM T readmill Rinberg v02 encoder.txt


Detailed explanations of the process


Tapping



- 1. Tap 1/4" (1/4-20) holes on both sides of the Treadmill.
- 2. Tap 4-40 holes for the encoder.









1. Make sure to adjust the hole so the ball bearing fits tightly.



Insert ball bearing adapter





- 1. Make sure to adjust the outer diameter of the adapters so it fits inside the ball bearing tightly.
- 2. Make sure to adjust the 'x hole' of the adapter so the Lego axis can fit tightly.



