EE-222: Microprocessor Systems

AVR Microcontroller:
Jump (aka Branch)

Instructor: Dr. Arbab Latif

NUST

SCHOOL OF ELECTRICAL ENGINEERING &
COMPUTER SCIENCE (SEECS)

Jump and Call

- CPU executes instructions one after another.
  - For example in the following C program, CPU first executes the instruction of line 3 (adds b and c), then executes the instruction of line 4.



Jump and Call (Continued)

- But sometimes we need the CPU to execute, an instruction other than the next instruction.
  - For example:
    - When we use a conditional instruction (if)
    - When we make a loop
    - When we call a function

Jump and Call (Continued)

- Example 1: Not executing the next instruction, because of condition.
  - In the following example, the instruction of line 6 is not executed.

```
1   void main ()
2   {
3       int a = 2;
4       int c = 3;
5       if (a == 8)
6           c = 6;
7       else
8           c = 7;
9       c = a + 3;
    }
```

Jump and Call (Continued)

- Example 2: In this example the next instruction will not be executed because of loop.
  - In the following example, the order of execution is as follows:
    - Line 4
    - Line 5
    - Again, line 4
    - Again line 5
    - Line 6



Jump and Call (Continued)

- Example 3: Not executing the next instruction, because of calling a function.
  - In the following example, the instruction of line 6 is not executed after line 5.

	Code
1	`void func1 ();`
2	`void main ()`
3	`{`
4	`int a = 2, c = 3;`
5	`func1 ();`
6	`c = a + 3;`
7	`}`
8	`void func1 (){`
9	`int d = 5 / 2;`
10	`}`
11	

Jump and Call (Continued)

- In the assembly language, there are 2 groups of instructions that make the CPU execute an instruction other than the next instruction.
  - These instructions are:
    - Jump: used for making loop and condition
    - Call: used for making function calls

Jump

- Jump changes the Program Counter (PC) and causes the CPU to execute an instruction other than the next instruction.

Jump

There are 2 kinds of Jump:

- Unconditional Jump:
  - When CPU executes an unconditional jump, it jumps unconditionally (without checking any condition) to the target location.
    - Example: RJMP and JMP instructions

- Conditional Jump:
  - When CPU executes a conditional jump, it checks a condition, if the condition is true then it jumps to the target location; otherwise, it executes the next instruction.

Unconditional Jump

Unconditional Jump in AVR

- There are 3 unconditional jump instructions in AVR: **RJMP**, **JMP**, and **IJMP**
- We label the location where we want to jump, using a unique name, followed by ':'
- Then, in front of the jump instruction we mention the name of the label.
- This causes the CPU to jump to the location we have labeled, instead of executing the next instruction.



Ways of specifying the Jump Target

- There are 3 ways to provide the jump address:
  - PC = operand
  - PC = PC + operand
  - PC = Z register

JMP

- JMP ⟺ PC = operand
  - Long Jump
  - 4-byte instruction
    - 10-bits for the opcode and rest 22-bit for the target address
    - 22-bit = 4M memory locations



$0 \le k < 4M$



JMP

- JMP ⟺ PC = operand

  - Example:

    - Operand = **00000000000000000110**

JMP

- In JMP, the operand, contains the address of the destination
- When an JMP is executed:
  - PC is loaded with the operand value



15

RJMP (Relative Jump)

- RJMP:
  - 2-byte instruction
  - Lower 12-bits for the relative address of the target
    - Range divided into forward and backward jumps.



RJMP (Relative jump)

- RJMP ⟺ PC = PC + operand

1100	xxxx xxxx xxxx

- Example: | 1100 0000 | 0000 0110 |
  - Operand = **000000000110**
  - **PC = PC + 000000000110**

RJMP

- When RJMP is executed:
  - The operand will be added to the current value of PC



IJMP (Indirect Jump)

- IJMP: ⟺ PC = Z register
  - 2-byte instruction
  - PC is loaded with the contents of Z-register
    - So jumps to the address pointed to by the Z-register
      - For example, if Z points to location 100, by executing IJMP, the CPU jumps to location 100
    - The instruction has no operand



Conditional Jump

Conditional Jump in AVR

SREG:	I	T	H	S	V	N	Z	C

- The conditional jump instructions in AVR are as follows:

Instruction	Abbreviation of	Comment
BREQ *lbl*	Branch if Equal	Jump to location *lbl* if Z = 1,
BRNE *lbl*	Branch if Not Equal	Jump if Z = 0, to location *lbl*
BRCS *lbl* BRLO *lbl*	Branch if Carry Set Branch if Lower	Jump to location *lbl*, if C = 1
BRCC *lbl* BRSH *lbl*	Branch if Carry Cleared Branch if Same or Higher	Jump to location *lbl*, if C = 0
BRMI *lbl*	Branch if Minus	Jump to location lbl, if N = 1
BRPL *lbl*	Branch if Plus	Jump if N = 0
BRGE *lbl*	Branch if Greater or Equal	Jump if S = 0
BRLT*lbl*	Branch if Less Than	Jump if S = 1
BRHS *lbl*	Branch if Half Carry Set	If H = 1 then jump to *lbl*
BRHC lbl	Branch if Half Carry Cleared	if H = 0 then jump to lbl
BRTS	Branch if T flag Set	If T = 1 then jump to lbl
BRTC	Branch if T flag Cleared	If T = 0 then jump to lbl
BRIS	Branch if I flag set	If I = 1 then jump to lbl
BRIC	Branch if I flag cleared	If I = 0 then jump to lbl

21

Usages of Conditional jump

- Conditions and
- Loop

Looping Instructions

Looping: Using BRNE

- BRNE [BRnach if Not Equal]:
  - uses the *ZERO* flag [Z=0]

```
LDI R16, 0
LDI R17, 3
LDI R18, 5 ; counter
AGAIN: ADD R16, R17
       DEC R18
       BRNE AGAIN
```

Looping: Example

- Write a program to:
  a. Clear R20
  b. Add 3 to R20 ten times
  c. And the send the sum to PORTB



Looping: Example



	INSTRUCTIONS
	LDI R16, 10
	LDI R20, 0
	LDI R21, 3
AGAIN:	ADD R20, R21
	DEC R16
	BRNE AGAIN
	OUT PORTB, R20

Looping: Example Overall

- Write a program to:
  a. Clear R20
  b. Add 3 to R20 ten times
  c. And the send the sum to PORTB

```
        LDI   R16, 10       ;R16 = 10 (decimal) for counter
        LDI   R20, 0        ;R20 = 0
        LDI   R21, 3        ;R21 = 3
AGAIN:ADD   R20, R21        ;add 03 to R20 (R20 = sum)
        DEC   R16           ;decrement R16 (counter)
        BRNE  AGAIN         ;repeat until COUNT = 0
        OUT   PORTB,R20     ;send sum to PORTB
```

Reading

- The AVR Microcontroller and Embedded Systems: Using Assembly and C by Mazidi et al., Prentice Hall
  - Chapter-3: 3.1

THANK YOU