

# Packing list in the box








OMG V2-S C Copper wire feed gear


OMG V2-S S

Steel wire feed gear

## Installation instructions









## Installation instructions














## **Gear Bite Position**











# Need to adjust the B plate: make the large and small gears bite to the correct position

B-plate screw positioning hole +0.3 tolerance Installing the large and small gears

Then tighten the M3 screws





## Connector installation



Tighten the screw of the pneumatic connector by hand OK Prohibit the use of tools

After installation, there is a 1mm gap distance is normal Do not use tools with strong torque-cause breakage









#### Adapter parts

https://diymaria.es.aliexpress.com/store/group/OMG-V2-S-extrusora/2092087\_516816446.html

























**Ender 3 5 Pro CR 10...** 




# Direct Extruder D2















## Direct extruder for E3D V6 D2






F4010-**L**.STL F4010-**R**.STL


Printable STL file download link https://github.com/my3dltd/OMG-V2-S




# Direct Extruder D3













# Far distance Filament Feeding





