AE 737 - MECHANICS OF DAMAGE TOLERANCE

LECTURE 16

Dr. Nicholas Smith

Last Updated: March 24, 2016 at 12:57am

Wichita State University, Department of Aerospace Engineering

SCHEDULE

- · 24 Mar Stress based fatigue
- 29 Mar Influence of notches on fatigue, Homework 7 assigned, Homework 6 due
- · 31 Mar Strain based fatigue, project abstract due
- · 5 Apr Strain based fatigue, Homework 7 due

 \cdot The extra credit opportunity is still open

- · The extra credit opportunity is still open
- $\boldsymbol{\cdot}$ There has been some confusion about the Google Sheets page

- · The extra credit opportunity is still open
- There has been some confusion about the Google Sheets page
- The page numbers listed are already being worked on or have been completed

- The extra credit opportunity is still open
- There has been some confusion about the Google Sheets page
- The page numbers listed are already being worked on or have been completed
- If you want to digitize a plot, find a figure not listed on the Google Sheet and add it to the sheet

- The extra credit opportunity is still open
- · There has been some confusion about the Google Sheets page
- The page numbers listed are already being worked on or have been completed
- If you want to digitize a plot, find a figure not listed on the Google Sheet and add it to the sheet
- Once you have e-mailed me the data, I will put an "x" in the completed column and record your extra credit points

- The extra credit opportunity is still open
- · There has been some confusion about the Google Sheets page
- The page numbers listed are already being worked on or have been completed
- If you want to digitize a plot, find a figure not listed on the Google Sheet and add it to the sheet
- Once you have e-mailed me the data, I will put an "x" in the completed column and record your extra credit points
- For now I do not have a due date for this project, but I may eventually allow students who have already completed a chart to complete a second one

OUTLINE

- 1. fatigue review
- 2. modeling real loads
- 3. mean stress effects
- 4. scatter
- 5. general stress

FATIGUE REVIEW

STRESS BASED FATIGUE


 One of the simplest assumptions we can make is that a load cycles between a constant maximum and minimum stress value

STRESS BASED FATIGUE

- One of the simplest assumptions we can make is that a load cycles between a constant maximum and minimum stress value
- This is a good approximation for many cases (axles, for example) and can also be easily replicated experimentally

STRESS BASED FATIGUE

- One of the simplest assumptions we can make is that a load cycles between a constant maximum and minimum stress value
- This is a good approximation for many cases (axles, for example) and can also be easily replicated experimentally
- · This is referred to as constant amplitude stressing



- $\Delta\sigma$ is known as the stress range, and is the difference between max and min stress

- $\Delta \sigma$ is known as the stress range, and is the difference between max and min stress
- σ_m is the mean stress, and can sometimes be zero, but this is not always the case

- $\Delta \sigma$ is known as the stress range, and is the difference between max and min stress
- σ_m is the mean stress, and can sometimes be zero, but this is not always the case
- \cdot σ_a is the stress amplitude, and is the variation about the mean

- $\Delta \sigma$ is known as the stress range, and is the difference between max and min stress
- σ_m is the mean stress, and can sometimes be zero, but this is not always the case
- \cdot σ_a is the stress amplitude, and is the variation about the mean
- We can express all of these in terms of the maximum and minimum stress

$$\Delta \sigma = \sigma_{max} - \sigma_{min} \tag{16.1}$$

$$\sigma_m = \frac{\sigma_{max} + \sigma_{min}}{2} \tag{16.2}$$

$$\sigma_a = \frac{\sigma_{max} - \sigma_{min}}{2} \tag{16.3}$$

• It is important to distinguish between the nominal (global) stress and the local stress at some point of interest

- It is important to distinguish between the nominal (global) stress and the local stress at some point of interest
- We use σ for the stress at a point (local stress)

- It is important to distinguish between the nominal (global) stress and the local stress at some point of interest
- We use σ for the stress at a point (local stress)
- We use S as the nominal (global) stress

- It is important to distinguish between the nominal (global) stress and the local stress at some point of interest
- We use σ for the stress at a point (local stress)
- · We use S as the nominal (global) stress
- In simple tension, $\sigma = S$

- It is important to distinguish between the nominal (global) stress and the local stress at some point of interest
- We use σ for the stress at a point (local stress)
- We use S as the nominal (global) stress
- In simple tension, $\sigma = S$
- For many cases (bending, notches), $\sigma \neq S$ in general

- It is important to distinguish between the nominal (global) stress and the local stress at some point of interest
- We use σ for the stress at a point (local stress)
- We use S as the nominal (global) stress
- In simple tension, $\sigma = S$
- For many cases (bending, notches), $\sigma \neq S$ in general
- We must also be careful to note σ_y , in some cases $S<\sigma_y$ but at some locations $\sigma>\sigma_y$

SIMPLE TENSION




Figure 1: In this case $S=\sigma$




Figure 2: As long as $\sigma < \sigma_y$, σ varies linearly. If $\sigma > \sigma_y$ at any location, however, the relationship is non-linear




Figure 3: As long as $\sigma < \sigma_y$, σ varies linearly. If $\sigma > \sigma_y$ at any location, however, the relationship is non-linear

 \cdot The length of a fatigue test is determined by two factors

- The length of a fatigue test is determined by two factors
 - 1. How many cycles it takes for the specified load to cause failure


- The length of a fatigue test is determined by two factors
 - 1. How many cycles it takes for the specified load to cause failure
 - 2. The speed of the motor controlling the test

- The length of a fatigue test is determined by two factors
 - 1. How many cycles it takes for the specified load to cause failure
 - 2. The speed of the motor controlling the test
- Servohydraulic machines generally have a speed of 10 100 Hz.

- · The length of a fatigue test is determined by two factors
 - 1. How many cycles it takes for the specified load to cause failure
 - 2. The speed of the motor controlling the test
- · Servohydraulic machines generally have a speed of 10 100 Hz.
- At a speed of 100 Hz, it would take 28 hours for 10⁷ cycles, 12 days for 10⁸ cycles, and nearly 4 months for 10⁹ cycles

- · The length of a fatigue test is determined by two factors
 - 1. How many cycles it takes for the specified load to cause failure
 - 2. The speed of the motor controlling the test
- · Servohydraulic machines generally have a speed of 10 100 Hz.
- At a speed of 100 Hz, it would take 28 hours for 10⁷ cycles, 12 days for 10⁸ cycles, and nearly 4 months for 10⁹ cycles
- While some machines can test at very high speeds, the inertia of the sample can interfere with results

STRESS LIFE CURVES



STRESS LIFE CURVES

 On a linear scale, the data appear not to agree well with any standard fit


STRESS LIFE CURVES

- On a linear scale, the data appear not to agree well with any standard fit
- It is also very difficult to differentiate between low-cycle fatigue failure stresses

STRESS LIFE CURVES

- On a linear scale, the data appear not to agree well with any standard fit
- It is also very difficult to differentiate between low-cycle fatigue failure stresses
- Instead S-N curves are often plotted on a semi-log or log-log scale, so pay attention to the axes

STRESS LIFE CURVES



• If the curve is nearly linear on a log-linear plot, we use the following form to fit the data

• If the curve is nearly linear on a log-linear plot, we use the following form to fit the data

$$\sigma_a = C + D \log N_f \tag{16.4}$$

• If the curve is nearly linear on a log-linear plot, we use the following form to fit the data

$$\sigma_a = C + D \log N_f \tag{16.4}$$

 When the data are instead linear on a log-log scale, the following form is generally used

• If the curve is nearly linear on a log-linear plot, we use the following form to fit the data

$$\sigma_a = C + D \log N_f \tag{16.4}$$

 When the data are instead linear on a log-log scale, the following form is generally used

$$\sigma_a = \sigma_f' \left(2N_f \right)^b \tag{16.5}$$

 If the curve is nearly linear on a log-linear plot, we use the following form to fit the data


$$\sigma_a = C + D \log N_f \tag{16.4}$$

 When the data are instead linear on a log-log scale, the following form is generally used


$$\sigma_a = \sigma_f' \left(2N_f \right)^b \tag{16.5}$$

• σ_f' and b are often considered material properties and can often be looked up on a table (p. 235)

17



STRESS LIFE CURVES




 The fatigue limit, or endurance limit, is a feature of some materials where below a certain stress, no fatigue failure is observed

- The fatigue limit, or endurance limit, is a feature of some materials where below a certain stress, no fatigue failure is observed
- Below the fatigue limit, this material is considered to have infinite life

- The fatigue limit, or endurance limit, is a feature of some materials where below a certain stress, no fatigue failure is observed
- Below the fatigue limit, this material is considered to have infinite life
- This most notably occurs in plain-carbon and low-alloy steels

- The fatigue limit, or endurance limit, is a feature of some materials where below a certain stress, no fatigue failure is observed
- Below the fatigue limit, this material is considered to have infinite life
- This most notably occurs in plain-carbon and low-alloy steels
- · In these materials, σ_e is considered to be a material property

- The fatigue limit, or endurance limit, is a feature of some materials where below a certain stress, no fatigue failure is observed
- Below the fatigue limit, this material is considered to have infinite life
- This most notably occurs in plain-carbon and low-alloy steels
- \cdot In these materials, σ_e is considered to be a material property
- This phenomenon is not typical of aluminum or copper alloys, but is sometimes arbitrarily assigned using whatever the failure stress is at some large number of cycles (10⁷ or 10⁸)



 Some other important terms are high cycle fatigue and low cycle fatigue

- Some other important terms are high cycle fatigue and low cycle fatigue
- "High cycle fatigue" generally is considered anything above 10³ cycles, but varies somewhat by material

- Some other important terms are high cycle fatigue and low cycle fatigue
- "High cycle fatigue" generally is considered anything above 10³ cycles, but varies somewhat by material
- High cycle fatigue occurs when the stress is sufficiently low that yielding effects do not dominate behavior

- Some other important terms are high cycle fatigue and low cycle fatigue
- "High cycle fatigue" generally is considered anything above 10³ cycles, but varies somewhat by material
- High cycle fatigue occurs when the stress is sufficiently low that yielding effects do not dominate behavior
- When yielding effects do dominate behavior, the strain-based approach is more appropriate


MODELING REAL LOADS


• Static loads are constant and do not vary. While they are not generally considered "fatigue" loads, they can be present during fatigue loads, which will change the response.

- Static loads are constant and do not vary. While they are not generally considered "fatigue" loads, they can be present during fatigue loads, which will change the response.
- Working loads change with time as a function of the normal operation of a component

- Static loads are constant and do not vary. While they are not generally considered "fatigue" loads, they can be present during fatigue loads, which will change the response.
- Working loads change with time as a function of the normal operation of a component
- Vibratory loads occur at a higher frequency than working loads and may be caused by the environment or secondary effects of normal operation.

- Static loads are constant and do not vary. While they are not generally considered "fatigue" loads, they can be present during fatigue loads, which will change the response.
- Working loads change with time as a function of the normal operation of a component
- Vibratory loads occur at a higher frequency than working loads and may be caused by the environment or secondary effects of normal operation.
- Accidental loads can occur at a much lower frequency than working loads





SIMPLIFIED LOAD

sketch book p 239

• We know that variable loads can often occur in real scenarios, but how can we model the effect?

- We know that variable loads can often occur in real scenarios, but how can we model the effect?
- Miner's Rule is often used to approximate the effect of variable amplitude load

- We know that variable loads can often occur in real scenarios, but how can we model the effect?
- Miner's Rule is often used to approximate the effect of variable amplitude load
- We consider each load amplitude (and the number of cycles at that amplitude) as having used up a percentage of a part's life

- We know that variable loads can often occur in real scenarios, but how can we model the effect?
- Miner's Rule is often used to approximate the effect of variable amplitude load
- We consider each load amplitude (and the number of cycles at that amplitude) as having used up a percentage of a part's life

$$\frac{N_1}{N_{f1}} + \frac{N_2}{N_{f2}} + \frac{N_3}{N_{f3}} + \dots = \sum \frac{N_i}{N_{fi}} = 1$$
 (16.6)

 Often there are "blocks" of variable amplitude loads which repeat

- Often there are "blocks" of variable amplitude loads which repeat
- · A typical flight cycle is a good example of this

- Often there are "blocks" of variable amplitude loads which repeat
- · A typical flight cycle is a good example of this
- A flight will have working loads, vibrations, as well as storms/turbulence, but each flight should have similar loading

- Often there are "blocks" of variable amplitude loads which repeat
- · A typical flight cycle is a good example of this
- A flight will have working loads, vibrations, as well as storms/turbulence, but each flight should have similar loading
- If we call the number of "block" B then we have

- Often there are "blocks" of variable amplitude loads which repeat
- · A typical flight cycle is a good example of this
- A flight will have working loads, vibrations, as well as storms/turbulence, but each flight should have similar loading
- · If we call the number of "block" B then we have

$$B\left[\sum \frac{N_i}{N_{if}}\right]_{rep} = 1 \tag{16.7}$$

VARIABLE AMPLITUDE LOAD EXAMPLE

 It is possible for each variable load case to have a different mean stress

- It is possible for each variable load case to have a different mean stress
- This would mean generating a different S-N curve for each potential mean stress

- It is possible for each variable load case to have a different mean stress
- This would mean generating a different S-N curve for each potential mean stress
- Much work has been done to instead convert a zero-mean stress curve to different mean stress amplitudes


 Since mean stress has an effect on fatigue life, sometimes a family of S-N curves at varying mean stress values is created

- Since mean stress has an effect on fatigue life, sometimes a family of S-N curves at varying mean stress values is created
- S-N curves for these are reported in different ways, but commonly σ_{max} replaces σ_a on the y-axis


- Since mean stress has an effect on fatigue life, sometimes a family of S-N curves at varying mean stress values is created
- S-N curves for these are reported in different ways, but commonly σ_{max} replaces σ_a on the y-axis
- One useful way of representing these data, instead of many S-N curves, is a constant-life diagram

- Since mean stress has an effect on fatigue life, sometimes a family of S-N curves at varying mean stress values is created
- S-N curves for these are reported in different ways, but commonly σ_{max} replaces σ_a on the y-axis
- One useful way of representing these data, instead of many S-N curves, is a constant-life diagram
- It is created by taking points from the S-N curves and plotting a line through constant N_f values

S-N CURVES AT VARIABLE σ_m



CONSTANT LIFE DIAGRAM



NORMALIZING

 One very useful way to plot this data is to normalize the amplitude by the zero-mean amplitude


NORMALIZING

- One very useful way to plot this data is to normalize the amplitude by the zero-mean amplitude
- \cdot We call the zero-mean amplitude as σ_{ar}

NORMALIZING

- One very useful way to plot this data is to normalize the amplitude by the zero-mean amplitude
- \cdot We call the zero-mean amplitude as σ_{ar}
- Plotting σ_a/σ_{ar} vs. σ_m provides a good way to group all the data together on one plot with the potential to fit a curve

NORMALIZED AMPLITUDE-MEAN DIAGRAM



 The first work on this problem was done by Goodman, who proposed the line

 The first work on this problem was done by Goodman, who proposed the line

$$\frac{\sigma_a}{\sigma_{ar}} + \frac{\sigma_m}{\sigma_u} = 1 \tag{16.8}$$

 The first work on this problem was done by Goodman, who proposed the line

$$\frac{\sigma_a}{\sigma_{ar}} + \frac{\sigma_m}{\sigma_u} = 1 \tag{16.8}$$

 This equation can also be used for fatigue limits, since they are just a point on the S-N curves

 The first work on this problem was done by Goodman, who proposed the line

$$\frac{\sigma_a}{\sigma_{ar}} + \frac{\sigma_m}{\sigma_u} = 1 \tag{16.8}$$

 This equation can also be used for fatigue limits, since they are just a point on the S-N curves

$$\frac{\sigma_e}{\sigma_{er}} + \frac{\sigma_m}{\sigma_u} = 1 \tag{16.9}$$

 While the Goodman line gives a good approximation to convert non-zero mean stress S-N curves, it is somewhat overly conservative at high mean stresses

- While the Goodman line gives a good approximation to convert non-zero mean stress S-N curves, it is somewhat overly conservative at high mean stresses
- It is also non-conservative for negative mean stresses

- While the Goodman line gives a good approximation to convert non-zero mean stress S-N curves, it is somewhat overly conservative at high mean stresses
- It is also non-conservative for negative mean stresses
- · An alternative fit is known as the Gerber Parabola

- While the Goodman line gives a good approximation to convert non-zero mean stress S-N curves, it is somewhat overly conservative at high mean stresses
- It is also non-conservative for negative mean stresses
- · An alternative fit is known as the Gerber Parabola

$$\frac{\sigma_a}{\sigma_{ar}} + \left(\frac{\sigma_m}{\sigma_u}\right)^2 = 1 \tag{16.10}$$

- While the Goodman line gives a good approximation to convert non-zero mean stress S-N curves, it is somewhat overly conservative at high mean stresses
- It is also non-conservative for negative mean stresses
- · An alternative fit is known as the Gerber Parabola

$$\frac{\sigma_a}{\sigma_{ar}} + \left(\frac{\sigma_m}{\sigma_u}\right)^2 = 1 \tag{16.10}$$

 In general, the Goodman line is a good fit for brittle materials (steels) while the Gerber parabola is a better fit for more ductile materials

• The Goodman line can also be improved by replacing σ_u with the corrected true fracture strength $\tilde{\sigma}_{fB}$ or the constant σ_f' from the S-N curve fit

• The Goodman line can also be improved by replacing σ_u with the corrected true fracture strength $\tilde{\sigma}_{fB}$ or the constant σ_f' from the S-N curve fit

$$\frac{\sigma_a}{\sigma_{ar}} + \frac{\sigma_m}{\sigma_f'} = 1 \tag{16.11}$$

• The Goodman line can also be improved by replacing σ_u with the corrected true fracture strength $\tilde{\sigma}_{fB}$ or the constant σ_f' from the S-N curve fit

$$\frac{\sigma_a}{\sigma_{ar}} + \frac{\sigma_m}{\sigma_f'} = 1 \tag{16.11}$$

This is known as the Morrow Equation

• The Goodman line can also be improved by replacing σ_u with the corrected true fracture strength $\tilde{\sigma}_{fB}$ or the constant σ_f' from the S-N curve fit

$$\frac{\sigma_a}{\sigma_{ar}} + \frac{\sigma_m}{\sigma_f'} = 1 \tag{16.11}$$

- This is known as the Morrow Equation
- For steels, $\sigma_f' \approx \tilde{\sigma}_{fB}$, but for aluminums these values can be significantly different, and better agreement is found using $\tilde{\sigma}_{fB}$.

 One more relationship that has shown particularly good results with aluminum alloys is the Smith, Watson, and Topper equations (SWT)

 One more relationship that has shown particularly good results with aluminum alloys is the Smith, Watson, and Topper equations (SWT)

$$\sigma_{ar} = \sqrt{\sigma_{max}\sigma_a} \tag{16.12}$$

 One more relationship that has shown particularly good results with aluminum alloys is the Smith, Watson, and Topper equations (SWT)

$$\sigma_{ar} = \sqrt{\sigma_{max}\sigma_a} \tag{16.12}$$

· In general, it is best to use a form that matches your data

 One more relationship that has shown particularly good results with aluminum alloys is the Smith, Watson, and Topper equations (SWT)

$$\sigma_{ar} = \sqrt{\sigma_{max}\sigma_a} \tag{16.12}$$

- · In general, it is best to use a form that matches your data
- If data is lacking, the SWT (16.12) and Morrow (16.11) equations generally provide the best fit

VARIABLE AMPLITUDE LOAD WITH MEAN STRESS



FATIGUE SCATTER

• One of the challenges with fatigue is that there is generally considerable scatter in the data


FATIGUE SCATTER


- One of the challenges with fatigue is that there is generally considerable scatter in the data
- Quantifying this scatter requires many repetitions, which makes for time consuming tests

FATIGUE SCATTER

- One of the challenges with fatigue is that there is generally considerable scatter in the data
- Quantifying this scatter requires many repetitions, which makes for time consuming tests
- In general, the scatter follows a lognormal distribution (or a normal distribution in $log(N_f)$)

S-N-P CURVE





 Often combined loads from different sources introduce stresses which are not uni-axial

- Often combined loads from different sources introduce stresses which are not uni-axial
- For ductile materials, good agreement has been found using an effective stress amplitude, similar to the octahedral shear yield criterion

- Often combined loads from different sources introduce stresses which are not uni-axial
- For ductile materials, good agreement has been found using an effective stress amplitude, similar to the octahedral shear yield criterion

$$\bar{\sigma}_a = \frac{1}{\sqrt{2}} \sqrt{(\sigma_{xa} - \sigma_{ya})^2 + (\sigma_{ya} - \sigma_{za})^2 + (\sigma_{za} - \sigma_{xa})^2 + 6(\tau_{xy}^2 + \tau_{yz}^2 + \tau_{zx}^2)}$$
(16.13)

- Often combined loads from different sources introduce stresses which are not uni-axial
- For ductile materials, good agreement has been found using an effective stress amplitude, similar to the octahedral shear yield criterion

$$\bar{\sigma}_a = \frac{1}{\sqrt{2}} \sqrt{(\sigma_{xa} - \sigma_{ya})^2 + (\sigma_{ya} - \sigma_{za})^2 + (\sigma_{za} - \sigma_{xa})^2 + 6(\tau_{xy}^2 + \tau_{yz}^2 + \tau_{zx}^2)}$$
(16.13)

The effective mean stress is given by

- Often combined loads from different sources introduce stresses which are not uni-axial
- For ductile materials, good agreement has been found using an effective stress amplitude, similar to the octahedral shear yield criterion

$$\bar{\sigma}_a = \frac{1}{\sqrt{2}} \sqrt{(\sigma_{xa} - \sigma_{ya})^2 + (\sigma_{ya} - \sigma_{za})^2 + (\sigma_{za} - \sigma_{xa})^2 + 6(\tau_{xy}^2 + \tau_{yz}^2 + \tau_{zx}^2)}$$
(16.13)

The effective mean stress is given by

$$\bar{\sigma}_m = \bar{\sigma}_{xm} + \bar{\sigma}_{ym} + \bar{\sigma}_{zm} \tag{16.14}$$

EFFECTIVE STRESS

• This effective stress can be used in all other relationships, including mean stress relationships

EFFECTIVE STRESS

- This effective stress can be used in all other relationships, including mean stress relationships
- Note that mean shear stress has no effect on the effective mean stress

EFFECTIVE STRESS

- This effective stress can be used in all other relationships, including mean stress relationships
- Note that mean shear stress has no effect on the effective mean stress
- · This is surprising, but agrees well with experiments