# AE 737 - MECHANICS OF DAMAGE TOLERANCE

# LECTURE 17

Dr. Nicholas Smith

Last Updated: March 31, 2016 at 3:52pm

Wichita State University, Department of Aerospace Engineering

#### SCHEDULE

- 29 Mar Influence of notches on fatigue, Homework 7 assigned, Homework 6 due
- · 31 Mar Strain based fatigue, project abstract due
- 5 Apr Crack Growth, Homework 7 due, Homework 8 assigned
- · 7 Apr Crack Growth

# **OUTLINE**

- 1. fatigue review
- 2. influence of notches
- 3. strain based fatigue

# FATIGUE REVIEW

- A part from AISI 4340 in a typical "block" undergoes 100,000 cycles with  $\sigma_{min}=0$  ksi and  $\sigma_{max}=100$  ksi and an additional 10 cycles with  $\sigma_{min}=50$  ksi and  $\sigma_{max}=200$  ksi
- · How many "blocks" can this part support before failure?

- Use the S-N-P chart on p. 245 for 7075-T6 Aluminum
- What is the probability of failure for 30 ksi at 10<sup>6</sup> cycles?
- To ensure that 99% of parts do not fail, after how many cycles should a fully reversed load of 35 ksi be inspected?
- How many cycles could the same part sustain if only 50% of parts are needed?

- The fatigue limit for AISI 4142 steel is 58 ksi for completely reversed fatigue loads.
- What is the fatigue limit for fatigue loads with  $\sigma_m = 10, 20, 30$  ksi?

- A material made of 2024-T4 Aluminum undergoes the following load cycle
  - $\sigma_{x,min} = 10$ ,  $\sigma_{x,max} = 50$
  - $\sigma_{y,min}=-20$ ,  $\sigma_{y,max}=20$
  - $\tau_{xy,min} = 0$ ,  $\tau_{xy,max} = 30$
- How many cycles can it support before failure?



• In this discussion, we use "notch" to refer to any geometric feature that increases the local stress (such as holes, fillets, grooves, etc.)

- In this discussion, we use "notch" to refer to any geometric feature that increases the local stress (such as holes, fillets, grooves, etc.)
- We discussed notches and stress concentration factors in terms of stress concentration factors

- In this discussion, we use "notch" to refer to any geometric feature that increases the local stress (such as holes, fillets, grooves, etc.)
- We discussed notches and stress concentration factors in terms of stress concentration factors
- In our fatigue notation,  $\sigma_{max} = K_t S$

- In this discussion, we use "notch" to refer to any geometric feature that increases the local stress (such as holes, fillets, grooves, etc.)
- We discussed notches and stress concentration factors in terms of stress concentration factors
- In our fatigue notation,  $\sigma_{max} = K_t S$
- This relates local stress to the average, nominal stress

- In this discussion, we use "notch" to refer to any geometric feature that increases the local stress (such as holes, fillets, grooves, etc.)
- We discussed notches and stress concentration factors in terms of stress concentration factors
- In our fatigue notation,  $\sigma_{max} = K_t S$
- This relates local stress to the average, nominal stress
- The stress intensity factor can be used to characterize the "strength" of a notch

• We might expect the fatigue life of a notched specimen to be similar to a pristine specimen with  $S_{a,pristine} = \sigma_{max,notched}$ 

- We might expect the fatigue life of a notched specimen to be similar to a pristine specimen with  $S_{a,pristine} = \sigma_{max,notched}$
- If we look at actual test data, however, this estimate would be overly conservative

- We might expect the fatigue life of a notched specimen to be similar to a pristine specimen with  $S_{a,pristine} = \sigma_{max,notched}$
- If we look at actual test data, however, this estimate would be overly conservative
- Even when the stress is adjusted for some fatigue notch factor,  $k_f$ , it is only valid at longer cycles ( $N_f > 10^6$ )

- We might expect the fatigue life of a notched specimen to be similar to a pristine specimen with  $S_{a,pristine} = \sigma_{max,notched}$
- If we look at actual test data, however, this estimate would be overly conservative
- Even when the stress is adjusted for some fatigue notch factor,  $k_f$ , it is only valid at longer cycles ( $N_f > 10^6$ )

$$k_f = \frac{\sigma_{ar}}{S_{ar}} \tag{17.1}$$

- We might expect the fatigue life of a notched specimen to be similar to a pristine specimen with  $S_{a,pristine} = \sigma_{max,notched}$
- If we look at actual test data, however, this estimate would be overly conservative
- Even when the stress is adjusted for some fatigue notch factor,  $k_f$ , it is only valid at longer cycles ( $N_f > 10^6$ )


$$k_f = \frac{\sigma_{ar}}{S_{ar}} \tag{17.1}$$

 Notches will have different effects, largely depending on their radius.

- We might expect the fatigue life of a notched specimen to be similar to a pristine specimen with  $S_{a,pristine} = \sigma_{max,notched}$
- If we look at actual test data, however, this estimate would be overly conservative
- Even when the stress is adjusted for some fatigue notch factor,  $k_f$ , it is only valid at longer cycles ( $N_f > 10^6$ )

$$k_f = \frac{\sigma_{ar}}{S_{ar}} \tag{17.1}$$

- Notches will have different effects, largely depending on their radius.
- The maximum possible fatigue notch factor is  $k_f = k_t$



 To avoid generating fatigue data for every possible notch configuration, some empirical relationships have been developed

- To avoid generating fatigue data for every possible notch configuration, some empirical relationships have been developed
- $\cdot$  A useful concept in these methods is the notch sensitivity factor

- To avoid generating fatigue data for every possible notch configuration, some empirical relationships have been developed
- · A useful concept in these methods is the notch sensitivity factor

$$q = \frac{k_f - 1}{k_t - 1} \tag{17.2}$$

- To avoid generating fatigue data for every possible notch configuration, some empirical relationships have been developed
- · A useful concept in these methods is the notch sensitivity factor

$$q = \frac{k_f - 1}{k_t - 1} \tag{17.2}$$

• When  $k_f = 1$ , q = 0, in which case the notch has no effect

- To avoid generating fatigue data for every possible notch configuration, some empirical relationships have been developed
- · A useful concept in these methods is the notch sensitivity factor

$$q = \frac{k_f - 1}{k_t - 1} \tag{17.2}$$

- When  $k_f = 1$ , q = 0, in which case the notch has no effect
- When  $k_f = k_t$ , q = 1, in which case the notch has its maximum effect

· Peterson developed the following relationship

· Peterson developed the following relationship

$$q = \frac{1}{1 + \frac{\alpha}{\rho}} \tag{17.3}$$

· Peterson developed the following relationship

$$q = \frac{1}{1 + \frac{\alpha}{\rho}} \tag{17.3}$$

 $\cdot$  Where ho is the radius of the notch

· Peterson developed the following relationship

$$q = \frac{1}{1 + \frac{\alpha}{a}} \tag{17.3}$$

- Where  $\rho$  is the radius of the notch
- $\alpha$  is a material property

Peterson developed the following relationship

$$q = \frac{1}{1 + \frac{\alpha}{\rho}} \tag{17.3}$$

- Where  $\rho$  is the radius of the notch
- $\alpha$  is a material property

**Table 1:** Table of  $\alpha$  values for Peterson notch sensitivity equation

Material	$\alpha$ (mm)	$\alpha$ (in)
Aluminum alloys	0.51	0.02
Annealed or low-carbon steels	0.25	0.01
Quenched and tempered steels	0.064	0.0025

• For high-strength steels, a more specific  $\alpha$  estimate can be found

$$\alpha = 0.025 \left(\frac{2070}{\sigma_u}\right)^{1.8}$$
 mm  $\sigma_u \ge 550$  MPa (17.4)

$$\alpha = 0.001 \left(\frac{300}{\sigma_u}\right)^{1.8} \qquad \text{in} \qquad \sigma_u \ge 80 \text{ ksi} \qquad (17.5)$$

 $\cdot$  For high-strength steels, a more specific lpha estimate can be found

$$\alpha = 0.025 \left(\frac{2070}{\sigma_u}\right)^{1.8}$$
 mm  $\sigma_u \ge 550 \text{ MPa}$  (17.4)

$$\alpha = 0.001 \left(\frac{300}{\sigma_u}\right)^{1.8} \qquad \text{in} \qquad \sigma_u \ge 80 \text{ ksi} \qquad (17.5)$$

 $\cdot$   $\alpha$  predictions are valid for bending and axial fatigue

 $\cdot$  For high-strength steels, a more specific lpha estimate can be found

$$\alpha = 0.025 \left(\frac{2070}{\sigma_u}\right)^{1.8}$$
 mm  $\sigma_u \ge 550 \text{ MPa}$  (17.4)

$$\alpha = 0.001 \left(\frac{300}{\sigma_u}\right)^{1.8} \qquad \text{in} \qquad \sigma_u \ge 80 \text{ ksi} \qquad (17.5)$$

- $\cdot$   $\, \alpha$  predictions are valid for bending and axial fatigue
- · For torsion fatigue, a good estimate can be found

 $\cdot$  For high-strength steels, a more specific lpha estimate can be found

$$\alpha = 0.025 \left(\frac{2070}{\sigma_u}\right)^{1.8}$$
 mm  $\sigma_u \ge 550$  MPa (17.4)

$$\alpha = 0.001 \left(\frac{300}{\sigma_u}\right)^{1.8} \qquad \text{in} \qquad \sigma_u \ge 80 \text{ ksi} \qquad (17.5)$$

- $\cdot$   $\, \alpha$  predictions are valid for bending and axial fatigue
- · For torsion fatigue, a good estimate can be found

$$\alpha_{torsion} = 0.6\alpha$$
 (17.6)

# ALTERNATIVE NOTCH SENSITIVITY FORMULATION

 $\cdot$  An alternative formulation for q was developed by Neuber

### ALTERNATIVE NOTCH SENSITIVITY FORMULATION

 $\cdot$  An alternative formulation for q was developed by Neuber

$$q = \frac{1}{1 + \sqrt{\frac{\beta}{\rho}}} \tag{17.7}$$

### ALTERNATIVE NOTCH SENSITIVITY FORMULATION

· An alternative formulation for q was developed by Neuber

$$q = \frac{1}{1 + \sqrt{\frac{\beta}{\rho}}} \tag{17.7}$$

• Where the material property  $\beta$  for steels is given by

$$\log \beta = -\frac{\sigma_u - 134}{586}$$
 mm  $\sigma_u \le 1520 \text{ MPa}$  (17.8)  
 $\log \beta = -\frac{\sigma_u + 100}{85}$  in  $\sigma_u \le 220 \text{ ksi}$  (17.9)

$$\log \beta = -\frac{\sigma_u + 100}{85} \qquad \text{in} \qquad \sigma_u \le 220 \text{ ksi} \qquad (17.9)$$

### ALTERNATIVE NOTCH SENSITIVITY FORMULATION

An alternative formulation for q was developed by Neuber

$$q = \frac{1}{1 + \sqrt{\frac{\beta}{\rho}}} \tag{17.7}$$

• Where the material property  $\beta$  for steels is given by

$$\log \beta = -\frac{\sigma_u - 134}{586} \qquad \text{mm} \qquad \sigma_u \le 1520 \text{ MPa} \qquad (17.8)$$

$$\log \beta = -\frac{\sigma_u + 100}{85} \qquad \text{in} \qquad \sigma_u \le 220 \text{ ksi} \qquad (17.9)$$

$$\log \beta = -\frac{\sigma_u + 100}{85} \qquad \text{in} \qquad \sigma_u \le 220 \text{ ksi} \qquad (17.9)$$

• For aluminum use the chart MPa (ksi) and mm (in.)  $S_{ij} \mid 150(22) \quad 300(43) \quad 600(87)$  $\beta$  | 2 (0.08) | 0.6 (0.025) | 0.5 (0.015)

 While the above methods are useful, they should be regarded as estimates only

- While the above methods are useful, they should be regarded as estimates only
- · Physical complexities are not fully modeled by these methods

- While the above methods are useful, they should be regarded as estimates only
- Physical complexities are not fully modeled by these methods
- · All of these have been developed for relatively "mild" notches

- While the above methods are useful, they should be regarded as estimates only
- Physical complexities are not fully modeled by these methods
- · All of these have been developed for relatively "mild" notches
- For sharp notches, best results are found by treating the notch as a crack

# **EXAMPLE**

 $\boldsymbol{\cdot}$  Find the notch sensitivity factor for the following scenario

$$ho=0.25$$
 in.  $\sigma_m=0$  ksi  $K_t=3.0$   $\sigma_u=84$  ksi



 The strain based fatigue method uses local stresses and strains (instead of global, nominal values)

- The strain based fatigue method uses local stresses and strains (instead of global, nominal values)
- The strain-based method gives greater detail, and validity at lower cycles

- The strain based fatigue method uses local stresses and strains (instead of global, nominal values)
- The strain-based method gives greater detail, and validity at lower cycles
- · It is still valid for high cycle fatigue

- The strain based fatigue method uses local stresses and strains (instead of global, nominal values)
- The strain-based method gives greater detail, and validity at lower cycles
- It is still valid for high cycle fatigue
- · Does not include crack growth analysis or fracture mechanics

 Similar to the S-N curves in stress-based fatigue analysis, we can plot the cyclic strain amplitude vs. number of cycles to failure

- Similar to the S-N curves in stress-based fatigue analysis, we can plot the cyclic strain amplitude vs. number of cycles to failure
- This is most commonly done using axial test machines (instead of rotating bending tests)

- Similar to the S-N curves in stress-based fatigue analysis, we can plot the cyclic strain amplitude vs. number of cycles to failure
- This is most commonly done using axial test machines (instead of rotating bending tests)
- The test is run in strain control (not load control)


- Similar to the S-N curves in stress-based fatigue analysis, we can plot the cyclic strain amplitude vs. number of cycles to failure
- This is most commonly done using axial test machines (instead of rotating bending tests)
- The test is run in strain control (not load control)
- · Generally plotted on log-log scale

 We can separate the total strain into elastic and plastic components


 We can separate the total strain into elastic and plastic components

$$\epsilon_a = \epsilon_{ea} + \epsilon_{pa} \tag{17.10}$$

# PLASTIC STRAIN



# **HYSTERESIS LOOPS**



### CYCLIC STRESS STRAIN CURVE

• While strain-life data will generally just report  $\epsilon_a$  and  $\epsilon_{pa}$ , some will also tabulate a form for the cyclic stress-strain curve

### CYCLIC STRESS STRAIN CURVE

• While strain-life data will generally just report  $\epsilon_a$  and  $\epsilon_{pa}$ , some will also tabulate a form for the cyclic stress-strain curve

$$\epsilon_a = \frac{\sigma_a}{E} + \left(\frac{\sigma_a}{H'}\right)^{\frac{1}{n'}} \tag{17.11}$$


 On strain life curves, the strain is often plotted three times per each experiment


- On strain life curves, the strain is often plotted three times per each experiment
- Once for total strain, once for plastic strain, and once for elastic strain

- On strain life curves, the strain is often plotted three times per each experiment
- Once for total strain, once for plastic strain, and once for elastic strain
- Since plastic strain and elastic strain vary by the number of cycles, a hysteresis loop from half the fatigue life is generally used

- On strain life curves, the strain is often plotted three times per each experiment
- Once for total strain, once for plastic strain, and once for elastic strain
- Since plastic strain and elastic strain vary by the number of cycles, a hysteresis loop from half the fatigue life is generally used
- · This is considered representative of stable behavior

# **EXPERIMENTAL DATA**





 We notice that the data for elastic and plastic strains are represented by straight lines, in the log-log scale

- We notice that the data for elastic and plastic strains are represented by straight lines, in the log-log scale
- If we recall the form used for a straight line in log-log plots for S-N curves:

- We notice that the data for elastic and plastic strains are represented by straight lines, in the log-log scale
- If we recall the form used for a straight line in log-log plots for S-N curves:

$$\sigma_a = \sigma_f'(2N_f)^b \tag{17.12}$$

- We notice that the data for elastic and plastic strains are represented by straight lines, in the log-log scale
- If we recall the form used for a straight line in log-log plots for S-N curves:

$$\sigma_a = \sigma_f'(2N_f)^b \tag{17.12}$$

· We can convert this to find the elastic component of strain

- We notice that the data for elastic and plastic strains are represented by straight lines, in the log-log scale
- If we recall the form used for a straight line in log-log plots for S-N curves:

$$\sigma_a = \sigma_f'(2N_f)^b \tag{17.12}$$

We can convert this to find the elastic component of strain

$$\epsilon_{ea} = \frac{\sigma_f'}{E} (2N_f)^b \tag{17.13}$$

• We can use the same form with new constants for the plastic component of strain

 We can use the same form with new constants for the plastic component of strain

$$\epsilon_{pa} = \epsilon_f'(2N_f)^c \tag{17.14}$$

 We can use the same form with new constants for the plastic component of strain

$$\epsilon_{pa} = \epsilon_f'(2N_f)^c \tag{17.14}$$

• We can combine 17.13 with 17.14 to find the total strain-life curve

 We can use the same form with new constants for the plastic component of strain

$$\epsilon_{pa} = \epsilon_f' (2N_f)^c \tag{17.14}$$

• We can combine 17.13 with 17.14 to find the total strain-life curve

$$\epsilon_a = \frac{\sigma_f'}{E} (2N_f)^b + \epsilon_f' (2N_f)^c \tag{17.15}$$

# **EXAMPLE**