AE 737: Mechanics of Damage Tolerance

Lecture 16 - Strain based fatigue

Dr. Nicholas Smith

Wichita State University, Department of Aerospace Engineering

29 March, 2021

1

schedule

- 29 Mar Strain-based Fatigue
- 31 Mar Crack Growth
- 2 Apr Homework 6 Due
- 5 Apr Boeing Method
- 7 Apr Cycle counting
- 9 Apr Homework 6 Self-grade, Homework 7 Due

outline

- strain based fatigue
- variable amplitude strains
- mean stress effects
- general trends
- notches
- multiaxial loading
- other factors affecting fatigue

strain based fatigue

3

strain based fatigue

- The strain based fatigue method uses local stresses and strains (instead of global, nominal values)
- The strain-based method gives greater detail, and validity at lower cycles
- It is still valid for high cycle fatigue (but gives same result as stress-based fatigue)
- Does not include crack growth analysis or fracture mechanics

4

strain life curve

- Similar to the S-N curves in stress-based fatigue analysis, we can plot the cyclic strain amplitude vs. number of cycles to failure
- This is most commonly done using axial test machines (instead of rotating bending tests)
- The test is run in strain control (not load control)
- Generally plotted on log-log scale


plastic and elastic strain

We can separate the total strain into elastic and plastic components


$$\epsilon_a = \epsilon_{ea} + \epsilon_{pa}$$

6

plastic strain



hysteresis loops



cyclic stress strain curve

• While strain-life data will generally just report ϵ_a and ϵ_{pa} some will also tabulate a form for the cyclic stress-strain curve

$$\epsilon_{\mathsf{a}} = \frac{\sigma_{\mathsf{a}}}{E} + \left(\frac{\sigma_{\mathsf{a}}}{H'}\right)^{\frac{1}{n'}}$$


8


plastic and elastic strain

- On strain life curves, the strain is often plotted three times per each experiment
- Once for total strain, once for plastic strain, and once for elastic strain
- Since plastic strain and elastic strain vary by the number of cycles, a hysteresis loop from half the fatigue life is generally used
- This is considered representative of stable behavior

10

experimental data





lines

- We notice that the data for elastic and plastic strains are represented by straight lines, in the log-log scale
- If we recall the form used for a straight line in log-log plots for S-N curves:

$$\sigma_a = \sigma_f'(2N_f)^b$$

• We can convert this to find the elastic component of strain

$$\epsilon_{ea} = \frac{\sigma_f'}{E} (2N_f)^b$$

 We can use the same form with new constants for the plastic component of strain

$$\epsilon_{pa} = \epsilon'_f (2N_f)^c$$

 We can combine the elastic and plastic portions to find the total strain-life curve

$$\epsilon_a = \frac{\sigma_f'}{E} (2N_f)^b + \epsilon_f' (2N_f)^c$$

14

example

ϵ_a	σ_a (MPa)	ϵ_{pa}	N_f
0.0202	631	0.01695	227
0.0100	574	0.00705	1030
0.0045	505	0.00193	6450
0.0030	472	0.00064	22250
0.0023	455	(0.00010)	110000

transition life

- With the strain-based fatigue method we are better equipped to discuss the difference between high and low-cycle fatigue
- Low-cycle fatigue is dominated by plastic effects, while high-cycle fatigue has little plasticity
- We can find the intersection of the plastic strain and elastic strain lines
- This point is Nt, the transition fatigue life

$$N_t = rac{1}{2} \left(rac{\sigma_f'}{\epsilon_f'}
ight)^{rac{1}{c-b}}$$

16

inconsistencies in constants

• If we consider the equation for the cyclic stress train curve

$$\epsilon_{\mathsf{a}} = \frac{\sigma_{\mathsf{a}}}{\mathsf{E}} + \left(\frac{\sigma_{\mathsf{a}}}{\mathsf{H}'}\right)^{\frac{1}{\mathsf{n}'}}$$

• We can consider the plastic portion and solve for σ_a

$$\sigma_{\rm a}={\it H}'\epsilon_{\rm pa}^{\it n'}$$

inconsistencies in constants

• We can eliminate $2N_f$ from the plastic strain equation

$$\epsilon_{pa} = \epsilon'_f (2N_f)^c$$

• By solving the stress-life relationship for $2N_f$

$$\sigma_a = \sigma_f'(2N_f)^b$$

and substituting that into the plastic strain

18

inconsistencies in constants

• We then compare with stress-life equations and find

$$H' = \frac{\sigma'_f}{(\epsilon'_f)^{b/c}}$$
$$n' = \frac{b}{c}$$

inconsistencies in constants

- However, in practice these constants are fit from different curves
- In some cases there can be large inconsistencies in these values
- One cause for this is data that do not lie on a straight line in the log-log domain
- For ductile materials at short lives, the true stresses and strains may differ significantly from engineering stress and strain

20


variable amplitude strains

variable amplitude strains


- As with stresses, we can apply variable amplitude strains
- However, when the change is made will affect whether there is a tensile or compressive mean stress

21

compressive mean



tensile mean



23

mean stress effects

mean stress in strain-based fatigue

- In regions where plastic strain is significant, some applied mean stress is likely to be relaxed through cyclic plastic strain
- When the plastic strain is not significant, mean stress will exist
- Mean strain does not generally affect fatigue life

24

morrow approach

 Recall the Morrow approach for mean stress effects from the stress-based method

$$\frac{\sigma_{\rm a}}{\sigma_{\rm ar}} + \frac{\sigma_{\rm m}}{\sigma_{\rm f}'} = 1$$

• We can rearrange the equation such that

$$\sigma_a = \sigma_f' \left[\left(1 - \frac{\sigma_m}{\sigma_f'} \right)^{\frac{1}{b}} (2N_f) \right]^b$$

morrow approach

 If we compare to the stress-life equation (σ_a = σ'_f(2N_f) we see that we can replace N_f with

$$N^* = N_f \left(1 - rac{\sigma_m}{\sigma_f'}
ight)^{rac{1}{b}}$$

 We can now substitute N* for N_f in the strain-life equation to find

$$\epsilon_{a} = \frac{\sigma_{f}'}{E} \left(1 - \frac{\sigma_{m}}{\sigma_{f}'} \right) (2N_{f})^{b} + \epsilon_{f}' \left(1 - \frac{\sigma_{m}}{\sigma_{f}'} \right)^{\frac{c}{b}} (2N_{f})^{c}$$

26

morrow approach

- Graphically, we can use the Morrow approach very easily using only the zero-mean stress graph
- From the zero-mean stress graph, find the point corresponding to your applied strain
- For a non zero mean stress, this point represents (ε_a, N*), we can now solve for N_f using the equation for N*

modified morrow

- While the Morrow equation agrees very well with many data, some are better fit with a modification
- In the modified version, it is assumed that the mean stress has no effect on the plastic term

$$\epsilon_a = \frac{\sigma_f'}{E} \left(1 - \frac{\sigma_f}{\sigma_f'} \right) (2N_f)^b + \epsilon_f' (2N_f)^c$$

• There is no convenient solution method for this form, and it generally must be solved numerically, or plotted with many families of σ_m

28

smith watson topper

- The Smith, Watson, and Topper approach assumes that the life for any given state is dependent on the product σ_{max} ε_a
- · After some manipulation, this gives

$$\sigma_{max}\epsilon_a = \frac{(\sigma_f')^2}{E}(2N_f)^{2b} + \sigma_f'\epsilon_f'(2N_f)^{b+c}$$

This method can also be solved graphically if a plot of
 σ_{max}ε_a is made using zero-mean data. All we need to do is
 find the new σ_{max}ε_a point to find a new N_f

comparison

- All three methods discussed are in general use
- The Morrow method is very good for steel
- The modified Morrow method gives improved results in many materials
- The SWT approach is very good for general use, but is non-conservative with a compressive mean stress

30


example p. 285

cycle counting

- In all fatigue methods (stress, strain, and crack propagation) the way we count load cycles can have an effect on our results
- To avoid being non-conservative, we need to always count the largest amplitudes first
- We will discuss some specific cycle-counting algorithms during crack propagation

32

cycle counting



general trends

true fracture strength

- We can consider a tensile test as a fatigue test with $N_f=0.5$
- We would then expect the true fracture strength $\tilde{\sigma}_f \approx \sigma_f'$
- And similarly for strain $\tilde{\epsilon}_f pprox \epsilon_f'$

ductile materials

- Since ductile materials experience large strains before failure, we expect relatively large ε'_f and relatively small σ'_f
- This will cause a less steep slope in the plastic strain line
- In turn this intersects with the elastic strain line much later, resulting a longer transition life for ductile materials

35

brittle materials

- = Brittle materials exhibit the opposite effect, with relatively low ϵ_f' and relatively high σ_f'
- This results in a steeper plastic strain line
- And shorter transition life

tough materials

- Tough materials have intermediate values for both ϵ'_f and σ'_ϵ
- This gives a transition life somewhere between brittle and ductile materials
- It is also noteworthy that strain-life for many metals pass through the point $\epsilon_a = 0.01$ and $N_f = 1000$ cycles
- Steels also follow a trend with Brinell Hardness, the higher they are on the HB scale, the lower their transition life

37

typical property ranges

- Most common engineering materials have -0.8 < c < -0.5, with most values being very close to c = -0.6
- The elastic strain slope generally has b = -0.085
- A "steep" elastic slope is around b = -0.12, common in soft metals
- While "shallow" slopes are around b = -0.05, common for hardened metals

notches

fatigue notch factor

- We previously found expressions for stress-based fatigue analysis when notches are present
- Due to yielding, the notch sensitivity is not the same for stress and strain controlled fatigue analysis
- One simple approach to find the strain fatigue notch factor is to use

$$K_t = \sqrt{K_f^{\sigma} K_f^{\epsilon}}$$

multiaxial loading

multiaxial loading

- Multi-axial loading in strain-based fatigue analysis is still an active field of research
- We are currently only capable of handling proportional loads that are in-phase (i.e. have the same frequency)

multiaxial loading

• If we consider the principal directions where $\sigma_{2a} = \lambda \sigma_{1a}$ we find an expression for the strain-life as

$$\epsilon_{1a} = \frac{\frac{\sigma_f'}{E} (1 - \nu \lambda) (2N_f)^b + \epsilon_f' (1 - 0.5\lambda) (2N_f)^c}{\sqrt{1 - \lambda + \lambda^2}}$$

41

stress triaxiality factor

Another approach is to consider the stress triaxiality factor

$$T = \frac{1 + \lambda}{\sqrt{1 - \lambda + \lambda^2}}$$

- Three notable cases of this are
 - 1. Pure planar shear: $\lambda = -1$ T = 0
 - 2. Uniaxial stress: $\lambda = 0$ T = 1
 - 3. Equal biaxial stress: $\lambda = 1$ T = 2

stress triaxiality factor

Marloff suggests the following inclusion of stress triaxiality

$$\bar{\epsilon_a} = \frac{\sigma_f'}{E} (2N_f)^b + 2^{1-T} \epsilon_f' (2N_f)^c$$

43

other factors affecting fatigue

factors affecting fatigue life

- At temperatures above one-half the melting temperature (absolute scale), creep-relaxation is significant
- This will cause the strain/stress-life curves to become rate dependent
- Occurs at room temperature for many materials (lead, tin, many polymers)
- At a sufficiently elevated temperature for any material

44

surface finish

- High cycle fatigue is sensitive to surface finish, samples are generally polished
- Low cycle fatigue is not sensitive to surface finish or residual stress
- The plastic deformation tends to remove residual stresses
- In high-cycle fatigue, crack initiation is important (poor surface finish allows cracks to form earlier)
- When plastic deformation is present (low-cycle fatigue), cracks form relatively quickly regardless of surface finish

surface finish

- Since low-cycle fatigue has little effect from surface finish, we could modify the strain life curve by altering only the elastic portion
- If we define the surface effect factor, m_s, we can find a new b_s to replace b in the strain-life equation

$$b_s = \frac{\log\left(m_s(2N_e)^b\right)}{\log(2N_e)}$$

46

surface treatments

- Treatments which decrease fatigue life:
 - Electro-plating (chrome, +corrosion resistance, -fatigue life)
 - Grinding improves surface finish, but introduces surface tension, and heat generated can temper quench
 - Stamping introduces discontinuities and irregularities
 - Forging can refine grain structure and improve physical properties, but can cause decarburization in steels, which hurts fatigue life
 - Hot rolling can also cause decarburization

surface treatments

- Some treatments improve fatigue life:
 - Cold rolling improves surface finish, introduces residual compressive stress on surface (slows crack initiation on surface)
 - Shot peeing introduces many small divots on surface, which can be detrimental in corrosion, but it does cause a residual compressive stress on the surface

48

size

- Size can also have effects on fatigue life
- Larger parts are more susceptible to damage/imperfections at the same stress level
- This is why composites are often made from very small fibers (glass fiber, carbon fiber, ceramic-matrix composites)

 The exact effect of size will depend on material, one study for low carbon steels found

$$m_d = \left(\frac{d}{25.4\text{mm}}\right)^{-0.093}$$

Which is then used to re-calculate material constants

$$\sigma'_{fd} = m_d \sigma'_f$$
 $\epsilon'_{fd} = m_d \epsilon'_f$

50

thermal fatigue

- Thermal loading can be introduced when two dissimilar parts are attached together, the coefficient of thermal expansion causes them to expand differently, introducing extra stresses due to the temperature change
- If the temperature is significantly different between two sides of a part thermal stresses can also be introduced

thermal fatigue

- Low temperatures generally cause a material to behave in a more brittle fashion, which alters the fatigue life
- High temperatures cause problems with creep-relaxation and can also affect the crystalline structure