AE 737: Mechanics of Damage Tolerance

Lecture 5 - Plastic Zone

Dr. Nicholas Smith

Wichita State University, Department of Aerospace Engineering

February 4, 2020

schedule

- 4 Feb Plastic Zone
- 6 Feb Plastic Zone, Homework 2 Due
- 11 Feb Fracture Toughness
- 13 Feb Fracture Toughness, Homework 3 Due


outline

- curved boundaries
- stress concentration factors
- plastic zone

curved boundaries

- For short cracks, we can use the *stress concentration factor* on a curved boundary to determine the stress intensity factor
- The stress concentration factor only gives the maximum stress at the curved boundary, thus the longer the crack is, the farther away from the curved boundary (and maximum stress) it is.
- Stress concentration factors can be found: pp. 82-85 in the text
- Also see supplemental text on Blackboard or here

- Suppose we want to determine the stress intensity on a panel, panel B
- We find a similar panel with a known stress intensity factor, panel A
- We adjust the applied load on panel A such that $K_{I,A}=K_{I,B}$
- The magnitude of this load adjustment is determined using the *stress concentration factors* in panels B and A



• Since *A* is a fictional panel, we set the applied stress, σ_A such that

$$\sigma_{max,B} = \sigma_{max,A}$$

• Substituting stress concentration factors

$$K_{t,B}\sigma_B=K_{t,A}\sigma_A$$


• Solving for σ_A

$$\sigma_A = rac{K_{t,B}}{K_{t,A}} \sigma_B$$

• Since the crack is short and $\sigma_{max,A} = \sigma_{max,B}$ we can say

$$egin{aligned} K_{I,B} &= K_{I,A} \ &= \sigma_A \sqrt{\pi c} eta_A \ &= rac{K_{t,B}}{K_{t,A}} \sigma_B \sqrt{\pi c} eta_A \end{aligned}$$


example 6 (p. 86)



long cracks on curved boundaries

- As a crack becomes very large, the effect of the curved boundary diminishes
- We find expressions for β_L (long crack) and β_S (short crack)
- We connect β_S to β_L using a straight line from β_S to a tangent intersection with β_L


long cracks on curved boundaries



example


• Example here

group one




- c = 0.75, e = 2.25, r = 0.5
- assume a is short and calculate β for this case
- calculate in terms of β for known state

group two




- c = 0.75, e = 2.25, r = 0.5
- assume a is long and calculate β for this case
- calculate in terms of β for known state

group three



- c = 0.75, e = 2.25, r = 0.5
- assume a is short and calculate β for this case
- calculate in terms of β for known state

group four



- c = 0.75, e = 2.25, r = 0.5
- assume a is long and calculate β for this case
- calculate in terms of β for known state


discussion

Draw a sketch to show how we could use this method to find cracks of intermediate length near a curved boundary

stress concentration factors


centered hole tension - p. 82

Stress Intensity Factors for a hole, (p. 82)



 K_{tg} uses stress for the cross-sectional area if no hole was present, K_{tn} uses stress at the net section (subtracting hole area). a is the hole diameter, W is specimen width.


off-center hole tension - p. 83



 K_{tg} uses stress for the cross-sectional area if no hole was present, K_{tn} uses stress at the net section (subtracting hole area). c is the distance from the closest edge to the center of the hole, e is the distance from the farthest edge to the center of the hole, r is hole radius.


bending of a bar with u-shaped notch - p. 84

 K_t For Bending of edge-notched bar (p.84)



Nominal stress used for K_t is given by $\sigma_{nom} = 6M/hd^2$ where M is applied bending moment, h is thickness, d is the net-section height (height minus notch depth). D is the height of the panel without a notch and r is the notch radius.

tension of a stepped bar with shoulder fillets - p. 85



D is the larger width (before the step), d is the width after the step. Nominal stress is $\sigma_{nom} = P/hd$, where h is specimen thickness. r is the fillet radius.

interactive page

• An interactive page with these plots can be accessed here

plastic zone

plastic zone

- Previous developments assumed perfectly elastic materials
- Most common materials have some plasticity
- Any stress above the yield stress will undergo plastic deformation (no stress higher than σ_y will be present in the material)

plastic zone

- Plasticity helps retard crack propagation due to residual stresses
- After an overload, elastic regions will contract back to their undeformed shape
- The region which has undergone plastic deformation, however, holds its deformed shape
- This introduces a region of residual compressive stress near the crack tip
- Before the crack can propagate, a stress needs to overcome this residual stress

2D problems

- We often simplify the full 3D elasticity equations for planar problems
- For very thin panels, we assume that all out-of-plane stresses are o
- This is called plane stress

plane stress

$$egin{aligned} \sigma_z &= au_{xz} = au_{zy} = 0 \ \epsilon_x &= rac{\sigma_x}{E} -
u rac{\sigma_y}{E} \ \epsilon_y &= -
u rac{\sigma_x}{E} + rac{\sigma_y}{E} \ \epsilon_z &= -
u rac{\sigma_x}{E} -
u rac{\sigma_y}{E} \ \gamma_{xy} &= rac{ au_{xy}}{G} \ \gamma_{xz} &= \gamma_{yz} = 0 \end{aligned}$$

2D problems

- When instead a panel is very thick, we assume that any strains through the thickness are small relative to other strains
- ullet $\epsilon_z=\gamma_{xz}=\gamma_{yz}=0$
- This is known as plane strain

plane strain


$$egin{align} \epsilon_x &= rac{\sigma_x}{E} -
u rac{\sigma_y}{E} -
u rac{\sigma_z}{E} \ \epsilon_y &= -
u rac{\sigma_x}{E} + rac{\sigma_y}{E} -
u rac{\sigma_z}{E} \ 0 &= -
u rac{\sigma_x}{E} -
u rac{\sigma_y}{E} + rac{\sigma_z}{E} \ \gamma_{xy} &= rac{ au_{xy}}{G} \ \gamma_{xz} &= \gamma_{yz} = 0 \ \end{pmatrix}$$

• If we recall the equation for opening stress (σ_y) near the crack tip

$$\sigma_y = \frac{K_I}{\sqrt{2\pi r}} \cos\frac{\theta}{2} \left(1 + \sin\frac{\theta}{2} \sin\frac{3\theta}{2} \right) \tag{1.2}$$

• In the plane of the crack, when $\theta = 0$ we find

$$\sigma_y = rac{K_I}{\sqrt{2\pi r}}$$



- We use *C*, the *Plastic Constraint Factor* to convert between Plane
 Strain and Plane Stress solutions
- The plastic zone size can now be approximated

$$egin{aligned} \sigma_{yy}(r=r_p) &= C\sigma_{YS} \ rac{K_I}{\sqrt{2\pi r_p}} &= C\sigma_{YS} \ r_p &= rac{1}{2\pi}igg(rac{K_I}{C\sigma_{YS}}igg)^2 \end{aligned}$$

ullet For plane stress (thin panels) we let C=1 and find r_p as

$$r_p = rac{1}{2\pi}igg(rac{K_I}{\sigma_{YS}}igg)^2$$

ullet And for plane strain (thick panels) we let $C=\sqrt{3}$ and find

$$r_p = rac{1}{6\pi} igg(rac{K_I}{\sigma_{YS}}igg)^2$$

Intermediate panels

• For panels which lie between plane strain and plane stress states, we use the following expression to estimate the plastic zone size


$$r_p = rac{1}{I\pi}igg(rac{K_I}{\sigma_{YS}}igg)^2$$

• Where *I* is defined as


$$I=6.7-rac{1.5}{t}igg(rac{K_I}{\sigma_{YS}}igg)^2$$

• And $2 \le I \le 6$

- If our material is perfectly elastic-plastic, no stresses above $C\sigma_{ys}$ will exist in the material
- This ignores the strain energy (represented by the area under the curve) in the plastic zone



- \bullet To account for the additional strain energy, Irwin considered a plastic zone size increased by some δ
- He also needed to adjust the stress function, and considered an equivalent crack tip in these calculations



We need A=B, so we set them equivalent and solve for δ .

$$egin{aligned} A &= \int_{0}^{r_{p}} \sigma_{yy} dr - r_{p} \sigma_{YS} \ &= \int_{0}^{r_{p}} rac{K_{I}}{\sqrt{2\pi r}} dr - r_{p} \sigma_{YS} \ &= rac{K_{I}}{\sqrt{2\pi}} \int_{0}^{r_{p}} r^{-1/2} dr - r_{p} \sigma_{YS} \ &= rac{2K_{I} \sqrt{r_{p}}}{\sqrt{2\pi}} - r_{p} \sigma_{YS} \end{aligned}$$

• We have already found r_p as

$$r_p = rac{1}{2\pi}igg(rac{K_I}{\sigma_{YS}}igg)^2$$

• If we solve this for K_I we find

$$K_I = \sqrt{2\pi r_p} \sigma_{YS}$$

• We can now substitute back into the strain energy of A


$$egin{aligned} A &= rac{2\sqrt{2\pi r_p}\sigma_{YS}\sqrt{r_p}}{\sqrt{2\pi}} - r_p\sigma_{YS} \ &= 2\sigma_{YS}r_p - r_p\sigma_{YS} \ &= r_p\sigma_{YS} \end{aligned}$$

• B is given simply as $B=\delta\sigma_{ys}$ so we equate A and B to find δ

$$egin{aligned} A &= B \ r_p \sigma_{YS} &= \delta \sigma_{YS} \ r_p &= \delta \end{aligned}$$

- ullet This means the plastic zone size is simply $2r_p$
- ullet However, it also means that the effective crack length is $a+r_p$
- Since r_p depends on K_I , we must iterate a bit to find the "real" r_p and K_I

Example



equations

$$eta = \left[1.122 - 0.231rac{a}{W} + 10.55 \left(rac{a}{W}
ight)^2 - 21.71 \left(rac{a}{W}
ight)^3 + 30.82 \left(rac{a}{W}
ight)^4
ight]
onumber \ I = 6.7 - rac{1.5}{t} \left(rac{K_I}{\sigma_{YS}}
ight)^2
onumber \ r_p = rac{1}{I\pi} \left(rac{K_I}{\sigma_{YS}}
ight)^2$$