# AE 737 - MECHANICS OF DAMAGE TOLERANCE

# LECTURE 18

Dr. Nicholas Smith

Last Updated: March 31, 2016 at 1:50pm

Wichita State University, Department of Aerospace Engineering

#### SCHEDULE

- · 31 Mar Strain based fatigue, project abstract due
- 5 Apr Crack Growth, Homework 7 due, Homework 8 assigned
- · 7 Apr Crack Growth, Stress Spectrum
- · 12 Apr Retardation, Boeing Commercial Method
- · 14 Apr Exam Review, Homework 8 Due
- 19 Apr Exam 2
- · 21 Apr Exam Solutions, Damage Tolerance

#### OUTLINE

- 1. strain based fatigue
- 2. general trends
- 3. other factors affecting fatigue
- 4. mean stress effects
- 5. multiaxial loading

 The strain based fatigue method uses local stresses and strains (instead of global, nominal values)

- The strain based fatigue method uses local stresses and strains (instead of global, nominal values)
- The strain-based method gives greater detail, and validity at lower cycles

- The strain based fatigue method uses local stresses and strains (instead of global, nominal values)
- The strain-based method gives greater detail, and validity at lower cycles
- · It is still valid for high cycle fatigue

- The strain based fatigue method uses local stresses and strains (instead of global, nominal values)
- The strain-based method gives greater detail, and validity at lower cycles
- It is still valid for high cycle fatigue
- · Does not include crack growth analysis or fracture mechanics

 Similar to the S-N curves in stress-based fatigue analysis, we can plot the cyclic strain amplitude vs. number of cycles to failure

- Similar to the S-N curves in stress-based fatigue analysis, we can plot the cyclic strain amplitude vs. number of cycles to failure
- This is most commonly done using axial test machines (instead of rotating bending tests)

- Similar to the S-N curves in stress-based fatigue analysis, we can plot the cyclic strain amplitude vs. number of cycles to failure
- This is most commonly done using axial test machines (instead of rotating bending tests)
- The test is run in strain control (not load control)


- Similar to the S-N curves in stress-based fatigue analysis, we can plot the cyclic strain amplitude vs. number of cycles to failure
- This is most commonly done using axial test machines (instead of rotating bending tests)
- The test is run in strain control (not load control)
- Generally plotted on log-log scale

 We can separate the total strain into elastic and plastic components


 We can separate the total strain into elastic and plastic components

$$\epsilon_a = \epsilon_{ea} + \epsilon_{pa} \tag{18.1}$$

# PLASTIC STRAIN



# **HYSTERESIS LOOPS**



#### CYCLIC STRESS STRAIN CURVE

• While strain-life data will generally just report  $\epsilon_a$  and  $\epsilon_{pa}$ , some will also tabulate a form for the cyclic stress-strain curve

#### CYCLIC STRESS STRAIN CURVE

• While strain-life data will generally just report  $\epsilon_a$  and  $\epsilon_{pa}$ , some will also tabulate a form for the cyclic stress-strain curve

$$\epsilon_a = \frac{\sigma_a}{E} + \left(\frac{\sigma_a}{H'}\right)^{\frac{1}{n'}} \tag{18.2}$$


• On strain life curves, the strain is often plotted three times per each experiment


- On strain life curves, the strain is often plotted three times per each experiment
- Once for total strain, once for plastic strain, and once for elastic strain

- On strain life curves, the strain is often plotted three times per each experiment
- Once for total strain, once for plastic strain, and once for elastic strain
- Since plastic strain and elastic strain vary by the number of cycles, a hysteresis loop from half the fatigue life is generally used

- On strain life curves, the strain is often plotted three times per each experiment
- Once for total strain, once for plastic strain, and once for elastic strain
- Since plastic strain and elastic strain vary by the number of cycles, a hysteresis loop from half the fatigue life is generally used
- · This is considered representative of stable behavior

# **EXPERIMENTAL DATA**





 We notice that the data for elastic and plastic strains are represented by straight lines, in the log-log scale

- We notice that the data for elastic and plastic strains are represented by straight lines, in the log-log scale
- If we recall the form used for a straight line in log-log plots for S-N curves:

- We notice that the data for elastic and plastic strains are represented by straight lines, in the log-log scale
- If we recall the form used for a straight line in log-log plots for S-N curves:

$$\sigma_a = \sigma_f'(2N_f)^b \tag{18.3}$$

- We notice that the data for elastic and plastic strains are represented by straight lines, in the log-log scale
- If we recall the form used for a straight line in log-log plots for S-N curves:

$$\sigma_a = \sigma_f'(2N_f)^b \tag{18.3}$$

· We can convert this to find the elastic component of strain

- We notice that the data for elastic and plastic strains are represented by straight lines, in the log-log scale
- If we recall the form used for a straight line in log-log plots for S-N curves:

$$\sigma_a = \sigma_f'(2N_f)^b \tag{18.3}$$

We can convert this to find the elastic component of strain

$$\epsilon_{ea} = \frac{\sigma_f'}{E} (2N_f)^b \tag{18.4}$$

• We can use the same form with new constants for the plastic component of strain

 We can use the same form with new constants for the plastic component of strain

$$\epsilon_{pa} = \epsilon_f'(2N_f)^c \tag{18.5}$$

 We can use the same form with new constants for the plastic component of strain

$$\epsilon_{pa} = \epsilon_f'(2N_f)^c \tag{18.5}$$

• We can combine 18.4 with 18.5 to find the total strain-life curve

 We can use the same form with new constants for the plastic component of strain

$$\epsilon_{pa} = \epsilon_f' (2N_f)^c \tag{18.5}$$

• We can combine 18.4 with 18.5 to find the total strain-life curve

$$\epsilon_a = \frac{\sigma_f'}{E} (2N_f)^b + \epsilon_f' (2N_f)^c$$
 (18.6)

# **EXAMPLE**

Data from p. 270

# TRANSITION LIFE

 With the strain-based fatigue method we are better equipped to discuss the difference between high and low-cycle fatigue

#### TRANSITION LIFE

- With the strain-based fatigue method we are better equipped to discuss the difference between high and low-cycle fatigue
- Low-cycle fatigue is dominated by plastic effects, while high-cycle fatigue has little plasticity

## TRANSITION LIFE

- With the strain-based fatigue method we are better equipped to discuss the difference between high and low-cycle fatigue
- Low-cycle fatigue is dominated by plastic effects, while high-cycle fatigue has little plasticity
- We can find the intersection of the plastic strain and elastic strain lines

## TRANSITION LIFE

- With the strain-based fatigue method we are better equipped to discuss the difference between high and low-cycle fatigue
- Low-cycle fatigue is dominated by plastic effects, while high-cycle fatigue has little plasticity
- We can find the intersection of the plastic strain and elastic strain lines
- This point is  $N_t$ , the transition fatigue life

## TRANSITION LIFE

- With the strain-based fatigue method we are better equipped to discuss the difference between high and low-cycle fatigue
- Low-cycle fatigue is dominated by plastic effects, while high-cycle fatigue has little plasticity
- We can find the intersection of the plastic strain and elastic strain lines
- This point is  $N_t$ , the transition fatigue life

$$N_t = \frac{1}{2} \left( \frac{\sigma_f'}{\epsilon_f'} \right)^{\frac{1}{c-b}} \tag{18.7}$$

• If we consider the equation for the cyclic stress train curve

$$\epsilon_a = \frac{\sigma_a}{E} + \left(\frac{\sigma_a}{H'}\right)^{\frac{1}{n'}} \tag{18.8}$$

• If we consider the equation for the cyclic stress train curve

$$\epsilon_a = \frac{\sigma_a}{E} + \left(\frac{\sigma_a}{H'}\right)^{\frac{1}{n'}} \tag{18.8}$$

 $\cdot$  We can consider the plastic portion and solve for  $\sigma_a$ 

$$\sigma_a = H' \epsilon_{pa}^{n'} \tag{18.9}$$

 $\cdot$  We can eliminate  $2N_f$  from the plastic strain equation

$$\epsilon_{pa} = \epsilon_f' (2N_f)^c \tag{18.10}$$

• We can eliminate  $2N_f$  from the plastic strain equation

$$\epsilon_{pa} = \epsilon_f' (2N_f)^c \tag{18.10}$$

• By solving the stress-life relationship for  $2N_f$ 

$$\sigma_a = \sigma_f'(2N_f)^b \tag{18.11}$$

and substituting that into the plastic strain

• We can eliminate  $2N_f$  from the plastic strain equation

$$\epsilon_{pa} = \epsilon_f' (2N_f)^c \tag{18.10}$$

• By solving the stress-life relationship for  $2N_f$ 

$$\sigma_a = \sigma_f'(2N_f)^b \tag{18.11}$$

and substituting that into the plastic strain

· We then compare with 18.9 and find

$$H' = \frac{\sigma_f'}{(\epsilon_f')^{b/c}}$$
 (18.12a)  
$$n' = \frac{b}{c}$$
 (18.12b)

$$n' = \frac{b}{c} \tag{18.12b}$$

However, in practice these constants are fit from different curves

- · However, in practice these constants are fit from different curves
- In some cases there can be large inconsistencies in these values

- · However, in practice these constants are fit from different curves
- In some cases there can be large inconsistencies in these values
- One cause for this is data that do not lie on a straight line in the log-log domain

- · However, in practice these constants are fit from different curves
- In some cases there can be large inconsistencies in these values
- One cause for this is data that do not lie on a straight line in the log-log domain
- For ductile materials at short lives, the true stresses and strains may differ significantly from engineering stress and strain



## TRUE FRACTURE STRENGTH

 $\cdot$  We can consider a tensile test as a fatigue test with  $N_f=0.5$ 

## TRUE FRACTURE STRENGTH

- $\cdot$  We can consider a tensile test as a fatigue test with  $N_f=0.5$
- We would then expect the true fracture strength  $\tilde{\sigma}_{\!f} \approx \sigma_{\!f}'$

## TRUE FRACTURE STRENGTH

- We can consider a tensile test as a fatigue test with  $N_f = 0.5$
- We would then expect the true fracture strength  $ilde{\sigma}_f pprox \sigma_f'$
- And similarly for strain  $\tilde{\epsilon}_f pprox \epsilon_f'$

## **DUCTILE MATERIALS**

• Since ductile materials experience large strains before failure, we expect relatively large  $\epsilon_f'$  and relatively small  $\sigma_f'$ 

## **DUCTILE MATERIALS**

- Since ductile materials experience large strains before failure, we expect relatively large  $\epsilon_f'$  and relatively small  $\sigma_f'$
- · This will cause a less steep slope in the plastic strain line

## **DUCTILE MATERIALS**

- Since ductile materials experience large strains before failure, we expect relatively large  $\epsilon_f'$  and relatively small  $\sigma_f'$
- · This will cause a less steep slope in the plastic strain line
- In turn this intersects with the elastic strain line much later, resulting a longer transition life for ductile materials

## **BRITTLE MATERIALS**

- Brittle materials exhibit the opposite effect, with relatively low  $\epsilon_f'$  and relatively high  $\sigma_f'$ 

## **BRITTLE MATERIALS**

- Brittle materials exhibit the opposite effect, with relatively low  $\epsilon_f'$  and relatively high  $\sigma_f'$
- · This results in a steeper plastic strain line

## **BRITTLE MATERIALS**

- Brittle materials exhibit the opposite effect, with relatively low  $\epsilon_f'$  and relatively high  $\sigma_f'$
- · This results in a steeper plastic strain line
- · And shorter transition life

- Tough materials have intermediate values for both  $\epsilon_f'$  and  $\sigma_f'$ 

- Tough materials have intermediate values for both  $\epsilon_f'$  and  $\sigma_f'$
- This gives a transition life somewhere between brittle and ductile materials

- Tough materials have intermediate values for both  $\epsilon_{\!f}'$  and  $\sigma_{\!f}'$
- This gives a transition life somewhere between brittle and ductile materials
- It is also noteworthy that strain-life for many metals pass through the point  $\epsilon_a=0.01$  and  $N_f=1000$  cycles

- Tough materials have intermediate values for both  $\epsilon_f'$  and  $\sigma_f'$
- This gives a transition life somewhere between brittle and ductile materials
- It is also noteworthy that strain-life for many metals pass through the point  $\epsilon_a=0.01$  and  $N_f=1000$  cycles
- Steels also follow a trend with Brinell Hardness, the higher they are on the HB scale, the lower their transition life

• Most common engineering materials have -0.8 < c < -0.5, with most values being very close to c = -0.6

- Most common engineering materials have -0.8 < c < -0.5, with most values being very close to c = -0.6
- The elastic strain slope generally has b = -0.085

- Most common engineering materials have -0.8 < c < -0.5, with most values being very close to c = -0.6
- The elastic strain slope generally has b = -0.085
- A "steep" elastic slope is around b = -0.12, common in soft metals

- Most common engineering materials have -0.8 < c < -0.5, with most values being very close to c = -0.6
- The elastic strain slope generally has b = -0.085
- A "steep" elastic slope is around b = -0.12, common in soft metals
- While "shallow" slopes are around b = -0.05, common for hardened metals

# OTHER FACTORS AFFECTING FATIGUE

• Factors other than the stress/strain can effect fatigue life

- · Factors other than the stress/strain can effect fatigue life
- At temperatures above one-half the melting temperature (absolute scale), creep-relaxation is significant

- · Factors other than the stress/strain can effect fatigue life
- At temperatures above one-half the melting temperature (absolute scale), creep-relaxation is significant
- This will cause the strain/stress-life curves to become rate dependent

- Factors other than the stress/strain can effect fatigue life
- At temperatures above one-half the melting temperature (absolute scale), creep-relaxation is significant
- This will cause the strain/stress-life curves to become rate dependent
- Occurs at room temperature for many materials (lead, tin, many polymers)

- Factors other than the stress/strain can effect fatigue life
- At temperatures above one-half the melting temperature (absolute scale), creep-relaxation is significant
- This will cause the strain/stress-life curves to become rate dependent
- Occurs at room temperature for many materials (lead, tin, many polymers)
- · At a sufficiently elevated temperature for any material

• S-N curves (stress-based method) are highly sensitive to surface finish, samples are generally polished

- S-N curves (stress-based method) are highly sensitive to surface finish, samples are generally polished
- Strain life curves are not very sensitive to surface finish or residual strength at short lives

- S-N curves (stress-based method) are highly sensitive to surface finish, samples are generally polished
- Strain life curves are not very sensitive to surface finish or residual strength at short lives
- The plastic deformation tends to remove residual stresses

- S-N curves (stress-based method) are highly sensitive to surface finish, samples are generally polished
- Strain life curves are not very sensitive to surface finish or residual strength at short lives
- · The plastic deformation tends to remove residual stresses
- In high-cycle fatigue, crack initiation is important (poor surface finish allows cracks to form earlier)

- S-N curves (stress-based method) are highly sensitive to surface finish, samples are generally polished
- Strain life curves are not very sensitive to surface finish or residual strength at short lives
- The plastic deformation tends to remove residual stresses
- In high-cycle fatigue, crack initiation is important (poor surface finish allows cracks to form earlier)
- When plastic deformation is present (low-cycle fatigue), cracks form relatively quickly regardless of surface finish

 Since low-cycle fatigue has little effect from surface finish, we could modify the strain life curve by altering only the elastic portion

- Since low-cycle fatigue has little effect from surface finish, we could modify the strain life curve by altering only the elastic portion
- If we define the surface effect factor,  $m_s$ , we can find a new  $b_s$  to replace b in the strain-life equation

- Since low-cycle fatigue has little effect from surface finish, we could modify the strain life curve by altering only the elastic portion
- If we define the surface effect factor,  $m_s$ , we can find a new  $b_s$  to replace b in the strain-life equation

$$b_{s} = \frac{\log\left(m_{s}(2N_{e})^{b}\right)}{\log(2N_{e})}$$
 (18.13)

• Surfaces are often treated for cosmetic or corrosion purposes, these treatments can affect fatigue life

- Surfaces are often treated for cosmetic or corrosion purposes, these treatments can affect fatigue life
- Treatments which decrease fatigue life:

- Surfaces are often treated for cosmetic or corrosion purposes, these treatments can affect fatigue life
- Treatments which decrease fatigue life:
  - Electro-plating (chrome, +corrosion resistance, -fatigue life)

- Surfaces are often treated for cosmetic or corrosion purposes, these treatments can affect fatigue life
- · Treatments which decrease fatigue life:
  - Electro-plating (chrome, +corrosion resistance, -fatigue life)
  - Grinding improves surface finish, but introduces surface tension, and heat generated can temper quench

- Surfaces are often treated for cosmetic or corrosion purposes, these treatments can affect fatigue life
- · Treatments which decrease fatigue life:
  - Electro-plating (chrome, +corrosion resistance, -fatigue life)
  - Grinding improves surface finish, but introduces surface tension, and heat generated can temper quench
  - · Stamping introduces discontinuities and irregularities

- Surfaces are often treated for cosmetic or corrosion purposes, these treatments can affect fatigue life
- · Treatments which decrease fatigue life:
  - Electro-plating (chrome, +corrosion resistance, -fatigue life)
  - Grinding improves surface finish, but introduces surface tension, and heat generated can temper quench
  - · Stamping introduces discontinuities and irregularities
  - Forging is generally good for refining grain structure and improving physical properties, but can cause decarburization in steels, which is harmful to fatigue life

- Surfaces are often treated for cosmetic or corrosion purposes, these treatments can affect fatigue life
- · Treatments which decrease fatigue life:
  - Electro-plating (chrome, +corrosion resistance, -fatigue life)
  - Grinding improves surface finish, but introduces surface tension, and heat generated can temper quench
  - · Stamping introduces discontinuities and irregularities
  - Forging is generally good for refining grain structure and improving physical properties, but can cause decarburization in steels, which is harmful to fatigue life
  - · Hot rolling can also cause decarburization

 $\boldsymbol{\cdot}$  Some treatments improve fatigue life:

- · Some treatments improve fatigue life:
  - Cold rolling improves surface finish, introduces residual compressive stress on surface (slows crack initiation on surface)

- · Some treatments improve fatigue life:
  - Cold rolling improves surface finish, introduces residual compressive stress on surface (slows crack initiation on surface)
  - Shot peeing introduces many small divots on surface, which can be detrimental in corrosion, but it does cause a residual compressive stress on the surface

• Size can also have effects on fatigue life

- · Size can also have effects on fatigue life
- Larger parts are more susceptible to damage/imperfections at the same stress level

- Size can also have effects on fatigue life
- Larger parts are more susceptible to damage/imperfections at the same stress level
- This is why composites are often made from very small fibers (glass fiber, carbon fiber, ceramic-matrix composites)

- Size can also have effects on fatigue life
- Larger parts are more susceptible to damage/imperfections at the same stress level
- This is why composites are often made from very small fibers (glass fiber, carbon fiber, ceramic-matrix composites)
- The exact effect of size will depend on material, one study for low carbon steels found

- · Size can also have effects on fatigue life
- Larger parts are more susceptible to damage/imperfections at the same stress level
- This is why composites are often made from very small fibers (glass fiber, carbon fiber, ceramic-matrix composites)
- The exact effect of size will depend on material, one study for low carbon steels found

$$m_d = \left(\frac{d}{25.4 \text{mm}}\right)^{-0.093} \tag{18.14}$$

- · Size can also have effects on fatigue life
- Larger parts are more susceptible to damage/imperfections at the same stress level
- This is why composites are often made from very small fibers (glass fiber, carbon fiber, ceramic-matrix composites)
- The exact effect of size will depend on material, one study for low carbon steels found

$$m_d = \left(\frac{d}{25.4 \text{mm}}\right)^{-0.093} \tag{18.14}$$

· Which is then used to re-calculate material constants

$$\sigma'_{fd} = m_d \sigma'_f, \qquad \epsilon'_{fd} = m_d \epsilon'_f$$
 (18.15)

 Thermal loading can be introduced when two dissimilar parts are attached together, the coefficient of thermal expansion causes them to expand differently, introducing extra stresses due to the temperature change

- Thermal loading can be introduced when two dissimilar parts are attached together, the coefficient of thermal expansion causes them to expand differently, introducing extra stresses due to the temperature change
- If the temperature is significantly different between two sides of a part thermal stresses can also be introduced

- Thermal loading can be introduced when two dissimilar parts are attached together, the coefficient of thermal expansion causes them to expand differently, introducing extra stresses due to the temperature change
- If the temperature is significantly different between two sides of a part thermal stresses can also be introduced
- Low temperatures generally cause a material to behave in a more brittle fashion, which alters the fatigue life

- Thermal loading can be introduced when two dissimilar parts are attached together, the coefficient of thermal expansion causes them to expand differently, introducing extra stresses due to the temperature change
- If the temperature is significantly different between two sides of a part thermal stresses can also be introduced
- Low temperatures generally cause a material to behave in a more brittle fashion, which alters the fatigue life
- High temperatures cause problems with creep-relaxation and can also affect the crystalline structure

# MEAN STRESS EFFECTS

## MEAN STRESS IN STRAIN-BASED FATIGUE

 In regions where plastic strain is significant, some applied mean stress is likely to be relaxed through cyclic plastic strain

## MEAN STRESS IN STRAIN-BASED FATIGUE

- In regions where plastic strain is significant, some applied mean stress is likely to be relaxed through cyclic plastic strain
- · When the plastic strain is not significant, mean stress will exist

## MEAN STRESS IN STRAIN-BASED FATIGUE

- In regions where plastic strain is significant, some applied mean stress is likely to be relaxed through cyclic plastic strain
- · When the plastic strain is not significant, mean stress will exist
- · Mean strain does not generally affect fatigue life

 Recall the Morrow approach for mean stress effects from the stress-based method

 Recall the Morrow approach for mean stress effects from the stress-based method

$$\frac{\sigma_a}{\sigma_{ar}} + \frac{\sigma_m}{\sigma_f'} = 1 \tag{18.16}$$

 Recall the Morrow approach for mean stress effects from the stress-based method

$$\frac{\sigma_a}{\sigma_{ar}} + \frac{\sigma_m}{\sigma_f'} = 1 \tag{18.16}$$

· We can rearrange the equation such that

 Recall the Morrow approach for mean stress effects from the stress-based method

$$\frac{\sigma_a}{\sigma_{ar}} + \frac{\sigma_m}{\sigma_f'} = 1 \tag{18.16}$$

· We can rearrange the equation such that

$$\sigma_a = \sigma_f' \left[ \left( 1 - \frac{\sigma_m}{\sigma_f'} \right)^{\frac{1}{b}} (2N_f) \right]^b \tag{18.17}$$

• If we compare to the stress-life equation  $(\sigma_a = \sigma'_f(2N_f)^b)$ , we see that we can replace  $N_f$  with

• If we compare to the stress-life equation  $(\sigma_a = \sigma'_f(2N_f)^b)$ , we see that we can replace  $N_f$  with

$$N^* = N_f \left( 1 - \frac{\sigma_m}{\sigma_f'} \right)^{\frac{1}{b}} \tag{18.18}$$

• If we compare to the stress-life equation  $(\sigma_a = \sigma'_f(2N_f)^b)$ , we see that we can replace  $N_f$  with

$$N^* = N_f \left( 1 - \frac{\sigma_m}{\sigma_f'} \right)^{\frac{1}{b}} \tag{18.18}$$

• We can now substitute  $N^*$  for  $N_f$  in the strain-life equation to find

• If we compare to the stress-life equation  $(\sigma_a = \sigma_f'(2N_f)^b)$ , we see that we can replace  $N_f$  with

$$N^* = N_f \left( 1 - \frac{\sigma_m}{\sigma_f'} \right)^{\frac{1}{b}} \tag{18.18}$$

• We can now substitute  $N^*$  for  $N_f$  in the strain-life equation to find

$$\epsilon_a = \frac{\sigma_f'}{E} \left( 1 - \frac{\sigma_m}{\sigma_f'} \right) (2N_f)^b + \epsilon_f' \left( 1 - \frac{\sigma_m}{\sigma_f'} \right)^{\frac{c}{b}} (2N_f)^c$$
 (18.19)

• Graphically, we can use the Morrow approach very easily using only the zero-mean stress graph

- Graphically, we can use the Morrow approach very easily using only the zero-mean stress graph
- From the zero-mean stress graph, find the point corresponding to your applied strain

- Graphically, we can use the Morrow approach very easily using only the zero-mean stress graph
- From the zero-mean stress graph, find the point corresponding to your applied strain
- For a non zero mean stress, this point represents ( $\epsilon_a$ ,  $N^*$ ), we can now solve for  $N_f$  using 18.18

• While the Morrow equation agrees very well with many data, some are better fit with a modification

- While the Morrow equation agrees very well with many data, some are better fit with a modification
- In the modified version, it is assumed that the mean stress has no effect on the plastic term

- While the Morrow equation agrees very well with many data, some are better fit with a modification
- In the modified version, it is assumed that the mean stress has no effect on the plastic term

$$\epsilon_a = \frac{\sigma_f'}{E} \left( 1 - \frac{\sigma_f}{\sigma_f'} \right) (2N_f)^b + \epsilon_f' (2N_f)^c$$
 (18.20)

- While the Morrow equation agrees very well with many data, some are better fit with a modification
- In the modified version, it is assumed that the mean stress has no effect on the plastic term

$$\epsilon_a = \frac{\sigma_f'}{E} \left( 1 - \frac{\sigma_f}{\sigma_f'} \right) (2N_f)^b + \epsilon_f' (2N_f)^c$$
 (18.20)

• There is no convenient solution method for this form, and it generally must be solved numerically, or plotted with many families of  $\sigma_m$ 

• The Smith, Watson, and Topper approach assumes that the life for any given state is dependent on the product  $\sigma_m ax \epsilon_a$ 

- The Smith, Watson, and Topper approach assumes that the life for any given state is dependent on the product  $\sigma_m ax \epsilon_a$
- · After some manipulation, this gives

- The Smith, Watson, and Topper approach assumes that the life for any given state is dependent on the product  $\sigma_m ax \epsilon_a$
- · After some manipulation, this gives

$$\sigma_{max}\epsilon_a = \frac{\left(\sigma_f'\right)^2}{E} (2N_f)^{2b} + \sigma_f'\epsilon_f'(2N_f)^{b+c}$$
 (18.21)

- The Smith, Watson, and Topper approach assumes that the life for any given state is dependent on the product  $\sigma_m ax \epsilon_a$
- · After some manipulation, this gives

$$\sigma_{max}\epsilon_a = \frac{\left(\sigma_f'\right)^2}{E} (2N_f)^{2b} + \sigma_f'\epsilon_f'(2N_f)^{b+c}$$
 (18.21)

• This method can also be solved graphically if a plot of  $\sigma_{max}\epsilon_a$  is made using zero-mean data. All we need to do is find the new  $\sigma_{max}\epsilon_a$  point to find a new  $N_f$ 

 $\cdot$  All three methods discussed are in general use

- · All three methods discussed are in general use
- $\boldsymbol{\cdot}$  The Morrow method is very good for steel

- · All three methods discussed are in general use
- · The Morrow method is very good for steel
- The modified Morrow method gives improved results in many materials

- · All three methods discussed are in general use
- · The Morrow method is very good for steel
- The modified Morrow method gives improved results in many materials
- The SWT approach is very good for general use, but is non-conservative with a compressive mean stress

# **EXAMPLE**



 Multi-axial loading in strain-based fatigue analysis is still an active field of research

- Multi-axial loading in strain-based fatigue analysis is still an active field of research
- We are currently only capable of handling proportional loads that are in-phase (i.e. have the same frequency)

- Multi-axial loading in strain-based fatigue analysis is still an active field of research
- We are currently only capable of handling proportional loads that are in-phase (i.e. have the same frequency)
- If we consider the principal directions where  $\sigma_{2a} = \lambda \sigma_{1a}$ , we find an expression for the strain-life as

- Multi-axial loading in strain-based fatigue analysis is still an active field of research
- We are currently only capable of handling proportional loads that are in-phase (i.e. have the same frequency)
- If we consider the principal directions where  $\sigma_{2a} = \lambda \sigma_{1a}$ , we find an expression for the strain-life as

$$\epsilon_{1a} = \frac{\frac{\sigma_f'}{E} (1 - \nu \lambda) (2N_f)^b + \epsilon_f' (1 - 0.5\lambda) (2N_f)^c}{\sqrt{1 - \lambda + \lambda^2}}$$
(18.22)

 $\boldsymbol{\cdot}$  Another approach is to consider the stress triaxiality factor

$$T = \frac{1+\lambda}{\sqrt{1-\lambda+\lambda^2}} \tag{18.23}$$

· Another approach is to consider the stress triaxiality factor

$$T = \frac{1+\lambda}{\sqrt{1-\lambda+\lambda^2}} \tag{18.23}$$

· Three notable cases of this are

$$T = \frac{1+\lambda}{\sqrt{1-\lambda+\lambda^2}} \tag{18.23}$$

- · Three notable cases of this are
  - 1. Pure planar shear:  $\lambda = -1, T = 0$

$$T = \frac{1+\lambda}{\sqrt{1-\lambda+\lambda^2}} \tag{18.23}$$

- · Three notable cases of this are
  - 1. Pure planar shear:  $\lambda = -1, T = 0$
  - 2. Uniaxial stress:  $\lambda = 0, T = 1$

$$T = \frac{1+\lambda}{\sqrt{1-\lambda+\lambda^2}} \tag{18.23}$$

- · Three notable cases of this are
  - 1. Pure planar shear:  $\lambda = -1, T = 0$
  - 2. Uniaxial stress:  $\lambda = 0, T = 1$
  - 3. Equal biaxial stress:  $\lambda = 1, T = 2$

$$T = \frac{1+\lambda}{\sqrt{1-\lambda+\lambda^2}} \tag{18.23}$$

- · Three notable cases of this are
  - 1. Pure planar shear:  $\lambda = -1, T = 0$
  - 2. Uniaxial stress:  $\lambda = 0, T = 1$
  - 3. Equal biaxial stress:  $\lambda = 1, T = 2$
- · Marloff suggests the following inclusion of stress triaxiality

$$T = \frac{1+\lambda}{\sqrt{1-\lambda+\lambda^2}} \tag{18.23}$$

- · Three notable cases of this are
  - 1. Pure planar shear:  $\lambda = -1, T = 0$
  - 2. Uniaxial stress:  $\lambda = 0, T = 1$
  - 3. Equal biaxial stress:  $\lambda = 1, T = 2$
- · Marloff suggests the following inclusion of stress triaxiality

$$\bar{\epsilon_a} = \frac{\sigma_f'}{E} (2N_f)^b + 2^{1-T} \epsilon_f' (2N_f)^c$$
 (18.24)