AE 737 - MECHANICS OF DAMAGE TOLERANCE

LECTURE 22

Dr. Nicholas Smith

Last Updated: April 14, 2016 at 2:29pm

Wichita State University, Department of Aerospace Engineering

SCHEDULE

- 14 Apr Exam Review
- · 19 Apr Damage Tolerance, Homework 8 Due
- 21 Apr Exam 2
- · 26 Apr Exam Solutions, Damage Tolerance
- · 28 Apr SPTE, AFGROW, Finite Elements

OUTLINE

- 1. crack growth retardation
- 2. exam 2
- 3. stress based fatigue
- 4. strain based fatigue
- 5. fracture based fatigue

 $\boldsymbol{\cdot}$ When an overload is applied, the plastic zone is larger

- · When an overload is applied, the plastic zone is larger
- This zone has residual compressive stresses, which slow crack growth until the crack grows beyond this over-sized plastic zone

- · When an overload is applied, the plastic zone is larger
- This zone has residual compressive stresses, which slow crack growth until the crack grows beyond this over-sized plastic zone
- We will discuss three retardation models, but no model has been shown to be perfect in all cases

- · When an overload is applied, the plastic zone is larger
- This zone has residual compressive stresses, which slow crack growth until the crack grows beyond this over-sized plastic zone
- We will discuss three retardation models, but no model has been shown to be perfect in all cases
- The Wheeler method reduces da/dN, the Willenborg model reduces ΔK , and the Closure model increases R (increases σ_{min})

- As long as crack is within overload plastic zone, we scale da/dN by some ϕ

- As long as crack is within overload plastic zone, we scale da/dN by some ϕ

$$(a_i + r_{pi}) = (a_{ol} + r_{pol})$$
 (22.1)

• As long as crack is within overload plastic zone, we scale da/dN by some ϕ

$$(a_i + r_{pi}) = (a_{ol} + r_{pol})$$
 (22.1)

• And ϕ is given by

$$\phi_i = \left[\frac{r_{pi}}{a_{ol} + r_{pol} - a_i}\right]^m \tag{22.2}$$

• As long as crack is within overload plastic zone, we scale da/dN by some ϕ

$$(a_i + r_{pi}) = (a_{ol} + r_{pol})$$
 (22.1)

• And ϕ is given by

$$\phi_i = \left[\frac{r_{pi}}{a_{ol} + r_{pol} - a_i}\right]^m \tag{22.2}$$

· and the constant, *m* is to be determined experimentally

WHEELER EXAMPLE

WILLENBORG RETARDATION

• Once again, we consider that retardation occurs when $(a_i + r_{pi}) = (a_{ol} + r_{pol})$

WILLENBORG RETARDATION

- Once again, we consider that retardation occurs when $(a_i + r_{pi}) = (a_{ol} + r_{pol})$
- Willenborg assumes that the residual compressive stress in the plastic zone creates an effective, $K_{max,eff}$, where $K_{max,eff} = K_{max} K_{comp}$

WILLENBORG RETARDATION

- Once again, we consider that retardation occurs when $(a_i + r_{pi}) = (a_{ol} + r_{pol})$
- Willenborg assumes that the residual compressive stress in the plastic zone creates an effective, $K_{max,eff}$, where $K_{max,eff} = K_{max} K_{comp}$
- · The effective stress intensity factor is given by

$$K_{max,eff} = K_{max,i} - \left[K_{max,OL} \sqrt{1 - \frac{\Delta a_i}{r_{pol}}} - K_{max,i} \right]$$
 (22.3)

 Galagher and Hughes observed that the Willenborg model stops cracks when they still propagate

- Galagher and Hughes observed that the Willenborg model stops cracks when they still propagate
- \cdot They proposed a correction to the model

- Galagher and Hughes observed that the Willenborg model stops cracks when they still propagate
- They proposed a correction to the model

$$K_{max,eff} = K_{max,i} - \phi_i \left[K_{max,OL} \sqrt{1 - \frac{\Delta a_i}{r_{pol}}} - K_{max,i} \right]$$
 (22.4)

- Galagher and Hughes observed that the Willenborg model stops cracks when they still propagate
- · They proposed a correction to the model

$$K_{max,eff} = K_{max,i} - \phi_i \left[K_{max,OL} \sqrt{1 - \frac{\Delta a_i}{r_{pol}}} - K_{max,i} \right]$$
 (22.4)

· And the correction factor, ϕ_i is given by

$$\phi_i = \frac{1 - K_{TH}/K_{max,i}}{s_{ol} - 1} \tag{22.5}$$

WILLENBORG EXAMPLE

• Once again, we consider that retardation occurs when $(a_i + r_{pi}) = (a_{ol} + r_{pol})$

- Once again, we consider that retardation occurs when $(a_i + r_{pi}) = (a_{ol} + r_{pol})$
- Within the overloaded plastic zone, the opening stress required can be expressed as

$$\sigma_{OP} = \sigma_{max}(1 - (1 - C_{f0})(1 + 0.6R)(1 - R))$$
 (22.6)

- Once again, we consider that retardation occurs when $(a_i + r_{pi}) = (a_{ol} + r_{pol})$
- Within the overloaded plastic zone, the opening stress required can be expressed as

$$\sigma_{OP} = \sigma_{max}(1 - (1 - C_{f0})(1 + 0.6R)(1 - R))$$
 (22.6)

 \cdot Commonly this is expressed using the Closure Factor, C_f

- Once again, we consider that retardation occurs when $(a_i + r_{pi}) = (a_{ol} + r_{pol})$
- Within the overloaded plastic zone, the opening stress required can be expressed as

$$\sigma_{OP} = \sigma_{max}(1 - (1 - C_{f0})(1 + 0.6R)(1 - R))$$
 (22.6)

 \cdot Commonly this is expressed using the Closure Factor, C_f

$$C_f = \frac{\sigma_{OP}}{\sigma_{max}} = (1 - (1 - C_{f0})(1 + 0.6R)(1 - R))$$
 (22.7)

- Once again, we consider that retardation occurs when $(a_i + r_{pi}) = (a_{ol} + r_{pol})$
- Within the overloaded plastic zone, the opening stress required can be expressed as

$$\sigma_{OP} = \sigma_{max}(1 - (1 - C_{f0})(1 + 0.6R)(1 - R))$$
 (22.6)

 \cdot Commonly this is expressed using the Closure Factor, C_f

$$C_f = \frac{\sigma_{OP}}{\sigma_{max}} = (1 - (1 - C_{f0})(1 + 0.6R)(1 - R))$$
 (22.7)

• Where C_{f0} is the value of the Closure Factor at R=0

- When using the closure model, we replace R with \mathcal{C}_f

- \cdot When using the closure model, we replace R with C_f
- If the model we are using is in terms of ΔK we will also need to use $\Delta K = (1-C_f)K_{max}$

CLOSURE EXAMPLE

• Just as a tensile "overload" retards crack growth, we might expect a compressive "underload" to accelerate crack growth

- Just as a tensile "overload" retards crack growth, we might expect a compressive "underload" to accelerate crack growth
- This effect is not usually modeled for a few reasons

- Just as a tensile "overload" retards crack growth, we might expect a compressive "underload" to accelerate crack growth
- · This effect is not usually modeled for a few reasons
 - 1. Compressive underloads are uncommon in airframes

- Just as a tensile "overload" retards crack growth, we might expect a compressive "underload" to accelerate crack growth
- · This effect is not usually modeled for a few reasons
 - 1. Compressive underloads are uncommon in airframes
 - 2. The acceleration effect is minimal

- Just as a tensile "overload" retards crack growth, we might expect a compressive "underload" to accelerate crack growth
- · This effect is not usually modeled for a few reasons
 - 1. Compressive underloads are uncommon in airframes
 - 2. The acceleration effect is minimal
 - 3. Analysis is generally adjusted with experimental data, so acceleration can be built in to current model

- Just as a tensile "overload" retards crack growth, we might expect a compressive "underload" to accelerate crack growth
- · This effect is not usually modeled for a few reasons
 - 1. Compressive underloads are uncommon in airframes
 - 2. The acceleration effect is minimal
 - 3. Analysis is generally adjusted with experimental data, so acceleration can be built in to current model
 - 4. Structures with large compressive loads are not generally subject to crack propagation problems

EXAM 2

• 5 questions

- 5 questions
- Bring calculator

- 5 questions
- Bring calculator
- Closed note/closed book

- 5 questions
- Bring calculator
- · Closed note/closed book
- Make sure you can integrate the Paris Law equation (see Homework 8 problems 1 and 2)

- 5 questions
- Bring calculator
- · Closed note/closed book
- Make sure you can integrate the Paris Law equation (see Homework 8 problems 1 and 2)
- No table look-ups (stress intensity factors, paris/walker law constants will be given in problem)




 $\boldsymbol{\cdot}$ Has the simplest analysis of any fatigue analysis

- · Has the simplest analysis of any fatigue analysis
- Very good for high cycle fatigue (i.e. low stress fatigue)

- · Has the simplest analysis of any fatigue analysis
- · Very good for high cycle fatigue (i.e. low stress fatigue)
- · High cycle fatigue means there is less plasticity

- · Has the simplest analysis of any fatigue analysis
- · Very good for high cycle fatigue (i.e. low stress fatigue)
- · High cycle fatigue means there is less plasticity
- \cdot Typically starts between $10^2 10^4$ cycles

- · Has the simplest analysis of any fatigue analysis
- · Very good for high cycle fatigue (i.e. low stress fatigue)
- · High cycle fatigue means there is less plasticity
- Typically starts between $10^2 10^4$ cycles
- This point varies by material, but can be found using strain-based fatigue analysis



- $\Delta\sigma$ is known as the stress range, and is the difference between max and min stress

- $\Delta \sigma$ is known as the stress range, and is the difference between max and min stress
- σ_m is the mean stress, and can sometimes be zero, but this is not always the case

- $\Delta \sigma$ is known as the stress range, and is the difference between max and min stress
- σ_m is the mean stress, and can sometimes be zero, but this is not always the case
- \cdot σ_a is the stress amplitude, and is the variation about the mean

- $\Delta \sigma$ is known as the stress range, and is the difference between max and min stress
- σ_m is the mean stress, and can sometimes be zero, but this is not always the case
- \cdot σ_a is the stress amplitude, and is the variation about the mean
- We can express all of these in terms of the maximum and minimum stress

$$\Delta \sigma = \sigma_{max} - \sigma_{min} \tag{22.8}$$

$$\sigma_m = \frac{\sigma_{max} + \sigma_{min}}{2} \tag{22.9}$$

$$\sigma_a = \frac{\sigma_{max} - \sigma_{min}}{2} \tag{22.10}$$

• It is also common to describe some ratios

- It is also common to describe some ratios
- The stress ratio, R is defined as

$$R = \frac{\sigma_{min}}{\sigma_{max}} \tag{22.11}$$

- · It is also common to describe some ratios
- The stress ratio, R is defined as

$$R = \frac{\sigma_{min}}{\sigma_{max}} \tag{22.11}$$

· And the amplitude ratio, A is defined as

$$A = \frac{\sigma_0}{\sigma_m} \tag{22.12}$$

USEFUL RELATIONS

 There are some useful relationships between the above equations

$$\Delta \sigma = 2\sigma_a = \sigma_{max}(1 - R) \tag{22.13a}$$

$$\sigma_m = \frac{\sigma_{max}}{2} (1 + R) \tag{22.13b}$$

$$R = \frac{1 - A}{1 + A}$$
 (22.13c)

$$A = \frac{1 - R}{1 + R} \tag{22.13d}$$

 $\boldsymbol{\cdot}$ High cycle fatigue requires a lot of testing

- · High cycle fatigue requires a lot of testing
- Usually for very high cycle fatigue some form of rotating beam test machine is used

- High cycle fatigue requires a lot of testing
- Usually for very high cycle fatigue some form of rotating beam test machine is used
- Rotating 4-point bend is one of the most common modern methods

- · High cycle fatigue requires a lot of testing
- Usually for very high cycle fatigue some form of rotating beam test machine is used
- Rotating 4-point bend is one of the most common modern methods
- · Tensile test machines can be used, but require much more time

ROTATING FOUR-POINT BEND




Figure 1: Four-point bend gives uniform stress (along top and bottom surfaces)

 Stress-life curves, or S-N curves, are generated from test data to predict the number of cycles to failure

- Stress-life curves, or S-N curves, are generated from test data to predict the number of cycles to failure
- In general, one set (or family) of S-N curves is generated using the same σ_m

- Stress-life curves, or S-N curves, are generated from test data to predict the number of cycles to failure
- In general, one set (or family) of S-N curves is generated using the same σ_m
- Usually S_a (the nominal stress equivalent of σ_a) is plotted versus N (the number of cycles)


• Each individual point on an S-N curve represents one fatigue experiment

- Each individual point on an S-N curve represents one fatigue experiment
- To find enough data to form statistical significance, as well as to fit a curve across all levels of fatigue is very time-consuming

- Each individual point on an S-N curve represents one fatigue experiment
- To find enough data to form statistical significance, as well as to fit a curve across all levels of fatigue is very time-consuming
- In the following plot, if only one test was performed for each point, the total number of cycles tested would be about 7.3x10⁷

- Each individual point on an S-N curve represents one fatigue experiment
- To find enough data to form statistical significance, as well as to fit a curve across all levels of fatigue is very time-consuming
- In the following plot, if only one test was performed for each point, the total number of cycles tested would be about 7.3x10⁷
- For a 100 Hz machine, this represents over 200 hours of consecutive testing

- Each individual point on an S-N curve represents one fatigue experiment
- To find enough data to form statistical significance, as well as to fit a curve across all levels of fatigue is very time-consuming
- In the following plot, if only one test was performed for each point, the total number of cycles tested would be about 7.3x10⁷
- For a 100 Hz machine, this represents over 200 hours of consecutive testing
- Each repetition would further increase the test time required




 On a linear scale, the data appear not to agree well with any standard fit

- On a linear scale, the data appear not to agree well with any standard fit
- It is also very difficult to differentiate between low-cycle fatigue failure stresses

STRESS LIFE CURVES

- On a linear scale, the data appear not to agree well with any standard fit
- It is also very difficult to differentiate between low-cycle fatigue failure stresses
- Instead S-N curves are often plotted on a semi-log or log-log scale, so pay attention to the axes

STRESS LIFE CURVES



• If the curve is nearly linear on a log-linear plot, we use the following form to fit the data

• If the curve is nearly linear on a log-linear plot, we use the following form to fit the data

$$\sigma_a = C + D \log N_f \tag{22.14}$$

• If the curve is nearly linear on a log-linear plot, we use the following form to fit the data

$$\sigma_a = C + D \log N_f \tag{22.14}$$

 When the data are instead linear on a log-log scale, the following form is generally used

• If the curve is nearly linear on a log-linear plot, we use the following form to fit the data

$$\sigma_a = C + D \log N_f \tag{22.14}$$

 When the data are instead linear on a log-log scale, the following form is generally used

$$\sigma_a = \sigma_f' \left(2N_f \right)^b \tag{22.15}$$

 If the curve is nearly linear on a log-linear plot, we use the following form to fit the data


$$\sigma_a = C + D \log N_f \tag{22.14}$$

 When the data are instead linear on a log-log scale, the following form is generally used

$$\sigma_a = \sigma_f' \left(2N_f \right)^b \tag{22.15}$$

• σ_f' and b are often considered material properties and can often be looked up on a table (p. 235)

STRESS LIFE CURVES




 The fatigue limit, or endurance limit, is a feature of some materials where below a certain stress, no fatigue failure is observed

- The fatigue limit, or endurance limit, is a feature of some materials where below a certain stress, no fatigue failure is observed
- Below the fatigue limit, this material is considered to have infinite life

- The fatigue limit, or endurance limit, is a feature of some materials where below a certain stress, no fatigue failure is observed
- Below the fatigue limit, this material is considered to have infinite life
- · This most notably occurs in plain-carbon and low-alloy steels

- The fatigue limit, or endurance limit, is a feature of some materials where below a certain stress, no fatigue failure is observed
- Below the fatigue limit, this material is considered to have infinite life
- This most notably occurs in plain-carbon and low-alloy steels
- · In these materials, σ_e is considered to be a material property

- The fatigue limit, or endurance limit, is a feature of some materials where below a certain stress, no fatigue failure is observed
- Below the fatigue limit, this material is considered to have infinite life
- · This most notably occurs in plain-carbon and low-alloy steels
- In these materials, σ_e is considered to be a material property
- This phenomenon is not typical of aluminum or copper alloys, but is sometimes arbitrarily assigned using whatever the failure stress is at some large number of cycles (10⁷ or 10⁸)



• We know that variable loads can often occur in real scenarios, but how can we model the effect?

- We know that variable loads can often occur in real scenarios, but how can we model the effect?
- Miner's Rule is often used to approximate the effect of variable amplitude load

- We know that variable loads can often occur in real scenarios, but how can we model the effect?
- Miner's Rule is often used to approximate the effect of variable amplitude load
- We consider each load amplitude (and the number of cycles at that amplitude) as having used up a percentage of a part's life

- We know that variable loads can often occur in real scenarios, but how can we model the effect?
- Miner's Rule is often used to approximate the effect of variable amplitude load
- We consider each load amplitude (and the number of cycles at that amplitude) as having used up a percentage of a part's life

$$\frac{N_1}{N_{f1}} + \frac{N_2}{N_{f2}} + \frac{N_3}{N_{f3}} + \dots = \sum \frac{N_i}{N_{fi}} = 1$$
 (22.16)

 Often there are "blocks" of variable amplitude loads which repeat

- Often there are "blocks" of variable amplitude loads which repeat
- · A typical flight cycle is a good example of this

- Often there are "blocks" of variable amplitude loads which repeat
- · A typical flight cycle is a good example of this
- A flight will have working loads, vibrations, as well as storms/turbulence, but each flight should have similar loading

- Often there are "blocks" of variable amplitude loads which repeat
- · A typical flight cycle is a good example of this
- A flight will have working loads, vibrations, as well as storms/turbulence, but each flight should have similar loading
- If we call the number of "block" B then we have

- Often there are "blocks" of variable amplitude loads which repeat
- · A typical flight cycle is a good example of this
- A flight will have working loads, vibrations, as well as storms/turbulence, but each flight should have similar loading
- · If we call the number of "block" B then we have

$$B\left[\sum \frac{N_i}{N_{if}}\right]_{rep} = 1 \tag{22.17}$$

 Since mean stress has an effect on fatigue life, sometimes a family of S-N curves at varying mean stress values is created

- Since mean stress has an effect on fatigue life, sometimes a family of S-N curves at varying mean stress values is created
- S-N curves for these are reported in different ways, but commonly σ_{max} replaces σ_a on the y-axis

- Since mean stress has an effect on fatigue life, sometimes a family of S-N curves at varying mean stress values is created
- S-N curves for these are reported in different ways, but commonly σ_{max} replaces σ_a on the y-axis
- One useful way of representing these data, instead of many S-N curves, is a constant-life diagram

- Since mean stress has an effect on fatigue life, sometimes a family of S-N curves at varying mean stress values is created
- S-N curves for these are reported in different ways, but commonly σ_{max} replaces σ_a on the y-axis
- One useful way of representing these data, instead of many S-N curves, is a constant-life diagram
- It is created by taking points from the S-N curves and plotting a line through constant N_f values

 The first work on this problem was done by Goodman, who proposed the line

 The first work on this problem was done by Goodman, who proposed the line

$$\frac{\sigma_a}{\sigma_{ar}} + \frac{\sigma_m}{\sigma_u} = 1 \tag{22.18}$$

 The first work on this problem was done by Goodman, who proposed the line

$$\frac{\sigma_a}{\sigma_{ar}} + \frac{\sigma_m}{\sigma_u} = 1 \tag{22.18}$$

 This equation can also be used for fatigue limits, since they are just a point on the S-N curves

 The first work on this problem was done by Goodman, who proposed the line

$$\frac{\sigma_a}{\sigma_{ar}} + \frac{\sigma_m}{\sigma_u} = 1 \tag{22.18}$$

 This equation can also be used for fatigue limits, since they are just a point on the S-N curves

$$\frac{\sigma_e}{\sigma_{er}} + \frac{\sigma_m}{\sigma_u} = 1 \tag{22.19}$$

 While the Goodman line gives a good approximation to convert non-zero mean stress S-N curves, it is somewhat overly conservative at high mean stresses

- While the Goodman line gives a good approximation to convert non-zero mean stress S-N curves, it is somewhat overly conservative at high mean stresses
- It is also non-conservative for negative mean stresses

- While the Goodman line gives a good approximation to convert non-zero mean stress S-N curves, it is somewhat overly conservative at high mean stresses
- It is also non-conservative for negative mean stresses
- · An alternative fit is known as the Gerber Parabola

- While the Goodman line gives a good approximation to convert non-zero mean stress S-N curves, it is somewhat overly conservative at high mean stresses
- It is also non-conservative for negative mean stresses
- · An alternative fit is known as the Gerber Parabola

$$\frac{\sigma_a}{\sigma_{ar}} + \left(\frac{\sigma_m}{\sigma_u}\right)^2 = 1 \tag{22.20}$$

- While the Goodman line gives a good approximation to convert non-zero mean stress S-N curves, it is somewhat overly conservative at high mean stresses
- It is also non-conservative for negative mean stresses
- · An alternative fit is known as the Gerber Parabola

$$\frac{\sigma_a}{\sigma_{ar}} + \left(\frac{\sigma_m}{\sigma_u}\right)^2 = 1 \tag{22.20}$$

 In general, the Goodman line is a good fit for brittle materials (steels) while the Gerber parabola is a better fit for more ductile materials

• The Goodman line can also be improved by replacing σ_u with the corrected true fracture strength $\tilde{\sigma}_{fB}$ or the constant σ_f' from the S-N curve fit

• The Goodman line can also be improved by replacing σ_u with the corrected true fracture strength $\tilde{\sigma}_{fB}$ or the constant σ_f' from the S-N curve fit

$$\frac{\sigma_a}{\sigma_{ar}} + \frac{\sigma_m}{\sigma_f'} = 1 \tag{22.21}$$

• The Goodman line can also be improved by replacing σ_u with the corrected true fracture strength $\tilde{\sigma}_{fB}$ or the constant σ_f' from the S-N curve fit

$$\frac{\sigma_a}{\sigma_{ar}} + \frac{\sigma_m}{\sigma_f'} = 1 \tag{22.21}$$

This is known as the Morrow Equation

• The Goodman line can also be improved by replacing σ_u with the corrected true fracture strength $\tilde{\sigma}_{fB}$ or the constant σ_f' from the S-N curve fit

$$\frac{\sigma_a}{\sigma_{ar}} + \frac{\sigma_m}{\sigma_f'} = 1 \tag{22.21}$$

- · This is known as the Morrow Equation
- For steels, $\sigma_f' \approx \tilde{\sigma}_{fB}$, but for aluminums these values can be significantly different, and better agreement is found using $\tilde{\sigma}_{fB}$.

 One more relationship that has shown particularly good results with aluminum alloys is the Smith, Watson, and Topper equations (SWT)

 One more relationship that has shown particularly good results with aluminum alloys is the Smith, Watson, and Topper equations (SWT)

$$\sigma_{ar} = \sqrt{\sigma_{max}\sigma_a} \tag{22.22}$$

 One more relationship that has shown particularly good results with aluminum alloys is the Smith, Watson, and Topper equations (SWT)

$$\sigma_{ar} = \sqrt{\sigma_{max}\sigma_a} \tag{22.22}$$

· In general, it is best to use a form that matches your data

 One more relationship that has shown particularly good results with aluminum alloys is the Smith, Watson, and Topper equations (SWT)

$$\sigma_{ar} = \sqrt{\sigma_{max}\sigma_a} \tag{22.22}$$

- · In general, it is best to use a form that matches your data
- If data is lacking, the SWT (22.22) and Morrow (22.21) equations generally provide the best fit

 Often combined loads from different sources introduce stresses which are not uni-axial

- Often combined loads from different sources introduce stresses which are not uni-axial
- For ductile materials, good agreement has been found using an effective stress amplitude, similar to the octahedral shear yield criterion

- Often combined loads from different sources introduce stresses which are not uni-axial
- For ductile materials, good agreement has been found using an effective stress amplitude, similar to the octahedral shear yield criterion

$$\bar{\sigma}_a = \frac{1}{\sqrt{2}} \sqrt{(\sigma_{xa} - \sigma_{ya})^2 + (\sigma_{ya} - \sigma_{za})^2 + (\sigma_{za} - \sigma_{xa})^2 + 6(\tau_{xy}^2 + \tau_{yz}^2 + \tau_{zx}^2)}$$
(22.23)

- Often combined loads from different sources introduce stresses which are not uni-axial
- For ductile materials, good agreement has been found using an effective stress amplitude, similar to the octahedral shear yield criterion

$$\bar{\sigma}_a = \frac{1}{\sqrt{2}} \sqrt{(\sigma_{xa} - \sigma_{ya})^2 + (\sigma_{ya} - \sigma_{za})^2 + (\sigma_{za} - \sigma_{xa})^2 + 6(\tau_{xy}^2 + \tau_{yz}^2 + \tau_{zx}^2)}$$
(22.23)

· The effective mean stress is given by

- Often combined loads from different sources introduce stresses which are not uni-axial
- For ductile materials, good agreement has been found using an effective stress amplitude, similar to the octahedral shear yield criterion

$$\bar{\sigma}_a = \frac{1}{\sqrt{2}} \sqrt{(\sigma_{xa} - \sigma_{ya})^2 + (\sigma_{ya} - \sigma_{za})^2 + (\sigma_{za} - \sigma_{xa})^2 + 6(\tau_{xy}^2 + \tau_{yz}^2 + \tau_{zx}^2)}$$
(22.23)

· The effective mean stress is given by

$$\bar{\sigma}_m = \bar{\sigma}_{xm} + \bar{\sigma}_{ym} + \bar{\sigma}_{zm} \tag{22.24}$$

• In this discussion, we use "notch" to refer to any geometric feature that increases the local stress (such as holes, fillets, grooves, etc.)

- In this discussion, we use "notch" to refer to any geometric feature that increases the local stress (such as holes, fillets, grooves, etc.)
- We discussed notches and stress concentration factors in terms of stress concentration factors

- In this discussion, we use "notch" to refer to any geometric feature that increases the local stress (such as holes, fillets, grooves, etc.)
- We discussed notches and stress concentration factors in terms of stress concentration factors
- In our fatigue notation, $\sigma_{max} = K_t S$

- In this discussion, we use "notch" to refer to any geometric feature that increases the local stress (such as holes, fillets, grooves, etc.)
- We discussed notches and stress concentration factors in terms of stress concentration factors
- In our fatigue notation, $\sigma_{max} = K_t S$
- This relates local stress to the average, nominal stress

- In this discussion, we use "notch" to refer to any geometric feature that increases the local stress (such as holes, fillets, grooves, etc.)
- We discussed notches and stress concentration factors in terms of stress concentration factors
- In our fatigue notation, $\sigma_{max} = K_t S$
- This relates local stress to the average, nominal stress
- The stress intensity factor can be used to characterize the "strength" of a notch

• We might expect the fatigue life of a notched specimen to be similar to a pristine specimen with $S_{a,pristine} = \sigma_{max,notched}$

- We might expect the fatigue life of a notched specimen to be similar to a pristine specimen with $S_{a,pristine} = \sigma_{max,notched}$
- If we look at actual test data, however, this estimate would be overly conservative

- We might expect the fatigue life of a notched specimen to be similar to a pristine specimen with $S_{a,pristine} = \sigma_{max,notched}$
- If we look at actual test data, however, this estimate would be overly conservative
- Even when the stress is adjusted for some fatigue notch factor, k_f , it is only valid at longer cycles ($N_f > 10^6$)

- We might expect the fatigue life of a notched specimen to be similar to a pristine specimen with $S_{a,pristine} = \sigma_{max,notched}$
- If we look at actual test data, however, this estimate would be overly conservative
- Even when the stress is adjusted for some fatigue notch factor, k_f , it is only valid at longer cycles ($N_f > 10^6$)

$$k_f = \frac{\sigma_{ar}}{S_{ar}} \tag{22.25}$$

- We might expect the fatigue life of a notched specimen to be similar to a pristine specimen with $S_{a,pristine} = \sigma_{max,notched}$
- If we look at actual test data, however, this estimate would be overly conservative
- Even when the stress is adjusted for some fatigue notch factor, k_f , it is only valid at longer cycles ($N_f > 10^6$)

$$k_f = \frac{\sigma_{ar}}{S_{ar}} \tag{22.25}$$

 Notches will have different effects, largely depending on their radius.

- We might expect the fatigue life of a notched specimen to be similar to a pristine specimen with $S_{a,pristine} = \sigma_{max,notched}$
- If we look at actual test data, however, this estimate would be overly conservative
- Even when the stress is adjusted for some fatigue notch factor, k_f , it is only valid at longer cycles ($N_f > 10^6$)

$$k_f = \frac{\sigma_{ar}}{S_{ar}} \tag{22.25}$$

- Notches will have different effects, largely depending on their radius.
- The maximum possible fatigue notch factor is $k_f = k_t$

 To avoid generating fatigue data for every possible notch configuration, some empirical relationships have been developed

- To avoid generating fatigue data for every possible notch configuration, some empirical relationships have been developed
- \cdot A useful concept in these methods is the notch sensitivity factor

- To avoid generating fatigue data for every possible notch configuration, some empirical relationships have been developed
- · A useful concept in these methods is the notch sensitivity factor

$$q = \frac{k_f - 1}{k_t - 1} \tag{22.26}$$

- To avoid generating fatigue data for every possible notch configuration, some empirical relationships have been developed
- · A useful concept in these methods is the notch sensitivity factor

$$q = \frac{k_f - 1}{k_t - 1} \tag{22.26}$$

• When $k_f = 1$, q = 0, in which case the notch has no effect

- To avoid generating fatigue data for every possible notch configuration, some empirical relationships have been developed
- · A useful concept in these methods is the notch sensitivity factor

$$q = \frac{k_f - 1}{k_t - 1} \tag{22.26}$$

- When $k_f = 1$, q = 0, in which case the notch has no effect
- When $k_f = k_t$, q = 1, in which case the notch has its maximum effect

· Peterson developed the following relationship

· Peterson developed the following relationship

$$q = \frac{1}{1 + \frac{\alpha}{\rho}} \tag{22.27}$$

· Peterson developed the following relationship

$$q = \frac{1}{1 + \frac{\alpha}{\rho}} \tag{22.27}$$

 \cdot Where ho is the radius of the notch

· Peterson developed the following relationship

$$q = \frac{1}{1 + \frac{\alpha}{\rho}} \tag{22.27}$$

- Where ρ is the radius of the notch
- \cdot α is a material property

Peterson developed the following relationship

$$q = \frac{1}{1 + \frac{\alpha}{\rho}} \tag{22.27}$$

- Where ρ is the radius of the notch
- α is a material property

Table 1: Table of α values for Peterson notch sensitivity equation

| Material | α (mm) | α (in) |
|-------------------------------|---------------|---------------|
| Aluminum alloys | 0.51 | 0.02 |
| Annealed or low-carbon steels | 0.25 | 0.01 |
| Quenched and tempered steels | 0.064 | 0.0025 |

• For high-strength steels, a more specific α estimate can be found

$$\alpha = 0.025 \left(\frac{2070}{\sigma_u}\right)^{1.8}$$
 mm $\sigma_u \ge 550$ MPa (22.28)

$$\alpha = 0.001 \left(\frac{300}{\sigma_u}\right)^{1.8}$$
 in $\sigma_u \ge 80$ ksi (22.29)

 \cdot For high-strength steels, a more specific lpha estimate can be found

$$\alpha = 0.025 \left(\frac{2070}{\sigma_u}\right)^{1.8}$$
 mm $\sigma_u \ge 550$ MPa (22.28)

$$\alpha = 0.001 \left(\frac{300}{\sigma_u}\right)^{1.8}$$
 in $\sigma_u \ge 80 \text{ ksi}$ (22.29)

 \cdot α predictions are valid for bending and axial fatigue

PETERSON NOTCH SENSITIVY

 \cdot For high-strength steels, a more specific lpha estimate can be found

$$\alpha = 0.025 \left(\frac{2070}{\sigma_u}\right)^{1.8}$$
 mm $\sigma_u \ge 550$ MPa (22.28)

$$\alpha = 0.001 \left(\frac{300}{\sigma_u}\right)^{1.8}$$
 in $\sigma_u \ge 80$ ksi (22.29)

- \cdot α predictions are valid for bending and axial fatigue
- · For torsion fatigue, a good estimate can be found

PETERSON NOTCH SENSITIVY

 \cdot For high-strength steels, a more specific lpha estimate can be found

$$\alpha = 0.025 \left(\frac{2070}{\sigma_u}\right)^{1.8}$$
 mm $\sigma_u \ge 550$ MPa (22.28)

$$\alpha = 0.001 \left(\frac{300}{\sigma_u}\right)^{1.8}$$
 in $\sigma_u \ge 80$ ksi (22.29)

- \cdot α predictions are valid for bending and axial fatigue
- · For torsion fatigue, a good estimate can be found

$$\alpha_{torsion} = 0.6\alpha$$
 (22.30)



 The strain based fatigue method uses local stresses and strains (instead of global, nominal values)

- The strain based fatigue method uses local stresses and strains (instead of global, nominal values)
- The strain-based method gives greater detail, and validity at lower cycles

- The strain based fatigue method uses local stresses and strains (instead of global, nominal values)
- The strain-based method gives greater detail, and validity at lower cycles
- · It is still valid for high cycle fatigue

- The strain based fatigue method uses local stresses and strains (instead of global, nominal values)
- The strain-based method gives greater detail, and validity at lower cycles
- It is still valid for high cycle fatigue
- · Does not include crack growth analysis or fracture mechanics

LINES

 If we separate elastic and plastic strains, we notice that the data for elastic and plastic strains are represented by straight lines, in the log-log scale

LINES

- If we separate elastic and plastic strains, we notice that the data for elastic and plastic strains are represented by straight lines, in the log-log scale
- If we recall the form used for a straight line in log-log plots for S-N curves:

- If we separate elastic and plastic strains, we notice that the data for elastic and plastic strains are represented by straight lines, in the log-log scale
- If we recall the form used for a straight line in log-log plots for S-N curves:

$$\sigma_a = \sigma_f'(2N_f)^b \tag{22.31}$$

- If we separate elastic and plastic strains, we notice that the data for elastic and plastic strains are represented by straight lines, in the log-log scale
- If we recall the form used for a straight line in log-log plots for S-N curves:

$$\sigma_a = \sigma_f'(2N_f)^b \tag{22.31}$$

We can convert this to find the elastic component of strain

- If we separate elastic and plastic strains, we notice that the data for elastic and plastic strains are represented by straight lines, in the log-log scale
- If we recall the form used for a straight line in log-log plots for S-N curves:

$$\sigma_a = \sigma_f'(2N_f)^b \tag{22.31}$$

We can convert this to find the elastic component of strain

$$\epsilon_{ea} = \frac{\sigma_f'}{E} (2N_f)^b \tag{22.32}$$

LINES

• We can use the same form with new constants for the plastic component of strain

LINES

 We can use the same form with new constants for the plastic component of strain

$$\epsilon_{pa} = \epsilon_f'(2N_f)^c \tag{22.33}$$

 We can use the same form with new constants for the plastic component of strain

$$\epsilon_{pa} = \epsilon_f'(2N_f)^c \tag{22.33}$$

• We can combine 22.32 with 22.33 to find the total strain-life curve

 We can use the same form with new constants for the plastic component of strain

$$\epsilon_{pa} = \epsilon_f' (2N_f)^c \tag{22.33}$$

• We can combine 22.32 with 22.33 to find the total strain-life curve

$$\epsilon_a = \frac{\sigma_f'}{E} (2N_f)^b + \epsilon_f' (2N_f)^c$$
 (22.34)

MEAN STRESS IN STRAIN-BASED FATIGUE

 In regions where plastic strain is significant, some applied mean stress is likely to be relaxed through cyclic plastic strain

MEAN STRESS IN STRAIN-BASED FATIGUE

- In regions where plastic strain is significant, some applied mean stress is likely to be relaxed through cyclic plastic strain
- · When the plastic strain is not significant, mean stress will exist

MEAN STRESS IN STRAIN-BASED FATIGUE

- In regions where plastic strain is significant, some applied mean stress is likely to be relaxed through cyclic plastic strain
- · When the plastic strain is not significant, mean stress will exist
- Mean strain does not generally affect fatigue life

 Recall the Morrow approach for mean stress effects from the stress-based method

 Recall the Morrow approach for mean stress effects from the stress-based method

$$\frac{\sigma_a}{\sigma_{ar}} + \frac{\sigma_m}{\sigma_f'} = 1 \tag{22.35}$$

 Recall the Morrow approach for mean stress effects from the stress-based method

$$\frac{\sigma_a}{\sigma_{ar}} + \frac{\sigma_m}{\sigma_f'} = 1 \tag{22.35}$$

· We can rearrange the equation such that

 Recall the Morrow approach for mean stress effects from the stress-based method

$$\frac{\sigma_a}{\sigma_{ar}} + \frac{\sigma_m}{\sigma_f'} = 1 \tag{22.35}$$

· We can rearrange the equation such that

$$\sigma_a = \sigma_f' \left[\left(1 - \frac{\sigma_m}{\sigma_f'} \right)^{\frac{1}{b}} (2N_f) \right]^b \tag{22.36}$$

• If we compare to the stress-life equation $(\sigma_a = \sigma'_f(2N_f)^b)$, we see that we can replace N_f with

• If we compare to the stress-life equation $(\sigma_a = \sigma'_f(2N_f)^b)$, we see that we can replace N_f with

$$N^* = N_f \left(1 - \frac{\sigma_m}{\sigma_f'} \right)^{\frac{1}{b}} \tag{22.37}$$

• If we compare to the stress-life equation $(\sigma_a = \sigma'_f(2N_f)^b)$, we see that we can replace N_f with

$$N^* = N_f \left(1 - \frac{\sigma_m}{\sigma_f'} \right)^{\frac{1}{b}} \tag{22.37}$$

• We can now substitute N^* for N_f in the strain-life equation to find

• If we compare to the stress-life equation $(\sigma_a = \sigma'_f(2N_f)^b)$, we see that we can replace N_f with

$$N^* = N_f \left(1 - \frac{\sigma_m}{\sigma_f'} \right)^{\frac{1}{b}} \tag{22.37}$$

• We can now substitute N^* for N_f in the strain-life equation to find

$$\epsilon_a = \frac{\sigma_f'}{E} \left(1 - \frac{\sigma_m}{\sigma_f'} \right) (2N_f)^b + \epsilon_f' \left(1 - \frac{\sigma_m}{\sigma_f'} \right)^{\frac{c}{b}} (2N_f)^c \tag{22.38}$$

• Graphically, we can use the Morrow approach very easily using only the zero-mean stress graph

- Graphically, we can use the Morrow approach very easily using only the zero-mean stress graph
- From the zero-mean stress graph, find the point corresponding to your applied strain

- Graphically, we can use the Morrow approach very easily using only the zero-mean stress graph
- From the zero-mean stress graph, find the point corresponding to your applied strain
- For a non zero mean stress, this point represents (ϵ_a , N^*), we can now solve for N_f using 22.37

 While the Morrow equation agrees very well with many data, some are better fit with a modification

- While the Morrow equation agrees very well with many data, some are better fit with a modification
- In the modified version, it is assumed that the mean stress has no effect on the plastic term

- While the Morrow equation agrees very well with many data, some are better fit with a modification
- In the modified version, it is assumed that the mean stress has no effect on the plastic term

$$\epsilon_a = \frac{\sigma_f'}{E} \left(1 - \frac{\sigma_m}{\sigma_f'} \right) (2N_f)^b + \epsilon_f' (2N_f)^c$$
 (22.39)

- While the Morrow equation agrees very well with many data, some are better fit with a modification
- In the modified version, it is assumed that the mean stress has no effect on the plastic term

$$\epsilon_a = \frac{\sigma_f'}{E} \left(1 - \frac{\sigma_m}{\sigma_f'} \right) (2N_f)^b + \epsilon_f' (2N_f)^c \tag{22.39}$$

• There is no convenient solution method for this form, and it generally must be solved numerically, or plotted with many families of σ_m

SMITH WATSON TOPPER

• The Smith, Watson, and Topper approach assumes that the life for any given state is dependent on the product $\sigma_m ax \epsilon_a$

SMITH WATSON TOPPER

- The Smith, Watson, and Topper approach assumes that the life for any given state is dependent on the product $\sigma_m ax \epsilon_a$
- After some manipulation, this gives

SMITH WATSON TOPPER

- The Smith, Watson, and Topper approach assumes that the life for any given state is dependent on the product $\sigma_m ax \epsilon_a$
- · After some manipulation, this gives

$$\sigma_{max}\epsilon_a = \frac{\left(\sigma_f'\right)^2}{E} (2N_f)^{2b} + \sigma_f'\epsilon_f'(2N_f)^{b+c}$$
 (22.40)

SMITH WATSON TOPPER

- The Smith, Watson, and Topper approach assumes that the life for any given state is dependent on the product $\sigma_m ax \epsilon_a$
- · After some manipulation, this gives

$$\sigma_{max}\epsilon_a = \frac{\left(\sigma_f'\right)^2}{E} (2N_f)^{2b} + \sigma_f'\epsilon_f'(2N_f)^{b+c}$$
 (22.40)

• This method can also be solved graphically if a plot of $\sigma_{max}\epsilon_a$ is made using zero-mean data. All we need to do is find the new $\sigma_{max}\epsilon_a$ point to find a new N_f

 \cdot All three methods discussed are in general use

- · All three methods discussed are in general use
- $\boldsymbol{\cdot}$ The Morrow method is very good for steel

- · All three methods discussed are in general use
- The Morrow method is very good for steel
- The modified Morrow method gives improved results in many materials


- · All three methods discussed are in general use
- · The Morrow method is very good for steel
- The modified Morrow method gives improved results in many materials
- The SWT approach is very good for general use, but is non-conservative with a compressive mean stress



FRACTURE SURFACE



FRACTURE SURFACE



 We can observe that fatigue damage occurs through crack propagation

- We can observe that fatigue damage occurs through crack propagation
- "cracks" and fracture mechanics have been omitted from all our fatigue discussion thus far

- We can observe that fatigue damage occurs through crack propagation
- "cracks" and fracture mechanics have been omitted from all our fatigue discussion thus far
- It would be beneficial to predict at what rate a crack will extend


· Crack growth rate can be measured experimentally

- · Crack growth rate can be measured experimentally
- $\boldsymbol{\cdot}$ Using a center-crack specimen, a fatigue load is applied

- · Crack growth rate can be measured experimentally
- · Using a center-crack specimen, a fatigue load is applied
- The crack length is measured and plotted vs. the number of cycles

- · Crack growth rate can be measured experimentally
- · Using a center-crack specimen, a fatigue load is applied
- The crack length is measured and plotted vs. the number of cycles
- The slope of this curve $(\frac{da}{dN})$ is then plotted vs. either $K_{I,max}$ or ΔK_I on a log-log scale

- · Crack growth rate can be measured experimentally
- · Using a center-crack specimen, a fatigue load is applied
- The crack length is measured and plotted vs. the number of cycles
- The slope of this curve $(\frac{da}{dN})$ is then plotted vs. either $K_{I,max}$ or ΔK_I on a log-log scale
- This chart is then commonly divided into three regions



REGION I

 \cdot In Region I crack growth is very slow and/or difficult to measure

REGION I

- In Region I crack growth is very slow and/or difficult to measure
- In many cases, da/dN corresponds to the spacing between atoms!

REGION I

- In Region I crack growth is very slow and/or difficult to measure
- In many cases, da/dN corresponds to the spacing between atoms!
- The point at which the da/dN curve intersects the boundary between Region I and Region II is often called the fatigue threshold

- In Region I crack growth is very slow and/or difficult to measure
- In many cases, da/dN corresponds to the spacing between atoms!
- The point at which the da/dN curve intersects the boundary between Region I and Region II is often called the fatigue threshold
- Typically 3-15 ksi√in for steel

- In Region I crack growth is very slow and/or difficult to measure
- In many cases, da/dN corresponds to the spacing between atoms!
- The point at which the da/dN curve intersects the boundary between Region I and Region II is often called the fatigue threshold
- Typically 3-15 ksi√in for steel
- · 3-6 ksi√in for aluminum

REGION II

• Most important region for general engineering analysis

REGION II

- Most important region for general engineering analysis
- Once a crack is present, most of the growth and life occurs in Region II

- · Most important region for general engineering analysis
- Once a crack is present, most of the growth and life occurs in Region II
- · Generally linear in the log-log scale

REGION III

Unstable crack growth

REGION III

- · Unstable crack growth
- Usually neglected (we expect failure before Region III fully develops in actual parts)

- · Unstable crack growth
- Usually neglected (we expect failure before Region III fully develops in actual parts)
- Can be significant for parts where we expect high stress and relatively short life

CRACK GROWTH RATE CURVE

 $\boldsymbol{\cdot}$ The crack growth rate curve is considered a material property

CRACK GROWTH RATE CURVE

- The crack growth rate curve is considered a material property
- The same considerations for thickness apply as with fracture toughness (K_c vs. K_{lc})

CRACK GROWTH RATE CURVE

- The crack growth rate curve is considered a material property
- The same considerations for thickness apply as with fracture toughness (K_c vs. K_{lc})
- \cdot Is also a function of the load ratio, $R=\sigma_{min}/\sigma_{max}$

• While the x-axis can be either ΔK or K_{max} , the shape of the data is the same

- While the x-axis can be either ΔK or K_{max} , the shape of the data is the same
- When we look at the effects of load ratio, *R*, the axis causes some differences on the plot

- While the x-axis can be either ΔK or K_{max} , the shape of the data is the same
- When we look at the effects of load ratio, *R*, the axis causes some differences on the plot
- With ΔK on the x-axis, increasing R will shift the curve up and to the left, shifting the fatigue threshold and fracture toughness on the graph as well

- While the x-axis can be either ΔK or K_{max} , the shape of the data is the same
- When we look at the effects of load ratio, *R*, the axis causes some differences on the plot
- With ΔK on the x-axis, increasing R will shift the curve up and to the left, shifting the fatigue threshold and fracture toughness on the graph as well
- With K_{max} on the x-axis, increasing R shifts the curve down and to the right, but fatigue threshold and fracture toughness keep same values

- While the x-axis can be either ΔK or K_{max} , the shape of the data is the same
- When we look at the effects of load ratio, *R*, the axis causes some differences on the plot
- With ΔK on the x-axis, increasing R will shift the curve up and to the left, shifting the fatigue threshold and fracture toughness on the graph as well
- With K_{max} on the x-axis, increasing R shifts the curve down and to the right, but fatigue threshold and fracture toughness keep same values
- In general, R dependence vanishes for R > 0.8 or R < -0.3. This effect is known as the band width

 Whether integrating numerically or analytically, it is time-consuming to consider multiple repeated loads

- Whether integrating numerically or analytically, it is time-consuming to consider multiple repeated loads
- It is particularly difficult to consider flight loads, which can vary by "mission"

- Whether integrating numerically or analytically, it is time-consuming to consider multiple repeated loads
- It is particularly difficult to consider flight loads, which can vary by "mission"
- For example, an aircraft may fly three different routes, in no particular order, but with a known percentage of time spent in each route

- Whether integrating numerically or analytically, it is time-consuming to consider multiple repeated loads
- It is particularly difficult to consider flight loads, which can vary by "mission"
- For example, an aircraft may fly three different routes, in no particular order, but with a known percentage of time spent in each route
- Traditional methods would use a random mix of each load spectra

- Whether integrating numerically or analytically, it is time-consuming to consider multiple repeated loads
- It is particularly difficult to consider flight loads, which can vary by "mission"
- For example, an aircraft may fly three different routes, in no particular order, but with a known percentage of time spent in each route
- Traditional methods would use a random mix of each load spectra
- The Boeing Method combines each repeatable load spectrum into one single equivalent cycle

$$\frac{da}{dN} = \left[\frac{1}{n}\right] \frac{dL}{dN} = 10^{-4} \left[\frac{k_{max}Z}{m_T}\right]^p \tag{22.41}$$

$$\frac{da}{dN} = \left[\frac{1}{n}\right] \frac{dL}{dN} = 10^{-4} \left[\frac{k_{max}Z}{m_T}\right]^p \tag{22.41}$$

$$\frac{dL}{dN} = n10^{-4} \left[\frac{k_{max}Z}{m_T} \right]^p \tag{22.42}$$

$$\frac{da}{dN} = \left[\frac{1}{n}\right] \frac{dL}{dN} = 10^{-4} \left[\frac{k_{max}Z}{m_T}\right]^p \tag{22.41}$$

$$\frac{dL}{dN} = n10^{-4} \left[\frac{k_{max} Z}{m_T} \right]^{\rho} \tag{22.42}$$

$$\frac{dN}{dL} = \frac{1}{n} 10^4 \left[\frac{m_T}{k_{max} Z} \right]^p \tag{22.43}$$

$$\frac{da}{dN} = \left[\frac{1}{n}\right] \frac{dL}{dN} = 10^{-4} \left[\frac{k_{max}Z}{m_T}\right]^p \tag{22.41}$$

$$\frac{dL}{dN} = n10^{-4} \left[\frac{k_{max} Z}{m_T} \right]^p \tag{22.42}$$

$$\frac{dN}{dL} = \frac{1}{n} 10^4 \left[\frac{m_T}{k_{max} Z} \right]^p \tag{22.43}$$

$$\int_{0}^{N} dN = \frac{10^{4}}{n} \int_{L_{0}}^{L_{f}} \left[\frac{m_{T}}{k_{max} Z} \right]^{p} dL$$
 (22.44)

$$\frac{da}{dN} = \left[\frac{1}{n}\right] \frac{dL}{dN} = 10^{-4} \left[\frac{k_{max}Z}{m_T}\right]^p \tag{22.41}$$

$$\frac{dL}{dN} = n10^{-4} \left[\frac{k_{max} Z}{m_T} \right]^p \tag{22.42}$$

$$\frac{dN}{dL} = \frac{1}{n} 10^4 \left[\frac{m_T}{k_{max} Z} \right]^p \tag{22.43}$$

$$\int_{0}^{N} dN = \frac{10^{4}}{n} \int_{L_{0}}^{L_{f}} \left[\frac{m_{T}}{k_{max}Z} \right]^{p} dL$$
 (22.44)

$$N = 10^4 \left(\frac{m_t}{z\sigma_{max}}\right)^p \int_{L_0}^{L_f} \frac{dL}{\left(n\sqrt{\pi L/n}\beta\right)^p}$$
 (22.45)

• In this form, the term $10^4 \left(\frac{m_t}{z\sigma_{max}}\right)^p$ is strictly from the applied load and material, while $\int_{L_0}^{L_f} \frac{dL}{\left(n\sqrt{\pi L/n}\beta\right)^p}$ is from geometry

- In this form, the term $10^4 \left(\frac{m_t}{z\sigma_{max}}\right)^p$ is strictly from the applied load and material, while $\int_{L_0}^{L_f} \frac{dL}{\left(n\sqrt{\pi L/n}\beta\right)^p}$ is from geometry
- \cdot If we now define G to account for crack geometry

- In this form, the term $10^4 \left(\frac{m_t}{z\sigma_{max}}\right)^p$ is strictly from the applied load and material, while $\int_{L_0}^{L_f} \frac{dL}{\left(n\sqrt{\pi L/n}\beta\right)^p}$ is from geometry
- If we now define G to account for crack geometry

$$G = \left[\int_{L_0}^{L_f} \frac{dL}{\left(n \sqrt{\pi L/n} \beta \right)^p} \right]^{-1/p}$$
 (22.46)

- In this form, the term $10^4 \left(\frac{m_t}{z\sigma_{max}}\right)^p$ is strictly from the applied load and material, while $\int_{L_0}^{L_f} \frac{dL}{\left(n\sqrt{\pi L/n}\beta\right)^p}$ is from geometry
- If we now define G to account for crack geometry

$$G = \left[\int_{L_0}^{L_f} \frac{dL}{\left(n\sqrt{\pi L/n}\beta \right)^p} \right]^{-1/p} \tag{22.46}$$

• And define $z\sigma_{max}=S$ as the equivalent load spectrum, then we have

- In this form, the term $10^4 \left(\frac{m_t}{z\sigma_{max}}\right)^p$ is strictly from the applied load and material, while $\int_{L_0}^{L_f} \frac{dL}{\left(n\sqrt{\pi L/n}\beta\right)^p}$ is from geometry
- · If we now define G to account for crack geometry

$$G = \left[\int_{L_0}^{L_f} \frac{dL}{\left(n\sqrt{\pi L/n}\beta \right)^p} \right]^{-1/p} \tag{22.46}$$

• And define $z\sigma_{max}=S$ as the equivalent load spectrum, then we have

$$N = 10^4 \left(\frac{m_t/G}{S}\right)^p \tag{22.47}$$

- In this form, the term $10^4 \left(\frac{m_t}{z\sigma_{max}}\right)^p$ is strictly from the applied load and material, while $\int_{L_0}^{L_f} \frac{dL}{\left(n\sqrt{\pi L/n}\beta\right)^p}$ is from geometry
- · If we now define G to account for crack geometry

$$G = \left[\int_{L_0}^{L_f} \frac{dL}{\left(n\sqrt{\pi L/n}\beta \right)^p} \right]^{-1/p} \tag{22.46}$$

• And define $z\sigma_{max}=S$ as the equivalent load spectrum, then we have

$$N = 10^4 \left(\frac{m_t/G}{S}\right)^p \tag{22.47}$$

 Using this method, G is typically looked up from a chart (such as on p. 369)

• To replace a repeated load spectrum with an equivalent load, we need to invert the relationship

- To replace a repeated load spectrum with an equivalent load, we need to invert the relationship
- Equation 22.47 gives cycles per crack growth, inverting gives crack growth per cycle

- To replace a repeated load spectrum with an equivalent load, we need to invert the relationship
- Equation 22.47 gives cycles per crack growth, inverting gives crack growth per cycle

crack growth per cycle =
$$10^{-4} \left(\frac{m_t/G}{S} \right)^{-\rho}$$
 (22.48)

- To replace a repeated load spectrum with an equivalent load, we need to invert the relationship
- Equation 22.47 gives cycles per crack growth, inverting gives crack growth per cycle

crack growth per cycle =
$$10^{-4} \left(\frac{m_t/G}{S} \right)^{-\rho}$$
 (22.48)

· If we consider a general, repeatable "block", we have

- To replace a repeated load spectrum with an equivalent load, we need to invert the relationship
- Equation 22.47 gives cycles per crack growth, inverting gives crack growth per cycle

crack growth per cycle =
$$10^{-4} \left(\frac{m_t/G}{S} \right)^{-\rho}$$
 (22.48)

· If we consider a general, repeatable "block", we have

$$10^{-4} \left(m_t / G \right)^{-p} \sum_{i} \left(\frac{1}{z \sigma_{max}} \right)_{i}^{-p} N_i = 10^{-4} \left(\frac{m_t / G}{S} \right)^{-p}$$
 (22.49)

- To replace a repeated load spectrum with an equivalent load, we need to invert the relationship
- Equation 22.47 gives cycles per crack growth, inverting gives crack growth per cycle

crack growth per cycle =
$$10^{-4} \left(\frac{m_t/G}{S} \right)^{-p}$$
 (22.48)

· If we consider a general, repeatable "block", we have

$$10^{-4} \left(m_t / G \right)^{-p} \sum_{i} \left(\frac{1}{z \sigma_{max}} \right)_{i}^{-p} N_i = 10^{-4} \left(\frac{m_t / G}{S} \right)^{-p}$$
 (22.49)

Which simplifies to

$$\sum_{i} (Z\sigma_{max})_{i}^{p} N_{i} = (S)^{p}$$
(22.50)

CYCLE COUNTING

 As illustrated in our previous example, cycle counting method can make a difference for variable amplitude loads

CYCLE COUNTING

- As illustrated in our previous example, cycle counting method can make a difference for variable amplitude loads
- Two common methods for cycle counting that give similar results are known as the "rainflow" and "range-pair" methods

CYCLE COUNTING

- As illustrated in our previous example, cycle counting method can make a difference for variable amplitude loads
- Two common methods for cycle counting that give similar results are known as the "rainflow" and "range-pair" methods
- ASTM E1049-85 "Standard Practices for Cycle Counting in Fatigue Analysis"

1. Read next peak or valley. S is the starting point, Y is the first range, X is the second range

- 1. Read next peak or valley. S is the starting point, Y is the first range, X is the second range
- 2. If X < Y advance points (S remains same, Y and X change)

- 1. Read next peak or valley. *S* is the starting point, *Y* is the first range, *X* is the second range
- 2. If X < Y advance points (S remains same, Y and X change)
- 3. If $X \ge Y$ and Y contains S, count Y as 1/2-cycle, discard S and go to 1

- 1. Read next peak or valley. *S* is the starting point, *Y* is the first range, *X* is the second range
- 2. If X < Y advance points (S remains same, Y and X change)
- 3. If $X \ge Y$ and Y contains S, count Y as 1/2-cycle, discard S and go to 1
- 4. If $X \ge Y$ and Y does not contain S, count Y as 1 cycle, discard both points in Y and go to 1 (S remains same)

- 1. Read next peak or valley. *S* is the starting point, *Y* is the first range, *X* is the second range
- 2. If X < Y advance points (S remains same, Y and X change)
- 3. If $X \ge Y$ and Y contains S, count Y as 1/2-cycle, discard S and go to 1
- 4. If $X \ge Y$ and Y does not contain S, count Y as 1 cycle, discard both points in Y and go to 1 (S remains same)
- 5. When end of data is reached, count each range as 1/2-cycle

1. Read next peak or valley. *Y* is the first range, *X* is the second range

- 1. Read next peak or valley. *Y* is the first range, *X* is the second range
- 2. If X < Y advance points

- 1. Read next peak or valley. *Y* is the first range, *X* is the second range
- 2. If X < Y advance points
- 3. If $X \ge Y$, count Y as 1 cycle and discard both points in Y, go to 1

- 1. Read next peak or valley. *Y* is the first range, *X* is the second range
- 2. If X < Y advance points
- 3. If $X \ge Y$, count Y as 1 cycle and discard both points in Y, go to 1
- 4. Remaining cycles are counted backwards from end of history