CIE 418: Lecture 3, Nov 8



1.832

→ 2

EI

200 GPa

10's of thousand cm





Observations

- Normalize EI's by smallest value to get easy to use numbers (round if needed)

Example: distributing a moment





$100 = \Sigma M_{members}$






w
L/2
L/2
Shear
Moment