

Arc SelfTest Fault

Alarm Attribute

Alarm name	Alarm Severity	Alarm Category
Arc SelfTest Fault	General	Communication alarm

Possible Cause

Cause ID	Possible Cause
1	Arc board detects CT magnetic ring wiring fault and causes self-check error

Suggestion

1. Upgrade to the latest firmware and restart the inverter.
2. If the issue remains, provide the completed troubleshooting results to SolaX technical support team through video or images. Including but not limited to:
 - 1) SN number of the inverter.