

BMS Low Temperature

Alarm Attribute

Alarm name	Alarm Severity	Alarm Category
BMS Low Temperature	General	Battery alarm

Possible Cause

Cause ID	Possible Cause
1	Battery low-temperature fault

Suggestion

1.Upgrade the firmware to the latest version.

2.If the error persists,Use the T-BAT-Charger to check the detailed cell voltage and temperature information of each battery and provide to the SolaX technical support team for further analysis.If the T-BAT-Charger is unavailable,provide the inverter's SN number to the SolaX technical support team for further analysis.