

Battery Temperature Low

Alarm Attribute

Alarm name	Alarm Severity	Alarm Category
Battery Temperature Low	General	Communication alarm

Possible Cause

Cause ID	Possible Cause
1	Battery low temperature
2	Lead-acid battery temperature too high

Suggestion

- 1.Ensure the battery's operating environment is not subjected to extreme low temperatures.
- 2.Update both the inverter and battery firmware to the latest version, then restart the inverter and battery.
- 3.If the issue remains, provide the completed troubleshooting results to SolaX technical support team through video or images.Including but not limited to:
 - 1) SN number of the inverter.