

EPS Overload Fault

Alarm Attribute

Alarm name	Alarm Severity	Alarm Category
EPS Overload Fault	General Alarm	Inverter alarm

Possible Cause

Cause ID	Possible Cause
1	EPS Overload Faul

Suggestion

- 1.Reduce the EPS port load. If the error persists even after disconnecting all EPS port loads, check the wiring at the inverter's AC port.
- 2.Update the firmware to the latest version.If the issue remains, provide the inverter's SN number to the SolaX technical support team for further analysis.