

Low Temperature Fault

Alarm Attribute

Alarm name	Alarm Severity	Alarm Category
Low Temperature Fault	General	Inverter alarm

Possible Cause

Cause ID	Possible Cause
1	Operating malfunction caused by low temperature
2	Environment temperature too low

Suggestion

1. Upgrade the inverter firmware version to the latest.
2. Confirm that the operating environment of the equipment meets the requirements specified in the manual.
3. If the problem remains, take photos around the inverter's enclosure and send them to the SolaX technical support team for analysis.