

Parallel Fault

Alarm Attribute

Alarm name	Alarm Severity	Alarm Category
Parallel Fault	General	Inverter alarm

Possible Cause

Cause ID	Possible Cause
1	Parallel Malfunction
2	Inverter communication abnormality

Suggestion

1. Check if the communication cables between the inverters are correctly connected.
- 2.Ensure all inverters are updated to the same firmware version.
- 3.Restart all inverters and reapply the parallel settings.
4. If the issue remains, provide the completed troubleshooting results to SolaX technical support team through video or images.Including but not limited to:
 - 1) SN number of the inverter.
 - 2)The condition of the communication ports—communication cable ports between inverters. If damaged, please take a clear photo.
 - 3)The connection status of the communication cable—communication cable connections between inverters, clearly displaying the specific ports connected.
 - 4) Parallel settings.