

BAY PROCEDURE


Tacoma RV Center · Document Library

CONCERN FACR08 freeze up interior leak condensate
MODEL Furrion Chill rooftop unit
DATE 2026-09-19
WO# WO-FACR
PRIMARY Furrion rooftop HVAC service manual, assembly and condensate. The Chill book is for layout.

WHAT THIS PATTERN USUALLY MEANS

A Furrion rooftop freeze, interior leak, or condensate drip is an assembly and condensate problem. Work from the Furrion rooftop HVAC service manual for the base pan, the drain, and freeze or suction icing. The Furrion Chill model book is fine for layout. This is not a Dometic rooftop job, and it is not a Unity or OneControl board job.

VISUAL FLOWCHART



BAY ORDER (DO THIS FIRST)


- ☐ 1. Open the Furrion rooftop HVAC service manual for the assembly and condensate path. The Chill model book is fine for layout.
- ☐ 2. Inspect the rooftop assembly, the evaporator pan, and the condensate drain.
- ☐ 3. Clear ice or a restricted drain and confirm the drain path before you condemn the sealed system.
- ☐ 4. Retest cooling. If the freeze or leak returns, stay on the assembly and condensate path.

DO NOT

- Do not start at Unity or OneControl board manuals for this rooftop freeze.
- Do not start at a Dometic-only rooftop manual for a Furrion rooftop unit.
- Do not invent OEM steps, and do not skip the drain and base-pan check.

SOURCES (SHOP DOCUMENT LIBRARY)

- Furrion Rooftop HVAC Troubleshooting & Service Manual CCD-0007990
 - Furrion Chill FACR CCD-0008666
- Figures: Rooftop assembly, base pan, and drain - Furrion Rooftop HVAC Troubleshooting & Service Manual CCD-...



Rooftop assembly / base pan

Inspect the evaporator pan and the condensate drain.

If the drain is restricted or the pan is iced, clear it, then retest cooling.

Drain path