

TAPES & SOLDERS

VINYL - 1" and 2" used on IJs, sleeves, wrap joints, 2" ~~used on outer wrap on boots because it won't stretch~~. Also used to protect butt ends on PIC cables. **VINYL IS FINAL**

FRICTION - 3/4" and 2" rolls, sticky on both sides, used as a final aerial wrap, not use in underground because it is gasoline soluble.

B GLASS - 3/4" and 2" used in underground on wraps for strength and heat protection on IJ's, auxiliary sleeves and wrap joints.

~~**CR TAPE** - 28" wide rolls used to make temporary closures on splices and trouble openings.~~

DR TAPE - 3/4" and 2" used for strength and waterproofing on IJ's, auxiliary's & wrap joints.

B ALUMINUM - 2" and 4" used for heat and strength protection on IJ's, auxiliary sleeves and wrap joints. Smooth down with hammer handle.

B SEALING - 2" used as drip collars and inner dams on PASP cable. It is conductive.

SEIMANS TAPE - 3" used on cables and end disks in Seimans closures. Comes as part of a kit and is non-conductive.

PAPER TAPE - 1/2" and 3/8" used to patch paper and pulp insulation.

COTTON MUSLIN - Used to wrap pulp splices and over CR on a boot

B POLY - Used to wrap PIC splices in sealed closures

COTTON TUCKING - Various sizes, used to protect the butt ends of paper/pulp cables. Keeps sharp edges from damaging conductors.

LEAD SERVING - Used to make a top clip for terminal stubs and to make tags for splice closures. Second clip on lead stub.

TRAC TAPE - Used on cables for TRAC closures to fill openings.

SHOELACE - Used for cotton sleeves. Making Bliffe

KOLD N KLOSE - Used to repair damaged cable sheath

TBT-50 - Used with Kold N Klose on pressurized cables

SOLDERS

Bar or Seam Solder - Used to solder seams on lead sleeves.

E Wiping or Pig Solder - Used for Pot Wiping.

Aluminum Solder - Used on ALPETH Cables.

Rosin Core - Used in C/O's for cross wiring and soldering to copper.

Sterine Core - Used for wiping lead to lead and is also used to check serrations on long nose pliers