



BATT-PORT



SW1=TEST-BTN-OFF-ON

U1C1J1L1J1C1

USB-OUT

+

-

