

Lecture 11

Assignment Project Exam Help

<https://powcoder.com>

~~Add WeChat powcoder~~
Sensitivity transfer functions


Outline

- Motivation
- Examples
 - Assignment Project Exam Help
- Sensitivity transfer functions
- Steady state errors
 - <https://powcoder.com>
- Conclusions
 - Add WeChat powcoder


Motivation

- Any control system typically has a number of different inputs (reference inputs, different disturbances)
Assignment Project Exam Help
- We want output ~~https://powcoder.com~~ to be sensitive to the reference, but also insensitive to disturbances entering the loop.
Add WeChat powcoder
- Effects of references and disturbances on signals in the loop captured by a gang of four *sensitivity transfer functions*.

Example (room temperature control)




Example (room temperature)



- Reference signal = desired temperature $R(s)$
- Input disturbance = heat dissipation (outside temperature, opening doors & windows) $D_i(s)$
- Measurement noise $D_m(s)$


Example (room temperature)



Reference is typically a piecewise constant signal.




Input disturbance is typically a slowly varying large signal (low frequency, large amplitude).




Measurement noise is typically a fast varying small signal (high frequency, small amplitude).

Example (cruise control)




- Reference signal = desired velocity $R(s)$
- Input disturbance = slope of the road $D_i(s)$
- Measurement noise $D_m(s)$



Taken from Astrom and Murray, Feedback systems.

Example (cruise control)



Reference is typically a constant signal.

Input disturbance is typically a slowly varying large signal (low frequency, large amplitude).

Measurement noise is typically a fast varying small signal (high frequency, small amplitude).

Comments

- Examples suggest that different control systems share similar structure and inputs possess similar properties.

Assignment Project Exam Help


- We now consider a general closed loop and analyse the effect of various inputs on the output.

Add WeChat powcoder

Assignment Project Exam Help
Sensitivity transfer functions
<https://powcoder.com>
Add WeChat powcoder

Recall:

Turn off one input and compute the transfer function in the usual manner for the other input.




$$Y(s) = T_0(s)R(s) + S_0(s)D_o(s)$$

$$T_0(s) = \frac{Y(s)}{R(s)} = \frac{G_0(s)C(s)}{1 + G_0(s)C(s)} \quad \text{with only } r \neq 0$$

$$S_0(s) = \frac{Y(s)}{D_o(s)} = \frac{1}{1 + G_0(s)C(s)} \quad \text{with only } d_o \neq 0$$

This is how we will compute “sensitivity functions”.

Typical block diagram



Assignment Project Exam Help

$G_0(s) = \frac{B_0(s)}{A_0(s)}$ nominal plant transfer function,

Add WeChat powcoder

$C(s) = \frac{P(s)}{L(s)}$ controller transfer function

$\{B_0(s), A_0(s)\}$ and $\{P(s), L(s)\}$ coprime (no common roots) polynomial pairs

$D_i(s), D_o(s), D_m(s)$ plant input, plant output and measurement noise uncertainty

$R(s), U(s), Y(s)$ reference, control, and plant output signals

Coprime polynomials

- Transfer function with coprime polynomials
 $A_0(s), B_0(s)$

Assignment Project Exam Help

$$G_0(s) = \frac{B_0(s)}{A_0(s)} = \frac{s-3}{(s+1)(s+2)} = \frac{s-3}{s^2+3s+2}$$

- Transfer function with polynomials
that are NOT coprime

$$G_0(s) = \frac{B_0(s)}{A_0(s)} = \frac{s+1}{(s+1)(s+2)} = \frac{s+1}{s^2+3s+2}$$

Possible performance specifications:

- It would be good if the output follows the reference (despite disturbances); i.e. the error should be very sensitive to the reference input.
<https://powcoder.com>
Add WeChat powcoder
- It would be good if disturbance not to affect the error for any value of reference; i.e. the error should be insensitive to the disturbance input.

Transfer functions:

- From the block diagram we have

$$Y(s) = D_0(s) + G_0(s)(U(s) + D_i(s)) \quad (1)$$

$$U(s) = C(s)(R(s) - D_m(s) - Y(s)) \quad (2)$$

Assignment Project Exam Help

- Next we will show that there exist “sensitivity” transfer functions so that we can write:
<https://powcoder.com>
Add WeChat powcoder

$$Y(s) = T_0(s)R(s) + S_0(s)D_o(s) + S_{i0}D_i(s) - T_0(s)D_m(s)$$

$$U(s) = S_{u0}(s)(R(s) - D_m(s) - D_o(s) - G_0(s)D_i(s))$$

Transfer functions with Y as output

- We substitute (2) into (1) – i.e. eliminate U:

$$Y = D_0 + G_0 C(R - D_m - Y) + G_0 D_i$$

$$\underbrace{Y}_{\text{Assignment Project Exam Help}} = D_0 + G_0 C R - G_0 C D_m - G_0 C Y + G_0 D_i$$

$$Y(1 + G_0 C) = G_0 C R + D_0 + G_0 D_i - G_0 C D_m$$

$$Y(s) = \underbrace{\frac{G_0(s)C(s)}{1 + G_0(s)C(s)}}_{T_0(s)} R(s) + \underbrace{\frac{1}{1 + G_0(s)C(s)}}_{S_0(s)} D_0(s) +$$

$$\underbrace{\frac{G_0(s)}{1 + G_0(s)C(s)}}_{S_{i0}(s)} D_i(s) - \underbrace{\frac{G_0(s)C(s)}{1 + G_0(s)C(s)}}_{T_0(s)} D_m(s)$$

Transfer functions with U as output

- We substitute (1) into (2) – i.e. eliminate Y.
Please do this as an exercise! We obtain:

Assignment Project Exam Help

- $$U(s) = \frac{C(s)}{1+C(s)G_0(s)}(R(s) - D_m(s) - D_o(s)) - \frac{C(s)G_0(s)}{1+C(s)G_0(s)} D_i(s)$$

Add WeChat powcoder

- NB: Another approach to getting $Y(s)$ or $U(s)$
 1. Suppress all inputs except one
 2. Redraw the loop in unity or general feedback form. Use the corresponding transfer function to get $Y(s)$ or $U(s)$ in terms of that input.
 3. Use linear superposition to sum up the contributions from all inputs.

“Sensitivity” transfer functions:

- For nominal plant $G_0(s) = \frac{B_0(s)}{A_0(s)}$ and controller $C(s) = \frac{P(s)}{L(s)}$ we can define:
Assignment Project Exam Help

$$T_0(s) \doteq \frac{G_0(s)C(s)}{1 + G_0(s)C(s)} = \frac{P_0(s)P(s)}{A_0(s)L(s) + B_0(s)P(s)}$$

complementary sensitivity

$$S_0(s) \doteq \frac{1}{1 + G_0(s)C(s)} = \frac{A_0(s)L(s)}{A_0(s)L(s) + B_0(s)P(s)}$$

(output) sensitivity

$$S_{i0}(s) \doteq \frac{G_0(s)}{1 + G_0(s)C(s)} = \frac{B_0(s)L(s)}{A_0(s)L(s) + B_0(s)P(s)}$$

input-disturbance sensitivity

$$S_{u0}(s) \doteq \frac{C(s)}{1 + G_0(s)C(s)} = \frac{A_0(s)P(s)}{A_0(s)L(s) + B_0(s)P(s)}$$

control sensitivity

Algebraic relationships:

- Sensitivities are algebraically related:

Assignment Project Exam Help

$$S_0(s) + T_0(s) = 1, \quad S_{i0}(s) = G_0(s)S_0(s) = T_0(s)/C(s),$$


Add WeChat powcoder

$$S_{u0}(s) = S_0(s)C(s) = T_0(s)/G_0(s)$$

Assignment Project Exam Help
Special case: two inputs
<https://powcoder.com>

Add WeChat powcoder

Two inputs:



$$Y(s) = T_0(s)R(s) + S_0(s)D_o(s)$$

Add WeChat powcoder

$$T_0(s) = \frac{Y(s)}{R(s)} = \frac{G_0(s)C(s)}{1 + G_0(s)C(s)}$$

with only $r \neq 0$


$$S_0(s) = \frac{Y(s)}{D_o(s)} = \frac{1}{1 + G_0(s)C(s)}$$

with only $d_o \neq 0$

Important constraint:

- $C(s)$ is the only degree of freedom for “shaping” the two transfer functions.
- If we shape one transfer function (e.g. for good tracking), this fixes the other (e.g. for disturbance rejection).
- This may lead to a trade-off between:
 - Good tracking;
 - Good disturbance rejection.

Example:



Assignment Project Exam Help

$$G_0(s) = \frac{100}{0.01s + 1} \quad C(s) = K$$

<https://powcoder.com>

$$Y(s) = T_0(s)R(s) + S_0(s)D_o(s)$$

Add WeChat powcoder


$$S_0(s) = \frac{1}{1+G_0(s)C(s)} = \frac{1}{1+\frac{100K}{0.01s+1}} = \frac{0.01s+1}{0.01s+1+100K}$$

$$T_0(s) = \frac{G_0(s)C(s)}{1+G_0(s)C(s)} = \frac{\frac{100K}{0.01s+1}}{1+\frac{100K}{0.01s+1}} = \frac{100K}{0.01s+1+100K}$$

Bode diagram

$$\frac{1}{1 + G_0C}$$

increasing the controller gain K reduces the 'sensitivity' of the controlled output to *low* frequency disturbances at the plant output




$$\frac{G_0C}{1 + G_0C}$$

increasing the controller gain K increases the range of frequencies (i.e. oscillating signals) that can be tracked by the output without attenuation or lag in steady-state

Assignment Project Exam Help
Two degrees of freedom controllers

<https://powcoder.com>
Add WeChat powcoder

Input-output relationships



$H(s)$ is a stable transfer function (reference filter)

Add WeChat powcoder
provides a second degree-of-freedom for
'shaping' reference response

$$Y(s) = \frac{G_0(s)C(s)H(s)}{1 + G_0(s)C(s)}R(s) + \frac{1}{1 + G_0(s)C(s)}D_o(s) + \frac{G_0(s)}{1 + G_0(s)C(s)}D_i(s) - \frac{G_0(s)C(s)}{1 + G_0(s)C(s)}D_m(s)$$

can only 'shape' one of these closed-loop transfer functions using $C(s)$...
setting one determines the other two!!!

Disturbance-input relationships

- We are also interested in how disturbances affect the inputs so it is sometimes of interest to consider:

<https://powcoder.com>

$$\begin{aligned} U(s) &= \frac{C(s)H(s)}{1 + G_0(s)C(s)} R(s) - \frac{C(s)}{1 + G_0(s)C(s)} D_o(s) \\ &\quad - \frac{G_0(s)C(s)}{1 + G_0(s)C(s)} D_i(s) - \frac{C(s)}{1 + G_0(s)C(s)} D_m(s) \end{aligned}$$

Input and output relationships

- We can rewrite the original relationships as

$$Y(s) = T_0(s)H(s)B(s) + T_0(s)D_m(s) + S_{i0}(s)D_i(s)$$

$$U(s) = S_{u0} \left(H(s)B(s) - D_m(s) - D_i(s) - G_0(s)D_i(s) \right)$$

- We can obtain sensitivities in the same manner as before using the block diagram. Please do this as an exercise.

Conclusions

- We have introduced one and two degree of freedom controllers and have introduced different sensitivity functions.
<https://powcoder.com>
- Sensitivities ~~are algebraically related!~~ Add WeChat ~~powcoder~~ This typically leads to trade-offs in design.
- We will study in more detail these sensitivities in the next lecture.