Argus Master CAM CNC Software

Client Quick Testing Guide - Simple Step-by-Step Instructions

TEST IT LIVE IN YOUR BROWSER NOW (NO INSTALLATION REQUIRED):
Open this link on your computer: **https://arguscamcncsoftware.vercel.app**
Works instantly on Google Chrome, Microsoft Edge, Firefox, or Safari.

Note for the Client: Everything in this software is **100% dynamic**. When you change numbers, toolpaths recalculate in real-time. When you post-process, real CNC files are created and downloaded to your PC.

Step 1: Open the Software & Look at the Screen

#	What to Do	What You Will See
1.1	Click the link: **https://arguscamcncsoftware.vercel.app**	The software loads in a clean, professional **Light CAD Theme** (similar to SolidWorks and Mastercam).
1.2	Look at the **3D Viewport** in the center.	You see the 3D part and the machine table. You can rotate the 3D view with your left mouse button, pan with right click, and zoom with scroll wheel.
1.3	Look at the **left sidebar** (Operations Manager).	You will see ready-to-run toolpaths: **Face Milling**, **2D Dynamic Pocket**, **3D Waterline Finishing**, and **5-Axis Swarf**.

Step 2: Watch the 3D Tool Cut the Part (Backplot Simulation)

#	What to Do	What You Will See
2.1	Click the **Toolpaths** tab at the top Ribbon • Click **Backplot** (cyan icon) - OR click the **Play (>) button** on Operation #2 in the left list.	A realistic 3D cutting tool (fluted endmill, shank, and tapered spindle holder) appears directly inside the 3D workspace.
2.2	Click the **Play (>) button** on the bottom control bar.	The tool moves along the toolpath. Green/blue lines show cutting passes. Dashed yellow lines show rapid positioning moves.
2.3	Drag the **Timeline Slider** back and forth with your mouse.	The tool jumps to that exact moment. You see live **X, Y, Z coordinates (mm)** updating in real time on the screen.
2.4	Click **Verify Solid** on the bottom bar.	Watch the solid raw stock block get carved away as the tool cuts into the cavity.

Step 3: Change Cutting Settings & Watch Toolpaths Recalculate Live

#	What to Do	What You Will See
3.1	Click the green **Operations Wizard** button in the top Ribbon.	A settings window opens with options for Face Milling, Pocketing, Contouring, and 5-Axis.
3.2	Select **Dynamic Pocket** • Change **Stepdown** from 4.0 mm to 1.5 mm • Change **Stepover %** from 50% to 25%.	You are asking the software to cut smaller, shallower, more precise passes.
3.3	Click **Generate & Add Operation**.	The window closes. **Look at the 3D screen:** The toolpath lines recalculate immediately with much denser, finer cuts matching your exact numbers!

Step 4: Generate & Download Real CNC G-Code to Your Computer

#	What to Do	What You Will See
4.1	In the Ribbon (Toolpaths tab), click the blue **G1 Post** button (or **Post & Export**).	The **NC2Check 5-Axis Post-Processor & Audit** window opens.
4.2	Select your CNC machine controller from the dropdown: • **Siemens 840D / Sinumerik ONE** (`.mpf`) • **Heidenhain TNC 640 (PLANE SPATIAL)** (`.h`) • **Fanuc 31i-B5** (`.nc`) • **Haas NextGen** (`.nc`)	The post engine prepares correct syntax, header codes, and kinematic commands for that exact controller brand.
4.3	Click **Run Pre-Flight Audit & Generate G-Code**.	The software checks if the part fits within DMG MORI DMU 50 axis limits. You see total **G-Code block count**, **cutting distance in meters**, and **cycle time in minutes**.
4.4	Click **Download File**.	A real CNC program file downloads to your PC (e.g. DMU50_ZeroClamp_Job.nc). Open it in Notepad - it contains genuine G-code ready for a real CNC machine!

Step 5: Test Real Machining Physics (Feeds & Speeds)

#	What to Do	What You Will See
5.1	In the Ribbon, click the cyan **Feeds & Speeds** button.	The Machining Physics Calculator opens.
5.2	Change the **Material** from *Aluminum 6061* to *Titanium Ti-6Al-4V* or *Steel 4140*.	Watch the numbers update instantly: **Cutting Force (Fc in Newtons)**, **Spindle Power (kW)**, and **Torque (Nm)** increase to match the harder metal.
5.3	Increase **Tool Stickout** from 45 mm to 70 mm.	The **Tool Deflection (microns)** recalculates live using beam bending formulas. Warnings appear if deflection is too high for precision tolerances.

Step 6: Switch Between Light and Dark Theme (1-Click)

#	What to Do	What You Will See
6.1	Click the **Sun / Moon icon** in the top-right TitleBar.	The entire screen switches instantly between **Mastercam Light CAD** and **Industrial Dark CAD** with zero lag or page reload.

1-Minute Client Feedback & Sign-Off

Feature Tested	Did it work smoothly?	Client Rating / Comments
1. 3D Toolpath Backplot & Scrubber	[ ] YES [ ] NO	
2. Solid Material Removal Verify	[ ] YES [ ] NO	
3. Operations Wizard Recalculation	[ ] YES [ ] NO	
4. G-Code Post & File Download	[ ] YES [ ] NO	
5. Feeds & Speeds Physics Math	[ ] YES [ ] NO	
6. Light / Dark Theme Toggle	[ ] YES [ ] NO	

Evaluator Name: _____ **Company:** _____ **Date:** _____ **Verdict:** [ ] APPROVED [ ] REVISE