

PLASMA SPRAY PROCESSORS

Works Instruction

QF/QMS/02/02

Rev. 00

Date : 01/03/2019



Operations/Work/Job Activity covered by this assessment: Removal of Old Coating

Required Personal Protective Equipment (PPE) :



Safety glasses must be worn at times.



Long and loose hair must be contained.



Appropriate footwear with substantial uppers must be worn.



Close fitting/protective clothing to cover arms and legs must be worn.



Respiratory protection devices required.



Oil free leather gloves and spats must be worn.



Hearing protection must be used when using this machine.

Loading & Unloading Check:

1. Ensure no slip/trip is present in work pass and walk ways.
2. Ensure that work area is clean and clear of grease, oil and any flammable materials.
3. Refer Work Instructions PSP/WI/14 while handling.

Operations Procedure:

1. To remove the old coating by means of Grit Blasting to achieve a clean parent metal substrate for further processing of coating.
2. De-grease the component to ensure a clean surface. Pre-inspect the component and note dimension of in the pre-inspection report.
3. Look for defects like pin holes, dents etc. if any, report to the Quality inspector.
4. Grit blast the coating area with appropriate grit size and pressure (application based).
5. Polish the component to observe any deformity on the surface.
6. Check the actual dimension after polishing and record it.
7. Repair the defects with the help of welding/buffing/cut on a lathe, grinding etc. to make the component fit for coating.

Assessor :		Signature:		Date:	
Approved:		Signature:		Date:	