

PLASMA SPRAY PROCESSORS

Works Instruction

QF/QMS/02/12

Rev. 05

Date : 01.04.2026



Operations/Work/Job Activity covered by this assessment: Pre-Inspection

Required Personal Protective Equipment (PPE) :



Safety glasses must be worn at times.



Long and loose hair must be contained.



Appropriate footwear with substantial uppers must be worn.



Close fitting/protective clothing to cover arms and legs must be worn.



Respiratory protection devices required.



Oil free leather gloves and spats must be worn.



Hearing protection must be used when using this machine.

Loading & Unloading Check:

1. Ensure no slip/trip is present in work pass and walk ways.
2. Ensure that work area is clean and clear of grease, oil and any flammable materials.
3. Refer Work Instructions PSP/WI/14 while handling.
4. Refer VT Procedure PSP/PM/22 While Visual Inspection.

Operations Procedure:

Scope: To check whether the Component received from the customer is conformal to its requirements and defect free for further processing.

1. Check Schedule in Dashboard /Email & collect PIR from Admin.
2. Check PIR Comment Section , If job is our Manufacturing 100% inspection to be done.
3. Refer Code - Pre inspection code. In case of absence of quote one can proceed without code and give PR to ISR for making quotation.
4. Compare the component with Customer inspection Report & Drawings. In case any deviation must be escalated as per escalation matrix .
5. Also refer Inspection code document no QF-QA-26 for method of checking and cross-checking PIR format no.
6. Strictly Follow the checklist mentioned on the PIR to avoid missing any fundamental points and avoid delays and errors in job execution.
7. Carry out Visual Inspection as per VT Procedure Document No. PSP/PM/22

PLASMA SPRAY PROCESSORS Works Instruction	QF/QMS/02/12	
	Rev. 05	
	Date : 01.04.2026	

8. In case of any dents/Scratches found during inspection, QC Personnel must get clearance from Customer via email before proceeding further.
9. Dimension to be check using Calibrated Instruments. Always check for error and mention instrument no. on PIR.
10. Check if job is below 50 HRC, if above. Ensure that checking hardness should not damage coating area of job. For ex – like barrel of Rolls.
11. Compare the component with Customer inspection Report & Drawings. In case drawing not available make hand sketch and indicate dimensions.
12. In case of coating removals of job, a follow-up inspection is required post coating removal and same to be mentioned on PIR
13. Any extra work scope required to be mentioned on PIR and highlighted for easy identification of internal Sales representative.
14. Get clearance from Production Engineer/Works Manager for De-coating/Grinding/ Machining /Welding of the component according to the dimension size and customer specification.
15. Record components details like, punch no, As Received dimension, Customer Dimension, Deviation etc.
16. After getting the approval from the QA / customer the QC Inspector will approve the PIR. In case of regular and responsive customer QC to coordinate directly with customers
17. After approval, the PIR is marked completed and hand over to internal sales Representative.
18. In case of any unavailability of information, nonconformance, queries one can contact QA / ISR or raise query in daily meeting to resolve in timely manner.

Assessor :	Prassana Wadkar	Signature:	PSW	Date:	01.04.2026
Approved:	Haarsh Doshi	Signature:	HDD	Date:	01.04.2026