

PLASMA SPRAY PROCESSORS

Works Instruction

QF/QMS/02/25

Rev. 01

Date : 15/05/2024



Operations/Work/Job Activity covered by this assessment: Packing Procedure

Required Personal Protective Equipment (PPE) :



Safety glasses must be worn at times.



Long and loose hair must be contained.



Appropriate footwear with substantial uppers must be worn.



Close fitting/protective clothing to cover arms and legs must be worn.



Respiratory protection devices required.



Oil free leather gloves and spats must be worn.



Hearing protection must be used when using this machine.

Loading & Unloading Check:

1. Ensure no slip/trip is present in work pass and walkways.
2. Ensure that work area is clean and clear of grease, oil and any flammable materials.
3. Refer Work Instructions PSP/WI/14 while handling.

Operations Procedure:

1. Handling During Loading/Unloading

- The Packing Department must ensure all customer components are handled with utmost care during loading and unloading.
- Components must be placed securely in wooden or cardboard boxes to prevent any physical damage.

2. Coordination with Quality Department

- Before packing any outgoing components, obtain the Packing Slip/List from the Quality Department.
- This ensures traceability and proper documentation of all dispatched items.

3. Storage on Shop Floor

- When storing customer components on the shop floor, racks, or stands:
 - Use rubber sheets or wooden planks to avoid direct contact with hard surfaces.
 - This prevents scratches, dents, or any damage to the components.

4. Packing Method – Standard Components

- Wrap all customer components using the following four-layer protection:

Prepared BY	Prasanna W	Signature:	PSW	Date:	18/5/2024
Approved By	Haarsh Doshi	Signature:	HDD	Date:	18/5/2024



1. Rust Inhibitor Paper / Stretch Film (first layer)
2. Bubble Wrap or Foam Sheet (second layer)
3. Cotton Navar Strip (third layer)
4. Outer Film (fourth layer)

- During the rainy season, add an additional plastic sheet to protect against moisture.

5. Use of Customer-Supplied Boxes

- If using customer-provided boxes:
 - Inspect thoroughly for any damage or wear before use.
 - Do not dispatch components in compromised packaging.

6. Pre-Strapping Quality Check

- Before final strapping of boxes:
 - Inform the Quality Department.
 - Allow quality personnel to verify the arrangement of components inside the box.
 - Ensure photographs are taken for records.

7. Final Packing Checklist

- After packing:
 - Record weight and dimensions on the Packing Slip.
 - Inform the Office Personnel.
 - Collect and affix the Packing Label/List on the wooden or cardboard box.

8. Labelling Unboxed Components

- For components sent without wooden/cardboard boxes:
 - Wrap in film and cotton navar as per standard.
 - Affix a label indicating Job Number or Customer ID Number.

9. Packing Heavy Components

- For heavy components:
 - Apply three layers of standard wrapping (as above).
 - Secure with 1-inch Jute Rope.
 - Apply Plastic Sheet as the final, fourth layer.

Prepared BY	Prasanna W	Signature:	PSW	Date:	18/5/2024
Approved By	Haarsh Doshi	Signature:	HDD	Date:	18/5/2024

PLASMA SPRAY PROCESSORS

Works Instruction

QF/QMS/02/25

Rev. 01

Date : 15/05/2024



Technical Specifications

Material	Specification
Foam Sheet	1 mm thickness
Cotton Navar	2" width × 1.85 mm thickness
Stretch Film	3 microns
Plastic Sheet	20 microns
Rust Preventive Oil SOVCL 412	

Prepared BY	Prasanna W	Signature:	PSW	Date:	18/5/2024
Approved By	Haarsh Doshi	Signature:	HDD	Date:	18/5/2024