

PLASMA SPRAY PROCESSORS Works Instruction	QF/QMS/02/38	
	Rev. 00	
	Date : 14.04.2024	

Operations/Work/Job Activity covered by this assessment : Masking

Work Instructions:

1. PIR or Job card must be collected from Planner / ISR (Inbound Sales representatives) before Masking.
2. Determine the area which is to be masked from the sketch or drawing present in PIR.
3. Select the masking tape/masking putty/shim/metal masking according to the process mentioned in the PIR/job card, i.e Green tape for PLASMA Process & Silver tape/metal masking/putty/shim for HVOF Process.
4. Clean the component with the help of acetone and make sure component is oil and Dust free after cleaning.
5. Begin masking the component by leaving atleast a gap of 2mm from coating area.
6. Mask two times at area which is adjacent to Coating area.
7. Make sure to apply proper pressure and eliminate all air pockets with the help of wooden stick.
8. Use insulation Tapes to cover the uncoated area of the Component and their by Complete the masking.
9. Fill the timesheet after complete masking.

Assessor :	Prasanna Wadkar	Signature:		Date:	
Approved:	Haarsh Doshi	Signature:		Date:	