The following steps outline the procedure for operating the system to measure the product dimension, generate SVG carton dieline, and automate the dieline creasing.

Note: Ensure the camera is mounted in a fixed position slightly-above the object, with well-lit, even lighting to prevent shadows or bright reflections from messing up the camera's view. Double-check that a piece of cardboard is placed in the CNC machine before starting the creasing process.

1. Ensure the breaker switch is plugged into a power outlet.
2. Ensure all adapters are securely plugged into the extension cord.
3. Turn on the main switch on the extension cord.
4. Power on the prototype.
5. Launch the desktop application.
6. Place the object on the measurement platform according to the provided guides.
7. Click the “Capture measurements” button.
8. Generate the dieline pattern.
9. Save the dieline pattern as an SVG file.
10. Launch the LightBurn application.
11. Import the SVG file.
12. Start the creasing process.
13. Wait for the creasing process to complete.
14. Insert the object into the assembled carton to verify that it fits properly.